MICROPROCESSORS AND

MRCET

MICROCONTROLLERS LAB



ELECTRICAL AND ELECTRONICS ENGINEERING

VISION

To evolve into a center of excellence in Engineering Technology through creative and innovative practices in teaching-learning, promoting academic achievement & research excellence to produce internationally accepted competitive and world class professionals.

MISSION

To provide high quality academic programmes, training activities, research facilities and opportunities supported by continuous industry institute interaction aimed at employability, entrepreneurship, leadership and research aptitude among students.

QUALITY POLICY

**

*

*

Impart up-to-date knowledge to the students in Electronics & Communication area to make them quality engineers.

Make the students experience the applications on quality equipment and tools.

Provide systems, resources and training opportunities to achieve continuous improvement.

Maintain global standards in education, training and services.



PROGRAMME EDUCATIONAL OBJECTIVES (PEOs)

PEO1: PROFESSIONALISM & CITIZENSHIP

To create and sustain a community of learning in which students acquire knowledge and learn to apply it professionally with due consideration for ethical, ecological and economic issues.

PEO2: TECHNICAL ACCOMPLISHMENTS

To provide knowledge based services to satisfy the needs of society and the industry by providing hands on experience in various technologies in core field.

PEO3: INVENTION, INNOVATION AND CREATIVITY

To make the students to design, experiment, analyze, interpret in the core field with the help of other multi disciplinary concepts wherever applicable.

PEO4: PROFESSIONAL DEVELOPMENT

To educate the students to disseminate research findings with good soft skills and become a successful entrepreneur.

PEO5: HUMAN RESOURCE DEVELOPMENT

To graduate the students in building national capabilities in technology, education and research.

PROGRAMME SPECIFIC OBJECTIVES (PSOs)

PSO1

To develop a student community who acquire knowledge by ethical learning and fulfill the societal and industry needs in various technologies of core field.

PSO2

To nurture the students in designing, analyzing and interpreting required in research and development with exposure in multi disciplinary technologies in order to mould them as successful industry ready engineers/entrepreneurs

PSO3

To empower students with all round capabilities who will be useful in making nation strong in technology, education and research domains.

PROGRAM OUTCOMES (POs)

Engineering Graduates will be able to:

- 1. **Engineering knowledge**: Apply the knowledge of mathematics, science, engineering fundamentals, and an engineering specialization to the solution of complex engineering problems.
- 2. **Problem analysis**: Identify, formulate, review research literature, and analyze complex engineering problems reaching substantiated conclusions using first principles of mathematics, natural sciences, and engineering sciences.
- 3. **Design / development of solutions**: Design solutions for complex engineering problems and design system components or processes that meet the specified needs with appropriate consideration for the public health and safety, and the cultural, societal, and environmental considerations.
- 4. **Conduct investigations of complex problems**: Use research-based knowledge and research methods including design of experiments, analysis and interpretation of data, and synthesis of the information to provide valid conclusions.
- 5. **Modern tool usage**: Create, select, and apply appropriate techniques, resources, and modern engineering and IT tools including prediction and modeling to complex engineering activities with an understanding of the limitations.
- 6. **The engineer and society**: Apply reasoning informed by the contextual knowledge to assess societal, health, safety, legal and cultural issues and the consequent responsibilities relevant to the professional engineering practice.
- 7. **Environment and sustainability**: Understand the impact of the professional engineering solutions in societal and environmental contexts, and demonstrate the knowledge of, and need for sustainable development.
- 8. **Ethics**: Apply ethical principles and commit to professional ethics and responsibilities and norms of the engineering practice.
- 9. Individual and team work: Function effectively as an individual, and as a member or leader in diverse teams, and in multidisciplinary settings.
- 10. **Communication**: Communicate effectively on complex engineering activities with the engineering community and with society at large, such as, being able to comprehend and write effective reports and design documentation, make effective presentations, and give and receive clear instructions.
- 11. **Project management and finance**: Demonstrate knowledge and understanding of the engineering and management principles and apply these to one's own work, as a member and leader in a team, to manage projects and in multi disciplinary environments.
- 12. Life- long learning: Recognize the need for, and have the preparation and ability to engage in independent and life-long learning in the broadest context of technological change.

Course Objectives:

- To develop and execute variety of assembly language programs of Intel 8086 including arithmetic and logical, sorting, searching, and string manipulation operations.
- To develop and execute the assembly language programs for interfacing Intel 8086 with peripheral devices.
- To develop and execute simple programs on 8051 micro controller.

Course Outcomes:

After going through this course the student will be able to

- The student will learn the internal organization of popular 8086/8051 microprocessors/microcontrollers.
- The student will learn hardware and software interaction and integration.
- To apply the concepts in the design of microprocessor/microcontroller based systems in real time applications

LABORATORY RULES

General Rules of Conduct in Laboratories:

1. You are expected to arrive on time and not depart before the end of a laboratory.

2. You must not enter a lab unless you have permission from a technician or lecturer.

3. You are expected to comply with instructions, written or oral, that the laboratory Instructor gives you during the laboratory session.

4. You should behave in an orderly fashion always in the lab.

5. You must not stand on the stools or benches in the laboratory.

6. Keep the workbench tidy and do not place coats and bags on the benches.

7. You must ensure that at the end of the laboratory session all equipment used is stored away where you found it.

8. You must put all rubbish such as paper outside in the corridor bins. Broken components should be returned to the lab technician for safe disposal.

9. You must not remove test equipment, test leads or power cables from any lab without permission.

10. Eating, smoking and drinking in the laboratories are forbidden.

11. The use of mobile phones during laboratory sessions is forbidden.

12. The use of email or messaging software for personal communications during laboratory sessions is forbidden.

13. Playing computer games in laboratories is forbidden.

Specific Safety Rules for Laboratories:

1. You must not damage or tamper with the equipment or leads.

2. You should inspect laboratory equipment for visible damage before using it. If there is a problem with a piece of equipment, report it to the technician or lecturer. DONOT return equipment to a storage area

3. You should not work on circuits where the supply voltage exceeds 40 volts without very specific approval from your lab supervisor. If you need to work on such circuits, you should contact your supervisor for approval and instruction on how to do this safely before commencing the work.

4. Always use an appropriate stand for holding your soldering iron.

5. Turn off your soldering iron if it is unlikely to be used for more than 10 minutes.

6. Never leave a hot soldering iron unattended.

7. Never touch a soldering iron element or bit unless the iron has been disconnected from the mains and has had adequate time to cool down.

8. Never strip insulation from a wire with your teeth or a knife, always use an appropriate wire stripping tool.

9. Shield wire with your hands when cutting it with a pliers to prevent bits of wire flying about the bench.

INDEX

PART-A

1.	Introduction to MASM	7
2.	16-bit Arithmetic Operations	12
3.	Sorting of Array for 8086	26
4.	Searching for Character in a String	37
5.	Sting Manipulations for 8086	45

PART-B

6.	Introduction to Hardware experiments	72
7.	Digital Clock Design using 8086	81
8.	Interfacing ADC&DAC to 8086	88
9.	Parallel Communication between Two Microprocessors using 8255	94
10.	Interfacing stepper to 8086	98
11.	Arithmetic, Logical and Bit Manipulation Instructions of 8051	104
12.	Timer/Counters in 8051	114
13.	Interrupt Handling in 8051	118
14.	UART Operation in 8051	122
15.	Interfacing LCD to 8051	126
16.	Interfacing Matrix keyboard to 8051	133

PART-A

1. INTRODUCTION TO MASM

EDITOR

An editor is a program, which allows you to create a file containing the assembly language statements for your program. As you type in your program, the editor stores the ASCII codes for the letters and numbers in successive RAM locations. When you have typed in all of your programs, you then save the file on a floppy of hard disk. This file is called source file. The next step is to process the source file with an assembler. In the MASM /TASM assembler, you should give your source file name the extension, .ASM

ASSEMBLER

An assembler program is used to translate the assembly language mnemonics for instructions to the corresponding binary codes. When you run the assembler, it reads the source file of your program from the disk, where you saved it after editing on the first pass through the source program the assembler determines the displacement of named data items, the offset of labels and pails this information in a symbol table. On the second pass through the source program, the assembler produces the binary code for each instruction and inserts the offset etc that is calculated during the first pass. The assembler generates two files on floppy or hard disk. The first file called the object file is given the extension. OBJ. The object file contains the binary codes for the instructions and information about the addresses of the instructions. The second file generated by the assembler is called assembler list file. The list file contains your assembly language statements, the binary codes for each instructions and the offset for each instruction. In MASM/TASM assembler, MASM/TASM source file name ASM is used to assemble the file. Edit source file name LST is used to view the list file, which is generated, when you assemble the file.

LINKER

A linker is a program used to join several object files into one large object file and convert to an **exe** file. The linker produces a link file, which contains the binary codes for all the combined modules. The linker however doesn't assign absolute addresses to the program, it assigns is said to

7

MPMC Lab Manual

be reloadable because it can be put anywhere in memory to be run. In MASM/TASM, LINK/TLIN8K source filename is used to link the file.

DEBUGGER

A debugger is a program which allows you to load your object code program into system memory, execute the program and troubleshoot are debug it the debugger allows you to look at the contents of registers and memory locations after your program runs. It allows you to change the contents of register and memory locations after your program runs. It allows you to change the contents of register and memory locations and return the program. A debugger also allows you to set a break point at any point in the program. If you inset a breakpoint the debugger will run the program up to the instruction where the breakpoint is set and stop execution. You can then examine register and memory contents to see whether the results are correct at that point. In MASM/TASM, td filename is issued to debug the file.

DEBUGGER FUNCTIONS:

- 1. Debugger allows looking at the contents of registers and memory locations.
- 2. We can extend 8-bit register to 16-bit register which the help of extended register option.
- 3. Debugger allows setting breakpoints at any point with the program.
- 4. The debugger will run the program up to the instruction where the breakpoint is set and then stop execution of program. At this point, we can examine registry and memory contents at that point.
- 5. With the help of dump we can view register contents.
- 6. We can trace the program step by step with the help of F7.
- 7. We can execute the program completely at a time using F8

The DOS -Debugger:

The DOS "Debug" program is an example of simple debugger that comes with MS-DOS. Hence it is available on any PC .it was initially designed to give the user the capability to trace logical errors in executable file.

Below, are summarized the basic DOS - Debugger commands

COMMAND	SYNTAX
Assemble	A [address]
Compare	C range address
Dump	D [range]
Enter	E address [list]
Fill	F range list
Go	G [=address] [addresses]
Hex	H value1 value2
Input	l port
Load	L[address] [drive][first sector][number]
Move	M range address
Name	N[pathname][argument list]
Output	O port byte
Proceed	P [=address][number]
Quit	Q
Register	R[register]
Search	S range list
Trace	T [=address][value]
Unassembled	u [range]
Write	W[address][drive][first sector][number]

MS-MASM:

Microsoft's Macro Assembler (MASM) is an integrated software package Written by Microsoft Corporation for professional software developers. It consists of an editor, an assembler, a linker and a debugger (Code View). The programmer's workbench combines these four parts into a user-friendly programming environment with built in on line help. The following are the steps used if you are to run MASM from DOS

9

MICROPROCESSOR LAB EXECUTION PROCEDURE

STEP1: Opening the DOS prompt

Click **start** menu button and click on **Run** and then type *cmd at* command prompt immediately DOS window will be appeared

STEP2: Checking the masm installation

To know MASAM is installed or not simply type **masm** at the command prompt upon that it replies masm version vendor (Microsoft), etc... If you get any error there is no masm in that PC

STEP3: Directory changing (create a folder with your branch and no in D drive)

Change the current directory to your won directory suppose your folder in **D** drive type the following commands to change the directory at command prompt type **D**: hit enter now you are in **D** drive type **cd folder name** hit the enter

Example: D cd ece10

Now we are in folder cse10

STEP4: writing the program

At the command prompt type the edit programname.asm

Example. Edit add.asm

Immediately editor window will open and there you have to write the program. Type the program in that window after completion save the Program, to save the program Go to file opt in the menu bar and select save opt now your code is ready to Assemble.

STEP5: Assembling, Linking and executing the program

Go to *file* opt click *exit* opt now DOS prompt will be displayed to assemble the program type the following commands at the DOS prompt

Masm Program Name, Program Name, Program Name, Program Name hit the enter

Example: Masm add, add, add, add enter

OR

Example: Masm add.asm

If there are any errors in the program assembler reports all of them at the command prompt with line no's, if there are now bugs your ready to link the program. To link the program type the following line at command prompt Link program name,,,,, (5 commas)

Example: Link add,,,,,

OR

Example: link add.obj

After linking you are ready to execute the program. To execute the program type the following command

Debug program name.exe hit the enter

Example: Debug add.exe

Now you entered into the execution part of the program here you have to execute the program instruction by instruction (debugging) first of all press the *r* key(register) hit the enter key it'll displays all the registers and their initial values in HEXDECIMAL note down the values of all the register which are used in the program. To execute the next instruction press **t** key (TRACE) hit the enter it'll execute that instruction and displays the contents of all the register. You have to do this until you reach the last instruction of the program. After execution you have to observe the results (in memory or registers based on what you have written in the program).

STEP6: Copying list file (common for all programs):

A list file contains your code starting address and end address along with your program .For every program assembler generates a list file at your folder, programname.lst (ex. Add.lst) you should copy this to your lab observation Opening a list file

> Edit programname.lst Example. Edit add.lst

EXPERIMENT NO.2


16 BIT ARITHMETIC OPERATIONS

AIM: Write an ALP to 8086 to perform 16-bit arithmetic operations in various Addressing Modes

TOOLS: PC installed with MASM

ALGORITHM:

Step I	:	Initialize the Data segment memory.
Step II	:	Initialize the Extra segment memory.
Step III	:	Load the first number into AX register.
Step IV	:	Add two numbers.
Step V	:	Store the result in Extra segment.
Step VI	:	Terminate the program
Step VII	:	Stop.



MPMC Lab Manual

PROGRAM:

(A) to bit dualiton using anterent dualessing modes	(A) 16-bit add	lition using differ	rent addressing modes
---	----------------	---------------------	-----------------------

ASSUME CS: CODE, DS: DATA, ES: EXTRA DATA SEGMENT

> OPR1 DW 5169H OPR2 DW 1000H

DATA ENDS

EXTRA SEGMENT

SUM DW ?

EXTRA ENDS CODE

SEGMENT START:

MOV AX, DATA

MOV DS, AX	; REGISTER ADDRESING MODE
MOV AX, OPR1	; DIRECT ADDRESSING MODE
ADD AX, OPR2	; DIRECT ADDRESSING MODE
MOV SUM, AX	; DIRECT ADDRESSING MODE
INT 03H	

CODE ENDS


END START

END

(B) 16-bit subtraction using different addressing modes

ALGORITHM:


Step I	:	Initialize the data & extra segment memory.
Step II	:	Load the first number into AX register.
Step IV	:	Sub AX from OPR2.
Step V	:	Store result in extra segment
Step VI	:	verify the result.
Step VII	:	Stop.



(C)16-bit Multiplication using different addressing modes

ALGORITHM:

:	Initialize the data & extra segment memory.
:	Load the first number into AX register.
:	Load the second number into BX register.
:	Multiply AX with BX.
:	store lower word in accumulator into extra segment.
:	Store Upper word in DX register into extra segment
:	Verify the result.
:	Stop.
	::



PROGRAM:

ASSUME CS: CODE, DS: DATA, ES: EXTRA

DATA SEGMENT

OPR1 DW 5169H

OPR2 DW 1000H

DATA ENDS

EXTRA SEGMENT

RES DW 2 DUP(0)

EXTRA ENDS

CODE SEGMENT


START:MOV AX,DATA

MOV DS,AX	; REGISTER ADDRESIING MODE
MOV AX,EXTRA	
MOV ES, AX	; REGISTER ADDRESIING MODE
MOV SI, OFFSET OPR	1
MOV AX,[SI]	; INDEXED ADDRESSING MODE
MOV BX,OPR2	; DIRECT ADDRESSING MODE
MUL BX	; REGISTER ADDRESSING MODE
MOV RES, AX	; DIRECT ADDRESSING MODE
MOV RES+2, DX	; DIRECT ADDRESSING MODE
INT 03H	
CODE ENDS	
END START	
END	

(D)16-bit Division using different addressing modes

ALGORITHM:

Step I	:	Initialize the data & extra segment memory.
Step II	:	Load the first number into DX:AX register pair.
Step III	:	Load the second number into BX register.
Step IV	:	Divide DX:AX pair by BX.
Step V	:	store the Quotient in AX register into extra segment.
Step VI	:	Store the reminder in DX register into extra segment.
Step VII	:	Verify the result.
Step VIII	:	Stop.



PROGRAM:

ASSUME CS: CODE, DS:DATA, ES:EXTRA

DATA SEGMENT

OPR1 DD 74105169H

OPR2 DW 7875H

DATA ENDS

EXTRA SEGMENT

DIVQ DW ?

DIVR DW ?

EXTRA ENDS

CODE SEGMENT

START:MOV AX, DATA				
MOV DS, AX	; REGISTER ADDRESIING MODE			
MOV AX, EXTRA				
MOV ES, AX	; REGISTER ADDRESIING MODE			
MOV SI, OFFSET OF	PR1			
MOV AX, [SI]	; INDEXED ADDRESSING MODE/			
MOV DX, [SI+2]	; INDEXED ADDRESSING MODE			
MOV BX, OPR2	; DIRECT ADDRESSING MODE			
DIV BX	; REGISTER ADDRESSING MODE			
MOV DIVQ, AX				
MOV DIVR, DX				
INT 03H				

CODE ENDS

END START

END

Result:

UNSIGNED NUMBERS

INPUT: OPR1 =

OPR2 =

OUTPUT: ALL RESULTS ARE STORED IN EXTRA SEGMENT (ES)

- SUM =
- DIFF=
- MUL=

MUL+2=

DIVQ=

DIVR=

Exercise Questions:

1) Write an assembly language program for the expression ax+b

2) Write an assembly language program for the squaring of 16 bit Hexa Decimal number.

3) Write an assembly language program for the factorial of 8 bit Hexadecimal number.

Viva Question:

- 1) What is meant by microprocessor?
- 2) What is meant by accumulator?
- 3) What is meant by assembler directive?
- 4) What are segment Registers?
- 5) What is the use of INT 03H instruction ?

OBSERVATION:

EXPERIMENT NO.3

SORTING AN ARRAY FOR 8086

AIM: Write and execute an ALP to 8086 processor to sort the given 16-bit numbers

in Ascending and Descending order.

TOOLS: PC installed with MASM 6.11

ALGORITHM:

Step I: Initialize the data segment memory.

Step II : Initialize the number of elements counter

Step III : Initialize the comparisons counter..

Step IV: Load the numbers into respective registers

Step V: Compare the elements. If first element < second element goto step VII Else go to next step.

Step VI: Swap the numbers in the memory..


Step VII: Increment memory pointer & Decrement the comparison counter.

Step VIII: Is count = 0 ? if yes go to next step else go to **step IV**.

Step IX: decrement the element counter.

Step X: Is count not 0 ? go Step III else go to next step

Step IX: Stop & terminate the program.



PROGRAM:

ASCENDING ORDER

ASSUME CS: CODE, DS: DATA

DATA SEGMENT

LIST DW 0125H,0144H,3001H,0003H,0002H

COUNT EQU 05H

DATA ENDS

CODE SEGMENT

START: MOV AX, DATA

MOV DS,AX

MOV DX,COUNT-1

BACK: MOV CX,DX

MOV SI, OFFSET LIST

AGAIN: MOV AX,[SI]

CMP AX,[SI+2]

JC GO

XCHG AX,[SI+2]

XCHG AX,[SI]

GO:INC SI

INC SI

LOOP AGAIN

DEC DX

JNZ BACK

INT 03H

CODE ENDS

END START

END

Result:

INPUT: (DS: 0000H) = 25H,01H,44H,01H,01H,30H,03H,00H,02H,00H OUTPUT: (DS: 0000H) =

DESCENDING ORDER

ALGORITHM:

Step I: Initialize the data segment memory.

Step II : Initialize the number of elements counter

Step III : Initialize the comparisons counter..

Step IV: Load the numbers into respective registers

Step V: Compare the elements. If first element > second element go to step VII Else go to next step.


Step VI: Swap the numbers in the memory.

Step VII: Increment memory pointer & Decrement the comparison counter.

Step VIII: Is count = 0? If yes go to next step else go to step IV.

Step IX: decrement the element counter.

Step X: Is count not 0? go Step III else go to next step Step IX: Stop & terminate the program.



DESCENDING ORDER

PROGRAM:

ASSUME CS: CODE, DS:DATA

DATA SEGMENT

LIST DW 0125H,0144H,3001H,0003H,0002H

COUNT EQU 05H

DATA ENDS

CODE SEGMENT

START: MOV AX, DATA

MOV DS,AX

MOV DX,COUNT-1

BACK:MOV CX,DX

MOV SI, OFFSET LIST

AGAIN:MOV AX,[SI]

CMP AX,[SI+2]

JAE GO

XCHG AX,[SI+2]

XCHG AX,[SI]

GO:INC SI

INC SI

LOOP AGAIN

DEC DX

JNZ BACK

INT 03H

CODE ENDS

END START

END

Result:

INPUT: (DS: 0000H) = 25H,01H,44H,01H,01H,30H,03H,00H,02H,00H

OUTPUT: (DS: 0000H) =

Exercise Questions:

- 1) Write an assembly language program for finding the maximum number in array of five 16 bit hexadecimal numbers?
- 2) Write an assembly language program for finding the minimum number in array of five 16 bit hexadecimal numbers?

Viva Questions:

- 1) What is the use of SI Register?
- 2) What is the use of XCHG instruction?
- 3) What is the use of CX Register ?
- 4) What is the use of JNZ instruction?

OBSERVATION:

EXPERIMENT NO: 4


SEARCH ING FOR CHARACTER IN A STRING

AIM: Write an ALP for searching for a number or character in a string for 8086.

TOOLS: PC installed with MASM 6.11

- **Step I** : Initialize the Data segment (DS) & Extra segment(ES)
- **Step II** : Load the offset address of the string into SI.
- **Step III** : Load the number of elements in the string into CX register
- **Step IV** : Move the character to be searched into the AL register
- **Step V** : Scan for the character in ES. If the character is not found go to step **VII** else go to next step.
- **Step VI** : Display the message that character found and go to step **VIII**
- **Step VII** : Display the message that character not found
- **Step VII** : Stop.& Terminate the program

FLOW CHART:



Program:

ASSUME CS: CODE, DS: DATA DATA SEGMENT

STRING DB 'MRCET\$'

SLEN EQU (\$-STRING)

CHAR DB 'E'

MSG1 DB 'THE CHARACTER IS FOUND\$'

MSG2 DB 'THE CHARACTER IS NOT FOUND\$'

DATA ENDS

CODE SEGMENT

START: MOV AX, DATA

MOV DS, AX

MOV ES, AX

LEA SI, STRING

MOV CX, LEN

MOV AL, CHAR

CLD

REPNE SCASB

JNZ EXIT

LEA DX, MSG1

MOV AH, 09H

INT 21H

JMP GOTOEND

EXIT: LEA DX, MSG2

MOV AH, 09H

INT 21H

GOTOEND: MOV AH, 4CH

INT 21H

CODE ENDS

END START

END

Exercise Questions:

1) Write an assembly language program for the password verification?

Viva Questions:

- 1) What is the use of SCASB Register?
- 2) What is the use of REPNE instruction?
- 3) What is the relation of CX Register with REPNE?

OBSERVATION:

EXPERIMENT NO.5


STRING MANIPULATIONS FOR 8086

AIM: To write an assembly language program to move the block of data from a source BLOCK to the specified destination BLOCK.

TOOLS: PC installed with MASM 6.11

A) BLOCK TRANSFER

- **Step I** : Initialize the Data segment (DS) & Extra segment (ES)
- **Step II** : Load the offset address of source and destination the string into SI and DI.
- **Step III** : Load the number of elements of the string into Count register(CL)
- **Step IV** : Clear Direction flag (DF) to make SI and DI into auto increment mode
- **Step V** : move the character by character from source to destination till the end
- **Step VI** : Stop & Terminate the program



PROGRAM:

ASSUME CS: CODE, DS: DATA

DATA SEGMENT

STRING DB 'MICROPROCESSOR\$'

COUNT EQU (\$-STRING)

ORG 0070H

DATA ENDS

EXTRA SEGMENT

ORG 0010H

STRING1 DB ?

EXTRA ENDS

CODE SEGMENT

START:

MOV AX,DATA MOV DS,AX MOV AX, EXTRA MOV ES,AX MOV SI,OFFSET STRING MOV DI,OFFSET STRING1 MOV CL,COUNT CLD REP MOVSB INT 03H CODE ENDS END START

RESULT:

END


INPUT: (DS: 0000H) = MICROPROCESSOR OUTPUT: (ES: 0010H) = MICROPROCESSOR

B) REVERSE STRING

AIM: To write an assembly language program to reverse the given string.

TOOLS: PC installed with MASM 6.11

- **Step I** : Initialize the Data segment (DS) & Extra segment (ES)
- Step II : Load the offset address of source and destination the string into SI and DI.
- **Step III** : Load the number of elements of the string into Count Register (CX)
- **Step IV** : Add CX to DI to Point to last location of the memory
- **Step V** : move the character by character from source to destination till the end
- **Step VI** : Stop & Terminate the program



PROGRAM:

ASSUME CS: CODE, DS: DATA ,ES:EXTRA

DATA SEGMENT

STRING1 DB 'MICROPROCESSOR\$'

STRLEN EQU (\$-STRING1)

DATA ENDS

EXTRA SEGMENT

STRING2 DB ?

EXTRA ENDS

CODE SEGMENT

START: MOV AX, DATA

MOV DS, AX

MOV AX, EXTRA

MOV ES, AX

MOV SI, OFFSET STRING1

MOV DI, OFFSET STRING2

MOV CX, STRLEN-1

ADD DI, CX

MOV DL,'\$'

MOV ES:[DI],DL

AGAIN: DEC DI

MOV AL,DS:[SI]

MOV ES:[DI],AL

INC SI

DEC CX

JNZ AGAIN

INT 3H

RESULT:

INPUT: ' MICROPROCESSOR'


OUTPUT: 'ROSSECORPORCIM'

C) LENGTH OF THE STRING

AIM: To write an assembly language program to find the length of the given string.

TOOLS: PC installed with MASM 6.11

- **Step I** : Initialize the data segment (DS)
- Step II : Initialize the counter CL with 0
- Step III : Move stating address of the string to SI register
- **Step IV** : Move the each character from memory to to Accumulator (AL)
- Step V : Compare AL with last character of the string i.e \$ and increment CL until ZF=0



MPMC Lab Manual

Program:

ASSUME CS:CODE, DS:DATA

DATA SEGMENT

STRING1 DB 'MICROPROCESSOR AND INTERFACING

LAB\$' SLENGTH DB 0

DATA ENDS

CODE SEGMENT

START: MOV AX, DATA

MOV DS, AX

SUB CL, CL

MOV SI, OFFSET STRING1

CLD

BACK: LODSB

INC CL

CMP AL,'\$'

JNZ BACK

DEC CL

MOV SLENGTH, CL

INT 03H

CODE ENDS

END START

RESULT: INPUT: 'MICROPROCESSOR AND INTERFACING LAB

OUTPUT:

D) STRING COMPARISON


AIM: Write an ALP to 8086 to compare the given strings.

TOOLS: PC installed with MASM 6.11

ALGORITHM:

- **Step I** : Initialize the data segment (DS) & extra Segment as per requirement
- **Step II** : Load the offset address of source and destination of the string into SI and DI.
- **Step III** : Initialize the counter register CX with length of source string
- **Step IV** : Clear Direction flag (DF) to make SI and DI into auto increment mode
- **Step V** : Compare source string with destination string until the characters are not equal or up to last last character
 - **Step VII** : If ZF=0 the strings are equal or otherwise the strings are not equal

Step VIII : Stop.



Program:

ASSUME CS: CODE, DS:DATA, ES:EXTRA

DATA SEGMENT

STRING1 DB 'MRCET'

STRLEN EQU (\$-STRING1)

SNOTEQUAL DB 'STRINGS ARE UNEQUAL\$'

SEQUAL DB 'STRINGS ARE EQUAL\$'

DATA ENDS

EXTRA SEGMENT

STRING2 DB 'MRCET'

EXTRA ENDS

CODE SEGMENT

START: MOV AX, DATA

MOV DS,AX

MOV AX, EXTRA

MOV ES,AX

MOV SI, OFFSET STRING1

MOV DI, OFFSET STRING2

CLD

MOV CX, STRLEN

REPZ CMPSB

JZ FORW

MOV AH, 09H

MOV DX, OFFSET SNOTEQUAL

INT 21H

JMP EXITP

FORW: MOV AH,09H

MOV DX, OFFSET SEQUAL

INT 21H

EXITP: MOV AH, 4CH

INT 03H

CODE ENDS

END START

RESULT: INPUT:

OUTPUT:

(E) STRING INSERTION

AIM: To Write and execute an Assembly language Program (ALP) to 8086 processor to insert or delete a character/ number from the given string.

TOOLS: PC installed with MASM 6.11

ALGORITHM:

Step I :Initialize the data segment (DS) & extra segment (ES)

Step II :Load the offset address of source and destination of the string into SI and DI.

Step III : Initialize the counter register CX with length of first part of source string

Step IV : Copy the first part of STRING1 in to STRING3 of extra segment

Step V : Load the offset address of STRING2 in to SI


Step VI : Copy the STRING2 in to STRING3 of extra segment after first string of STRING1

Step VII: Load the new offset address of source of the STRING1 into SI

Step VIII: Copy the second part of STRING1 in to extra segment

Step IX: Stop

MPMC Lab Manual



Program:

ASSUME CS:CODE, DS:DATA, ES:EXTRA

DATA SEGMENT

STRING1 DB 'MICROPROCESSOR INTERFACING LAB\$'

STRING2 DB 'AND '

STRLEN EQU (\$-STRING1)

ORG 0070H

DATA ENDS

EXTRA SEGMENT

ORG 0010H

STRING3 DB 38 DUP(0)

EXTRA ENDS

CODE SEGMENT

START: MOV AX, DATA

MOV DS, AX

MOV AX, EXTRA

MOV ES, AX

MOV SI, OFFSET STRING1

MOV DI, OFFSET STRING3

CLD

MOV CX, 15

REP MOVSB

CLD

MOV SI, OFFSET STRING2

MOV CX,4

REP MOVSB

MOV SI, OFFSET STRING1

ADD SI,15

MOV CX, 15

REP MOVSB

INT 3H

CODE ENDS

END START

RESULT:

INPUT:	STRING1: 'MICROPROCESSOR INTERFACING LAB'
	STRING2: 'AND '
OUTPUT:	STRING3: 'MICROPROCESSOR AND INTERFACING LAB'

(F) STRING DELETION

ASSUME CS: CODE, DS:DATA, ES:EXTRA

DATA SEGMENT

STRING1 DB 'MICROPROCESSOR AND INTERFACING LAB\$'

ORG 0070

DATA ENDS

EXTRA SEGMENT

ORG 0010H

STRING2 DB 40 DUP (0)

EXTRA ENDS

CODE SEGMENT

START: MOV AX, DATA MOV DS, AX MOV AX, EXTRA MOV ES, AX MOV SI, OFFSET STRING1 MOV DI, OFFSET STRING2 CLD MOV CX, 15 REP MOVSB CLD MOV SI, OFFSET STRING1 ADD SI, 19

MOV CX, 15

REP MOVSB

INT 03H

CODE ENDS

END START

RESULT:

INPUT:	STRING1: MICROPROCESSOR AND INTERFACING LAB'
OUTPUT:	STRING2: 'MICROPROCESSOR INTERFACING LAB'

Exercise Questions:

- 1) Write an assembly language program for the palindrome of a given string?
- 2) Write an assembly language program for the display of given string?

Viva Questions:

- 1) What are the string manipulation instructions?
- 2) What are the repeat instructions?
- 3) What is the use of DUP instruction?
- 4) What is the meaning of ORG assembler Directive?

OBSERVATION:

PART-B

INTRODUCTION TO HARDWARE EXPERIMENTS


8086 Programs can also executed by using ADM TK_ μ P Trainer kits. The Assembly language programs (ALP) can be executed by the following steps

- 1. UxAsm
- 2. ΤΚμΡ
- 1. UxAsm: It is used to translate the Assembly language program in to Machine language (Hex

File). The input file to the UxAsm is .asm and one of the output files is hex file

Procedure for UXASM:

1. Go to start and select UXAsm



2. Verify the license by observing the following window and click "OK"

/ Documents		Keil_uVision_4	shOeyac		
My Computer	SdContigE:: v4	NEW	Procedure for IKI Ip		
My Network. Places	Dew Folder	New Microsoft Office Wor	Procedure For FRAM		
	New Fulder (2)		UX	lsm 🔀	
Internet Explorer	verb sat	project1	4	Use profiler is located to www.sobs greec, D40D7EA00C00 ADM, 01-JUL-2010.	
AVR Studio 5.0	PLAN(1)	projecti Javapt		UXashii	
Black Jawk Control Pa	Addition	projecti uv			
Code Compo		STARTUP.ASI			
DAEMON Tools		TKUP86	ord 🔟 Procedure for UXASM		PK 4 5

3. Go to file and select "open source" and browse the source file(.ASM file)

My Document:		Doyaé	
	UXAsm - example < C:\ADMV		
	File Edit View Build Window Hel		
	New_Source	P C R R	
	Open_Source		
	Save_Source		
My Network	New Project Ctrl+N	sm	
Places	Open Project Ctrl+O		
-	Edit Project		
	Close Project		
-	Save Project Ctrl I S		
Recycle Bin	Save As		
	CopySnoFile		
\mathbf{i}	GetNIC		
	1 D:\NewFolder\example		
Internet	2 D:\surya\Addition		
Explorer	3 D:\New Folder\example		
	4 E:\ece\Addition		
2	Exit		
AVR Studio 5	LAR		
Blackhawk. Control Pa			
Code	Open source file to edit Counter-strike STARTUP.AST	NUM NUM	
Compo	1.6		
Ð			
DAEMON Tool Lite	s Keil uVision4 TKUP86		
	👻 uxasm - Microsoft Word	Procedure for UXASM	🔣 🛃 🧐 🖉 3-15 PM

4. Observe the following window which shows the source code.

; the basic reset jump ; load stack pointer ; initialize 8255
; the basic reset jump ; load stack pointer
; the basic reset jump ; load stack pointer
; load stack pointer
; clear num1 variable ; call delay ; use num1 for led count value ; ; ; ;

5. Again go to file select "New Project"

	IXAsm - example File Edit View Build Window Hel New Source	k and a first first		
	Open_Source Save_Source	P C B R		
work	New Project Ctrl+N Open Project Ctrl+O Edit Project Close Project Save Project Ctrl+S Save As	UP86.DEF" i , ofoooh	; the basic reset jump	
5	CopySnoFile GetNIC 1 D:\NewFolder\example	SP, STKPTR INIT8255 AL, 00H BX,NUM1 [BX],AL	; load stack pointer ; initialize 8255 ; ; ; clear numl variable	
not rer	2 D:\surya\Addition D D:\New Folder\example 4 F:\ere\Addition	L DELAY AL,[BX] DX,PA8255 DX,AL	; clean humi valiable ; call delay ; use numi for led count value ;	
tin 5	007.	DX,PB8255 F DX,AL 7 DX,PC8255	; ; ;	
awk Pa				
e 0	Create a new project Counter-strike STAKTUP:AST 1.6		Ln 1 NUM	

6. To add source file click on "Add File" and browse the source file and provide the source file path with .Uxa extension in the Project and press Tab and Press "Save" and click on "OK"

My Documents Mozilla Firefox Kell_uVision_4 xhOcya6			
My Compute File Edit View Build Window Help Dig D & D & D & P C B R			
My Network Places File List	Project(* uxa)		
File List F:VedVa.asm File List F:VedVa.asm Internet Explorer	F:VedVa.uxa F:VedVa.uxa MDB (CPU specific) File [C:VDMVUXAsm\8086\WX8086.MDB HEX File F:VedVa.HEX SYM File	Browse CPU_MDB	
AVR Studio 5 Add File Remove File MDB File	F:VedVa.SYM		
Eladhawk Control Pa For Help, press F1 Code Colliner-strike STARTUP/ASI	in 1	NUM	
Compo 1.6			
🛃 start 🛛 🖾 uxasm - Microsoft Word 🖓 Procedure for UXASM 🔛	UXAsm - example		🌃 🗊 🧐 🖉 3:23 PM

7. Observe the following window and double click on path of the File to view the program

🚟 UXAsm - digclk		
File Edit View Build Window Help		
	U B R	
Project Files Files Fi	DEF" INCLUDE EXTERNS NOW START CODING HERE	
START :	ORG OFFOODI MOV SP,STKPTR ; load ctack pointor CALL INIT8255 ; initialize 8255 MOV AL.OCH MOV [0200H], AL MOV [0200H], AL MOV AL, OOH 0014H 0014H 0014H D14 2014 0014H D14 EC 28255 07H L EC 28255	×
For Help, press F1		Ln 1 NUM
🥵 🧐 🖉 🦉 🛃 👘	NGSTON (G:) 📝 MICROPROCESSOR 🧮 UXAsm digelk	🍳 🗞 📶 🕺 2:24 PM

8. To save the project go to File select "save project"

🄌 🙆 👔	📚 🗾			
My Documents Mozilla Firefox Keil_u' (Wision_4 xhOcya6 (1)			
My Compute File Edit View Build	Window Help			
New_Source Open_Source Save_Source	P C B R			
My Network Places Open Project Edit Project Close Project	Ctrl+N Ctrl+O			
Recycle Bin Save As	Ctrl+S)E "TKUP86.DEF"			
AVR Studio 5 Blackhawk Control Pa	MOV AL, OOH	t ; load sta ; initial; ; ; ; clear nu ; call dej	uml variable	
			Ln 1 NUM	
🐉 start 🛛 🔄 uxasm - Mic	crosoft Word 🛛 📓 Procedure for UXASM	🔛 UXAsm - a		🐹 🕏 🧐 3:28 PM

9. To compile the program, click on "C" and observe the following window

The State of the S	
	xet
definid.	
R lie and li	
DePonter Sales et Dates La Manager Street Harton (Sales et Dates et Dates Sales);:	

10. If any errors, Fix the errors, click on "OK" and click on "B" to build the program

My Documents Mozilla Firefox Keil_uWision_4 xhOcya6 (1)		
UXAsm - a		
My Compute File Edit View Build Window Help		
My Network Places		
Recycle Bin UXAsm Internet Explorer AVR Studio 5		
F:\led\a.asm :adding symbols F:\led\a.asm :resolving arguments & symbols F:\led\a.asm :resolving abs Farse no:2 completed F:\led\a.asm :creating listing Listing completed		
MOD & SLD completed	Ln 1 NUM	
Code Counter-Strike STARTUP.ASI Cumpu 1.6		
DAEMON Tools Kell uVision4 TKUP26 Lite Procedure for UXASM [Compatibility Mode] - Microsoft Word		
Start		🐹 🕵 🧐 🖉 3:32 PM
		A

ΤΚμΡ

INTRODUCTION:

TKμP is an ideal trainer cum development boards for Microprocessors like Z80, 8032, 8085, 8088 and 8086. All interface is provided through 10 pin polarized Box Headers. TKμP user interface software communicates with the TKμP hardware through PC parallel port LPT1 and provides fast download of hex files. The PC user interface can open multiple windows for memory Dump and List. Multiple dump windows is also useful to study memory move operations and programs. TKμP is made up of three sections:

1. CPU specific daughter board.

2. Base board section: It has following features

Four sockets for memory which can accommodate maximum 4x128KB.


- 8279 key board display controller.
- 8255 IO expander.

 \succ

- 8155 IO expander with timer counter.
- 8251 Asynchronous serial Transmitter and Receiver.
- 3. User interface section: It has following features
 - Hex keypad.
 - 8-Leds indicator.
 - Four multiplexed 7-Segment displays.
 - LCD 16 characters x 2 lines.
 - I2C NVRAM 24C1024.
 - I2C RTC PCF8583.
 - I2C ADC/DAC PCF8591.
 - Serial port interface through MAX232.

Procedure for TKµP

1. Go to start and select TKµP



2. To Test the I/O connection clicks on Test I/O and click on OK

ly Documents	Mozilla Firefox	Kell_uvision_4	shocyas	
My Computer				
Places		Semanticasori:		
Recycle Bin	New Folder (2)	projecti	Dialog TKuP-USB-IO	
	verb set	project 1	Selct USB device	
	AC LESSON	projecti .uvopt	Cancel OK	
Blackhawk ontrol Pa	Addition	project Lov		-
Compo		STARTOS ASI		
	Kell uvisionsi	TKUPOS		
tert start		Computer	Document1 - Microsof	

3. The following window will be displayed and go to window, select tile to avoid the overlap of windows

🙈 TKuP-8086 - TKup8086			
File Edit View ListMem TKu			
	New Window Cascade		
	Arrange Icons		
Dump_1	1 Dump_1		
At 📰 ListMem	1 Dump_1 ✓ 2 ListMem		
Addr Date			
000001 00			
000002 00			
0 00003 00			
000005 00			
0 00007 00			
0 00008 00			
00 A0000 00			
0 00008 00			
00 0000 00			
		-1	
Arrange windows as non-overlapp	ing tiles		NUM
📑 start 📄 📑 My Co		A TKuP-8086 - TKup8086	📂 🥩 🧐 2022 PM

4 .To clear the garbage data from dump window, go to Listmem and select fillmem

																							-
r	Date				Mns	∍mor	die:																 -
00	00				11110	11101	110																
01	00				_																		_
02	00																						
03	00																						
05	00																						
06	80																						
07	00																						
08	00																						
09	00												240,535,950										
OA	00										Fatt 1	Mem	эгу					? 🔼					
OB	00																						
OC	80									_				100		-							
OE	00									_		Start	Addr	11			Eill						
cite.												End.		1			Cancel						
					_	_						End .	Addr	-				_					 _
r dump												Fill D	ata										6
				04	-	06	-	-	-								Break	1		F			 _
	00 01								09	UA		10				-	break	_	1.1	E.			1
10	00 00		00	00	00		00	00	00	00	00	00	00	00	00								-
20	00 00		00	00	00	00	00	00	00	00	00	00	00		00								
30	00 00	0 0 0	00	00	00		00		00	00	00	00	οō	00	00								
40	00 00		00	00	00	00	00		00	00	00	00	00		00								
50	00 00		00	00	00	00	00		00	00	00	00	00	00	00								
60	00 00	00	00	00	00	00	00	00	00	00	00	00	00		00								
20	88 88	3 88	88	88	88	88	88	88	88	88	88	88	88		88				1000	88.9			
90			00		00		00						00		00	• • • • •			• •				
20	00 00		80	80	80		00		88	88	00	88	80	80	00		::::						
BO	00 00	0 00	00	00	00	00	00	00	00	ōō.	ōō	ōō	ōō		00								
CO	00 00		00	00						00	00	00	00		00					21			
DO	00 00		00		00					00	00	00	00		00								
EO	00 00	00	00	00	00	00	00	00	00	00	00	00	00	00	00					-			

5. To clear the data from dump window, enter start and, end address and fill the data with 00

ListMen																							
ddr	Dat	a			Mne	mon	ic.						_						_				
0000	00																						
0001	00																						
0002	00																						
0003	80	5																					
	0.0	<u>.</u>																					
0005	00	<u>}</u>																					
007	86																						
007																							
008	00	2																					
008											E HUL	Aemo						2					
DOB	80											Neime	.ry							4			
808																			_				
OOD	00	5												Contraction of the local division of the loc		- 22			0				
OOE		5										Start	Add	000	0		Eill	1					
TUTE		· · ·								_				111		-2 1	Cano						
												End	Addr		*		Caric	.01					
												Fill D.	ata	00						1			
dr	00 0	1 0	12 03	0.4	05	0.6	07	00	0.0	0.0		-					Brea	ak		EF		 	and a state of the local division in which the
000	00 0				00					DIC.		1								5 E			_
010	00 0	0.0	10 00	00	00	00	00	00	00		00	00	00	00	00	2012-01-01		Logica hards	100				
020	00 0	00 0	0 00		00	00			00	õõ.	ŏŏ	ŏŏ	00	00									
030	00 0	0 0	10 00			00	00	00			00	00		00	00								
040	00 0		0 00	00	00	00	00	00	00	00	00		00	00									
050			00 00		00	00	00	00	ŏŏ	ŏŏ	ŏŏ.												
060	00 0	0 0	0 00	00	00	00	00	00	00	00	00	00	00	00	00			1000		15/15/			
070	00 0	0 0		00	00	00	00	00	00	00	00	00	00	00						0.0			
080	ŏŏ č		io oc		00	ŏŏ	ŏŏ	ŏŏ	ŏŏ		ŏŏ	ŏŏ	ŏŏ	ŏŏ									
090			0 00		00	00			00	ŏŏ	00			00		2000		2000					
000	00 0				00	00	00	00	00	00	00	00	00	00									
OBO			0 00			õõ.			00		00		00						100				
Inc'n			10 00				00		00	00	00		00	00				1913 0 1		15/520			
ODDO	00 0		0 00		00	οõ				ōō.			ōō										
ODEO			io oc																				
		_											_						_				6
elp, press	s F1		y Comp																			 	NUM

6. To load the hex file ,go to "Listmem" and select "HexLoad"

🦧 1KuP-80)86 - IK	up808	36																								- 6	r ×
						nlp																						
	一品町		6	8 K	?																							
🔛 ListMen	m																										_ 🗆	\times
Addr	Dat				Mnc	amor	nic																					-
00000	UU																											
00001	00																											
00003	0.0																											
00004	UU																											
000005	00																											
00007	0.0																											
00000	00								Con											0								
000008	00								He	IX FI	le Lo	au									\sim	1						
00008	0.0																											
UUUUC	00									FIIO N	omo										_							
0000E	00									CILA	DM)T	KUP\T	Kuna	086\8	255_LI	ED\825	S_LE	D.HEX										
																												- 1
Dump_	2										Dro	wse	1		Load	1		6	ncel	10						31	- 10	
and the second se										-	DIO	oose	_	-	Load		-	1	ncer	_								
Addr	00 0		03	00	00	00		00	4	Г								Br	wak	1			 _	 	 			-
00010	00 0							00	<u> </u>		~~	~~	~~		~~													
00020	00 0			nn	nn	nn						nn	nn	nn														
00030			00	00	00	00	00			00	00	00	00		00		• •											
00050	00 0	0 00		00	00	00	00	00	00	00	00	00	00	õõ	00					1.1.1	16							
00060	00 0			nn	nn	0.0	0.0			00	00	00	nn		nn						200							
00070			00	00	00	00	00			00	00	00	00		00					:::								
00030	00 0	0 00	00	00	00	00	00	00	00	00	00	00	00	00	00													
000000	00 0				00	00					00		00		00						-							
000000	00 0												00		00					:::								
00000		0 00		00	00	00	00	00		00			00		00						22							
0.3000	101 0	0 00	1111	IIII	IIII	mi	IIII	IIII	m	m	IIII	ш	m	nn	ini.	1.1.1					38							
													_															-
For Help, press			_			_						_						_						 	 -	1	NUM	
🔧 start		🚽 My (omput	her			1	Brocer	dure f	or TK	In E		-	TKuP-	8086 -	TKup8	086									192 B	 ><:00 	

7. Browse the hex file from the source and click on "Load"

	0B6 IKu /iew ListMe			/indov	y He	dp																					- 19	
🗅 🧀 🖬	I & Pan	1133	6	-	7																							
🔊 ListMor	m																									1	_ (=	51,
Addr	Data				Mne	mon	ic																					
00000	00																											
0002	00																											1
0003	00																											
0005	00																											
0006	00																											
0007	00													_	_							-						
0009	0.0								H		le Lo	ad								6	7							
000A	00																					-						
00000	00									File N	ame																	
OOOD	00									ante				_														
OOOE	00									1	teel .																	
								_															 					_
Dump_										<u> </u>	Bro	wse		-	Load	1		0	ancel							1	- I C	1
ddr	00 01								C	Ť									Break	1								
0000			00		00			00												_								
0020	00 00	пп	nn	nn	nn	nn	nn	nn																				
0030	00 00										00			00														
0050										88				00		11	:::											
0060	00 00								00	00	00	00	00	00														
0070	00 00								00	00	00	00	00	00		• •												
0090	00 00	00	00	00	00	00	00	00	ōō	00	00	ōō.	00	00	00		:::											
OOAO OOBO	00 00										00	00	00	00														
0080											00	00	00	00				:::										
OODO	00 00	00	00	00	00	00	00	00	00	00	00	00	00	00	00													
UUEU	00 00	UU	uu	υu	UU.	υu	UU	UU	υu	υu	uu	υu	uu	υu	00	• •	• • •	•••	• • • •	• • •	• • •							
Help, pres				_	_	_		_	_		_		_	_		_	_	_		_		_					NUM	-
Help, pres		1 page 1	omputi			T	THE R. L.	roced	ture t	-	up f				- 8086 -	10000												-
Jalan		may c	amplati	644 - C			1	10000	aure i	OF TR	of the Free		TOP OF	madP-	0006 -	TRUP	0066									1000	2000	2

8. To view the program on the window, go to "Listmem" and select address

		1										
ListMem	setMem FillMem											
ldr	HexLoad		Mnem	anic	2							
0000	Symbol		THOM									
0001	00											
002	00											
0003	00											
0004	00											
0005	00											
0002	88											
1008	00											
2000	00											
ADDO	00											
DOOB	00											
DOOC	00											
DOOD												
	00											
DOOF	88											
	00											
DOOF	00											(_)(=
Dump_1	00 01 02							OD OE		3456789ABCI	DEF	
Dump_1	00 01 02	00 0	00 0	0 00	00 0	0 000	00 00	00 00	00	3456789ABCI		
000F Dump_1 dr 0000		00 0		0 00	00 0	0 00		00 00	00			
Dump_1 Idr 1000 1010									00 00			
Dump_1 dr 0000 0010 0020												
Dump_1 dr 0000 0010 0020 0030 0040												
Dump_1 dr 1000 1010 1020 1030 1030												[-](C
Dump_1 dr 0000 0010 0020 0030 0040 0050 0060												
Dump_1 dr 0010 0020 0030 0040 0050 0050 0050												
Dump 1 Idr 1000 1010 1020 1030 1040 1050 1050 1060 1060												
Dump 1 dr 10 1010 1020 1030 1040 1040 1040 1050 1050 1050												(=)(=
Dump_1 Idr 1010 1020 1030 1040 1050 1050 1050 1050 1050 1050 105												
Dump_1 ldr 10000 1010 1020 1030 1040 1040 1050 1050 1050 1050 1050 105												
Dump_1 Idr 0000 0000 0000 0000 0000 0000 0000												
Dump_1 ldr 10000 1010 1020 1030 1040 1040 1050 1050 1050 1050 1050 105												

9. Enter the starting address of the program click "OK"

ddr														
	Data			Symb					emon					
FOOD	BCF011 E8290(F		STA	ART						rkptr			
F009	8000	0							ALL		AT8279			
1008	BB0010	-							IOV E					
FOOB	8807								iov i					
TOOD	E81600	•		LP1					ALL					
FO10	8807								IOV Z					
F012	BA4000	0						N	IOV I	×,PZ	48255			
F015	EE							C	UTT I	X.AI				
F016	DA4200	0									0255			
5019	EE							C	UTT I	X,AI	en el composition de la compos			
FOIA	BA4400	0						N	IOV I	$\times P$	28255			
FOID	EE								UTT I					
FOIE											7			
	40							1	NC A	×				
								1	NC A	×				
TOTE	40 8807							1	NC A	×				
Dump_	40 8807							4		× ×	. AT.			-
Dump_	40 8807								NC A	H×1	.AT. DE OF	012345678		
Dump_	40 8807 1 00 01 02	0 00	00	00 C	0 0	0 0	0 00			AX 1	.AT.			
Dump_ ldr 1000	40 8807 1 00 01 02 00 00 00		00				0 00				.AT.			
Dump_ ldr 1000 0010	40 8807		00								АТ. ОЕ ОГ 00 00			- (-
Dump_ ldr 0010 0020	40 8807								B OC		AT.			
Dump_ ldr 0010 0020 0020	40 8807								B 00		AT.			
Dump_ ldr 0010 0020 0030 0030 0040	40 8807								B 00		AT.			
Pump ldr 0010 0020 0030 0040 0040	40 8807										AT.			
Dump ldr 0010 0020 0030 0040 0040 0050 0050	40 8807								B 00		AT.			
Dump Idr 1000 1000 1000 1000 1000 1000 1000	40 8807										AT.			- 0
Dump_ ldr 0010 0020 0040 0040 0050 0060 0060 0060	40 8807 1 00 01 02 00 00 00 00 00 00 00 00 00 00 00 00 00 00										AI.			
Dump ldr 1010 1020 1030 1040 1050 1040 1050 1060 1060 1080 1080	40 8807										AI.			 - 0
Dump ldr 0010 0020 0020 0020 0020 0020 0020 002	40 8807 1 00 01 05 00 00 00 00 00 00 00 00 00 00 00 00 00 00										AT.			
Dump_	40 8807										AT.			- 10

10. To verify the output, change the "SW-PP PROGRAM" switch to execution mode and verify output

EXPERIMENT NO: 6

DIGITAL CLOCK DESIGN USING 8086

AIM: Write an ALP for digital clock design using 8086

TOOLS:

- i. UXASM
- ii. TKUP
- iii. TKUP86 KIT
- iv. FRC CABLE

PROGRAM:

; CONNECT BH4 (PORT A) TO CNLED

#INCLUDE "TKUP86.DEF"

- ;****** INCLUDE EXTERNS NOW
- ;****** START CODING HERE

ORG 0FFFF0H

JMPF 0F000H,0F000H ; the basic reset jump

ORG 0FF000H

START: MOV SP,STKPTR ; load stack pointer

CALL INIT8255 ; initialize 8255

MOV AL,0CH

MOV [0200H], AL

MOV AL, 00H

- NXTHR: MOV CX, 003CH
- NXTMNT: MOV BX,003CH
- NXTSEC: CALL SECDLY

MOV DX,PA8255

MOV AL, 07H

OUT DX,AL

DEC BX

JNE NXTSEC

MPMC Lab Manual

MOV DX,PA8255

MOV AL,38H

OUT DX,AL

DEC CX

JNE NXTMNT

MOV DX, PA8255

MOV AL, 0C0H

OUT DX, AL

MOV AX,[0200H]

DEC AX

MOV [0200H], AX

JNE NXTHR

SECDLY: PUSH AX

PUSH BX

PUSH CX

PUSH DX

MOV CX, 1234H

DLY: NOP

LOOP DLY

NOP

POP DX

POP CX

POP BX

POP AX

RET

;****** initialize 8255

INIT8255

MOV AL,080H MOV DX, CMD8255 OUT DX,AL

MOV AL,00H

MOV DX,PA8255 OUT DX,AL MOV DX,PB8255 OUT DX,AL MOV DX,PC8255 OUT DX,AL RET

RESULT: INPUT:

OUTPUT:

Exercise Questions:

1) Write an assembly language program for the different clock rates to display the clock on the LCD.

Viva Questions:

- 1) What is the use of IN and OUT instructions?
- 2) What is meant by procedure?
- 3) What is meant by PPI?
- 4) What are the modes of 8255?

EXPERIMENT NO: 7

PROGRAM FOR INTERFACING ADC&DAC TO 8086

AIM: Write an ALP for interfacing ADC to 8086

TOOLS:

- i. UXASM
- ii. TKUP
- iii. TKUP86 KIT
- iv. FRC CABLE
- v. ADC KIT

PROGRAM:

- ; CONNECT BH4 (PORT A) TO DAC BH1A
- ; CONNECT BH5 (PORTB) TO DAC BH2B
- ; CONNECT CRO PROBES TO CND1_1 OF DAC

#INCLUDE "TKUP86.DEF"

DATA SEGMENT

PORTA EQU 9000H

PORTC EQU 9004H

CNTLPRT EQU 9006H

MEM DW 2000H

DATA ENDS

CODE SEGMENT

ASSUME CS: CODE, DS: DATA

START: MOV AX, DATA

MOV DS, AX

MOV DX, CNTLPRT

MOV AL, 98H

OUT DX, AL

MOV AL, 01H

OUT DX, AL

MOV AL, 00 OUT DX, AL

MOV DX, PORTC

CHK: IN AL, DX

AND AL, 80H

JZ CHK

MOV DX, PORTA

IN AL, DX

MOV MEM, AL

INT 03H

CODE ENDS

END START

RESULT: INPUT :

OUTPUT :

INTERFACING DAC TO 8086

AIM: Write an ALP for interfacing DAC to 8086

TOOLS:

- i. UXASM
- ii. TKUP
- iii. TKUP86 KIT
- iv. FRC CABLE

PROGRAM:

- ; CONNECT BH4 (PORT A) TO DAC BH1A
- ; CONNECT BH5 (PORTB) TO DAC BH2B
- ; CONNECT CRO PROBES TO CND1_1 OF DAC

#INCLUDE "TKUP86.DEF"

ORG 0FFFF0H

JMPF 0F000H,0F000H

ORG 0FF000H

MOV AL,080H

MOV DX,CMD8255

OUT DX,AL

MOV AL,00H

MOV DX,PA8255

OUT DX,AL

MOV DX, PB8255

OUT DX,AL

MOV DX,PC8255

OUT DX,AL

RPT: MOV AL,00H

MOV AL,0FFH

AGAIN: MOV DX, PA8255

OUT DX, AL

CALL DELAY

CALL DELAY

CALL DELAY

CALL DELAY

CALL DELAY

CALL DELAY

INC AX

JNE AGAIN

JMP RPT

DELAY: MOV CX, OFFOOH

NXT2: MOV BX, 1234H

NXT: NOP

NOP

NOP

NOP

NOP

DEC BX

JNE NXT

RET

RESULT: INPUT :

OUTPUT :

Exercise Questions:

- 1) Write an assembly language program to convert a saw tooth wave into digital.
- 2) Write an assembly language program for the generation of triangular wave

Viva Questions:

- 1) What is the function of INC Instruction?
- 2) What is the function of NOP Instruction?
- 3) What is the size of the ports of 8255?
- 4) What is the function of the control word register of 8255?

OBSERVATION:

EXPERIMENT NO: 8

PARALLEL COMMUNICATION BETWEEN TWO MICROPROCESSORS USING 8255

AIM: Write an ALP for parallel communication between two microprocessors using 8255 **TOOLS:**

- i. UXASM
- ii. TKUP
- iii. TKUP86 KIT
- iv. FRC CABLE

PROGRAM: FOR DATA IN KIT

#INCLUDE "TKUP86.DEF"

ORG 0FFFF0H

JMPF 0F000H,0F000H

ORG 0FF000H

MOV AL,080H

MOV DX,CMD8255

OUT DX,AL

MOV AL,00H

MOV DX, PA8255

OUT DX,AL

MOV DX,PB8255

OUT DX,AL

MOV DX,PC8255

OUT DX,AL

RPT: MOV AL,47H

MOV DX,PA8255

OUT DX,AL

MOV DX,PB8255

OUT DX,AL

MOV DX,PC8255

OUT DX,AL

JMP RPT

PROGRAM: FOR DATA OUT KIT

#INCLUDE "TKUP86.DEF ORG OFFFF0H JMPF 0F000H,0F000H ORG 0FF000H MOV AL,090H MOV DX,CMD8255 OUT DX,AL MOV AL,00H MOV DX, PA8255 OUT DX,AL MOV DX, PB8255 OUT DX,AL MOV DX, PC8255 OUT DX,AL RPT: MOV DX,PA8255 IN AL,DX MOV [0200H],AL MOV DX, PB8255 OUT DX,AL

- MOV DX,PC8255
- OUT DX,AL JMP RPT

RESULT:

Exercise Questions:

1) Write an assembly language program to transfer MRCET string in between two 8255 kits.

Viva Questions:

- 1) What is the function of IN Instruction?
- 2) What is the function of OUT Instruction?
- 3) What is the size of the ports of 8255?
- 4) What is the function of the control word register of 8255?

OBSERVATION:

EXPERIMENT NO: 9

PROGRAM FOR INTERFACING STEPPER TO 8086

(A) ROTATE THE STEPPER MOTOR IN ANTICLOCKWISE DIRECTION

; Connect 8255 Ports A to CNLED

;**** INCLUDE DEFINATION FILES NOW #INCLUDE "TKUP86.DEF"

;****START CODING HERE

ORG ()FFFF0H	
JMPF (0F000H,0F000H ; the b	asic reset jump
ORG ()FF000H	
START MO	V SP,STKPTR	; load stack pointer
	CALL INIT8255	; initialize 8255
LP1	MOV AL,01H	; use num1 for led count value
	MOV DX,PA8255	
	OUT DX,AL	;
	CALL DELAY	; call delay
	MOV AL,02H	; use num1 for led count value
	MOV DX,PA8255	
	OUT DX,AL	
	CALL DELAY	; call delay
	MOV AL,04H	; use num1 for led count value
	MOV DX,PA8255	
	OUT DX,AL	
	CALL DELAY	; call delay
	MOV AL,08H	; use num1 for led count value
	MOV DX,PA8255	
	OUT DX,AL	
	CALL DELAY	; call delay
	JMP START	; restart again
.**** /	*** Delay module	
DELAY	NOP	;
	MOV CX,03500H	; load Delay count = 0x3500
	NOP	;
DLY1	NOP	;
	LOOP DLY1	;
	RET	; end of delay
.**** /	*** initialize 8255	

INIT8255

MOV AL,080H	; make all ports output
MOV DX, CMD8255	
OUT DX,AL	; write to command register
MOV AL,00H	; clear all ports
MOV DX,PA8255	
OUT DX,AL	;
MOV DX,PB8255	
OUT DX,AL	;
MOV DX,PC8255	
OUT DX,AL	;
RET	;

(B)ROTATE THE STEPPER MOTOR IN CLOCKWISE DIRECTION

;***** START CODING HERE

ORG 0FFFF0H JMPF 0F000H,0F000H ; the basic reset jump

	ORG 0FF000H	
START M	OV SP,STKPTR	; load stack pointer
	CALL INIT8255	; initialize 8255
LP1	MOV AL,08H	; use num1 for led count value
	MOV DX,PA8255	
	OUT DX,AL	
	CALL DELAY	; call delay
	MOV AL,04H	; use num1 for led count value
	MOV DX,PA8255	
	OUT DX,AL	
	CALL DELAY	; call delay
	MOV AL,02H	; use num1 for led count value
	MOV DX,PA8255	;
	OUT DX,AL	
	CALL DELAY	; call delay
	MOV AL,01H	; use num1 for led count value
	MOV DX,PA8255	
	OUT DX,AL	
	CALL DELAY	; call delay
	JMP START	; restart again

.****** ' Delay module

DELAY NOP

MOV CX,03500H ; load Delay count = 0x3500 NOP DLY1 NOP LOOP DLY1 RET ; end of delay ·******* initialize 8255 INIT8255 MOV AL,080H ; make all ports output MOV DX, CMD8255 OUT DX,AL ; write to command register MOV AL,00H ; clear all ports MOV DX, PA8255 OUT DX,AL MOV DX, PB8255 OUT DX,AL MOV DX, PC8255 OUT DX,AL RET

RESULT: INPUT:

OUTPUT:

Exercise Questions:

1) Write an assembly language program to rotate a stepper motor for 20 steps in clockwise direction?

Viva Questions:

- 1. Explain the principle of stepper motor.
- 2. How to calculate step angle?
- 3. What are the applications of stepper motor

OBSERVATION:

EXPERIMENT NO: 10

ARITHMETIC, LOGICAL AND BIT MANIPULATION INSTRUCTIONS OF 8051

AIM: Write an ALP for Arithmetic, logical and bit manipulation operations in 8051

TOOLS:

- i. UXASM
- ii. TKUP
- iii. TKUP86 KIT
- iv. FRC CABLE

A) PROGRAM: FOR ARITHMETIC INSTRUCTIONS OF 8051 ;Connect P1 to CNLED1

#INCLUDE "TKUP52.DEF"

ORG 0000H

START: LJMP MAIN

ORG 0150H

- MAIN MOV SP,#50H
 - MOV R0,#20H

MOV R1,#07H

- MOV A,R0
- ADD A,R1
- MOV P1,A
- LCALL DELAY
- MOV A,R0
- SUBB A,R1
- MOV P1,A
- LCALL DELAY
- MOV A,R0
- MOV 0F0H,R1
- MUL AB
- MOV P1,A

LCALL DELAY

MOV P1,0F0H

LCALL DELAY

MOV A,R0

MOV 0F0H,R1

DIV AB

MOV P1,A

LCALL DELAY

MOV P1,0F0H

LCALL DELAY

LJMP MAIN

DELAY NOP

MOV R4,#020H

- DLY3 MOV R3,#0FFH
- DLY2 MOV R2,#0FFH

NOP

- DLY1 NOP
 - NOP

NOP

DJNZ R2, DLY1

DJNZ R3, DLY2

DJNZ R4, DLY3

RET ;

B) PROGRAM: FOR LOGICAL INSTRUCTIONS OF 8051

i) ;Connect P1 to CNLED1

#INCLUDE "TKUP52.DEF"

ORG 0000H

START: LJMP MAIN

ORG 0150H

MAIN MOV SP,#50H

MOV A,#35H

ANL A,#OFH

MOV P1,A

ACALL DLY

MOV A,#04H

ORL A,#30H

MOV P1,A

ACALL DLY

MOV A,#54H

XRL A,#78H

MOV P1,A

ACALL DLY

MOV A,#55H

CPL A

MOV P1,A

ACALL DLY

DLY NOP

NOP

MOV R4,#020H

- DLY3 MOV R3,#0FFH
- DLY2 MOV R2,#0FFH

NOP

DLY1 NOP

NOP

NOP

NOP

DJNZ R2, DLY1

DJNZ R3, DLY2

DJNZ R4, DLY3

RET

ii) ;Connect P1 to CNLED1

#INCLUDE "TKUP52.DEF"

ORG 0000H

START: LJMP MAIN

ORG 0150H

MAIN: MOV SP,#060H

MOV A,#0A5H

MOV P1,A

LCALL SFTDL

RR A

MOV P1,A

LCALL SFTDL

SWAP A

MOV P1,A

LCALL SFTDL

RL A

MOV P1,A

LCALL SFTDL

SETB C

RLC A

MOV P1,A

LCALL SFTDL

RRC A

MOV P1,A

LCALL SFTDL

LJMP MAIN

SFTDL MOV R4,#50H

- DL3 MOV R5,#0FFH
- DL2 MOV R6,#0FFH
- DL1 DJNZ R6,DL1

DJNZ R5,DL2

DJNZ R4, DL3

RET

C) PROGRAM: FOR BIT MANIPULATION INSTRUCTIONS OF 8051 ; Connect P1 to CNLED1

#INCLUDE "TKUP52.DEF"

ORG 0000H

START: LJMP MAIN

ORG 0150H

MAIN MOV SP,#50H

MOV P1,#00H

MOV C,00H

SETB C

MOV P1_7,C

LCALL SFTDL

CLR C

ANL C,00H

MOV P1_7,C

LCALL SFTDL

CPL C

MOV P1_3,C

LCALL SFTDL

ORL C,00H

MOV P1_7,C

LCALL SFTDL

LJMP MAIN

SFTDL MOV R4,#50H

- DL3 MOV R5,#0FFH
- DL2 MOV R6,#0FFH
- DL1 DJNZ R6, DL1

DJNZ R5,DL2

MPMC Lab Manual

R17 Autonomous III B. Tech II Semester

DJNZ R4,DL3

RET

RESULT: INPUT:

OUTPUT:

Exercise Questions:

1) Write an assembly language program for the addition of 012H and 376H in 8051?

- 1) What are the ports of 8051?
- 2) What is the use of DJNZ instruction?
- 3) What are the bit manipulation instructions of 8051?
- 4) What are the flags of 8051?

EXPERIMENT NO: 11

TIMER/COUNTERS IN 8051

AIM: Write an ALP to verify timer/counter operation in 8051

TOOLS: i) UXASM

li) TKUP

- lii) TKUP86 KIT
- IV) FRC CABLE

PROGRAM:

; Connect P1 to CNLED1

#INCLUDE "TKUP52.DEF"

ORG 0000H

- START: LJMP MAIN ORG 0150H
- MAIN: MOV SP,#060H MOV TMOD,#01H
- BACK: MOV TL0,#075H

MOV TH0,#0B8H

MOV P1,#0AAH

LCALL SFTDL

ACALL DELAY

MOV TL0,#00H

MOV TH0,#00H

MOV P1,#055H

ACALL DELAY

LCALL SFTDL

SJMP BACK

ORG 300H

- DELAY: SETB TCON4
- AGAIN: JNB TCON5, AGAIN

MPMC Lab Manual

CLR TCON4 CLR TCON5

RET

SFTDL MOV R4,#10H

- DL3 MOV R5,#0FFH
- DL2 MOV R6,#0FFH
- DL1 DJNZ R6,DL1 DJNZ R5,DL2

DJNZ R4, DL3

RET

RESULT: INPUT:

OUTPUT:

Exercise Questions:

1) Write a assembly language program for counting number of 1's and 0's in 34H?

- 1) What are timer/counter registers in 8051?
- 2) What is the size of timer/Counter?
- 3) When timer overflow occurs?
- 4) What are special functions registers of 8051?

EXPERIMENT NO: 12 INTERRUPT HANDLING IN 8051

AIM: Write an ALP to verify the interrupt handling in 8051

tools i) UXASM

ii)TKUP

iii)TKUP86 KIT

iv)FRC CABLE

PROGRAM:

#INCLUDE "TKUP52.DEF"

ORG 0000H

START: LJMP MAIN

ORG 0150H

- MAIN MOV SP,#50H MOV IE,#85H
- HERE MOV P1,#7EH SJMP HERE ORG 0003H ; INTO ISR MOV P1,#0AAH LCALL DELAY LCALL DELAY LCALL DELAY RETI ORG 0013H ; INT1 ISR MOV P1,#0A5H LCALL DELAY LCALL DELAY RETI DELAY NOP

MOV R4,#020H

- DLY3 MOV R3,#0FFH
- DLY2 MOV R2,#0FFH
- DLY1 NOP
 - NOP DJNZ R2,DLY1 DJNZ R3,DLY2 DJNZ R4,DLY3 RET

RESULT: INPUT:

OUTPUT:

Exercise Questions:

1) Write the program for interrupt handing of 8051 using PORT 0?

- 1) What are the interrupts of 8051?
- 2) What is the Priority among 8051 interrupts?
- 3) What are the interrupt registers of 8051?
- 4) What is the size of the interrupt registers of 8051?

EXPERIMENT NO: 13

UART OPERATION IN 8051

AIM: To observe the UART operation in 8051

TOOLS: i) UXASM

- ii) TKUP
- iii) TKUP86 KIT
- iv) FRC CABLE

PROGRAM:

; CONNECT THE RS232 FROM PC TO TKUP51 KIT

; CONNECT THE Tx PIN OF 8051 TO Rx OF MAX232 AND VICE VERSA

; CONNECT PORT1 TO CNLED

#INCLUDE "TKUP52.DEF"

ORG 0000H

START: LJMP MAIN

ORG 0150H

MAIN: MOV SP,#060H

MOV IE,#85H

MOV TMOD,#20H

MOV TH1,#0FAH

MOV SCON,#50H

SETB TCON6

- RPT: MOV SBUF,#'Y'
- HERE: JNB SCON1,HERE

CLR SCON1

MOV A,#'A'

MOV P1,A

SJMP RPT

RESULT: INPUT:

OUTPUT:

Exercise Questions:

1) Where do we prefer the serial communication & Why?

- 1) What is the full form of UART?
- 2) What is meant by Synchronous and Asynchronous communication?
- 3) What is the serial communication registers in 8051?
- 4) Which data communication method is supported by 8051?

EXPERIMENT NO: 14

INTERFACING LCD TO 8051

AIM: Write an ALP for interfacing LCD to 8051

TOOLS:

I) UXASM

II) TKUP

III) TKUP86 KIT

IV) FRC CABLE

PROGRAM:

;CONNECT BH4 TO CNLCDC

;CONNECT BH6 TO CNLCDD

#INCLUDE "TKUP52.DEF"

ORG 0000H

START: LJMP MAIN

ORG 0150H

MAIN MOV SP,#060H

LCALL INIT8255

LOOP MOV DPTR,#CMDTBL

LCALL INIT_LCD

MOV DPTR,#STRTBL

LP1 MOV A,#0

MOVC A,@A+DPTR

CJNE A,#00,LP2

LCALL DELAY

LCALL DELAY

LCALL DELAY

LJMP MAIN

LP2 LCALL WR_DAT

MPMC Lab Manual

R17 Autonomous III B. Tech II Semester

INC DPTR

LCALL SDELAY

LJMP LP1

;******LCD init module

INIT_LCD

MOV A,#0

MOVC A,@A+DPTR

CJNE A,#00,IL2

RET

IL2 LCALL WR_CMD

INC DPTR

LJMP INIT_LCD

;****** LCD Write CMD module

WR_CMDPUSH DPH

PUSH DPL

MOV DPTR,#PB8255

LCALL WRPORT

LCALL SDELAY

MOV A,#04

MOV DPTR,#PA8255

LCALL WRPORT

LCALL SDELAY

MOV A, #00

MOV DPTR,#PA8255

LCALL WRPORT

LCALL SDELAY

POP DPL

POP DPH

RET

;****** LCD Write Data module

WR_DAT PUSH DPH

MPMC Lab Manual

R17 Autonomous III B. Tech II Semester

PUSH DPL

MOV DPTR,#PB8255

LCALL WRPORT

LCALL SDELAY

MOV A,#05H

MOV DPTR,#PA8255

LCALL WRPORT

LCALL SDELAY

MOV A,#01H

MOV DPTR,#PA8255

LCALL WRPORT

LCALL SDELAY

POP DPL

POP DPH

RET

;*****Write Port WRPORT CLR P1_7 MOVX @DPTR,A SETB P1_7 RET .****** **Read Port** CLR P1_7 RDPORT MOVX A,@DPTR SETB P1_7 RET •******* Delay module SDELAY NOP MOV R0,#0FFH MOV R1,#01H LJMP DLY1

NOP

DELAY NOP

MOV R0,#0FFH

MOV R1,#055H

NOP

DLY1 DJNZ R0, DLY1

MOV R0,#0FFH

DJNZ R1, DLY1

RET

;****** initialize 8255

INIT8255

MOV A,#080H

MOV DPTR,#CMD8255

LCALL WRPORT

RET

ORG 0500H

;****** initialize seven segment table

CMDTBL HEX 38,0E,02,01,00

STRTBL ASCII "HELLO ADM - TKUP"

ENDTBL HEX 00,00

RESULT:

OUTPUT :

INPUT :

Viva Questions:

- 1) What are the special function register of 8051?
- 2) What is the function of accumulator register?
- 3) What is the function of CJNE instruction?
- 4) What is the function of MOVX instruction?

MPMC Lab Manual

EXPERIMENT NO: 15

INTERFACING MATRIX/KEYBOARD TO 8051

AIM: Write an ALP for interfacing Matrix/keyboard to 8051

TOOLS: i) UXASM

ii) TKUP

iii) TKUP86 KIT

iv)FRC CABLE

PROGRAM:

- ;****** 8255_KBD
- ******* INCLUDE DEFINATION FILES NOW
- ; 1. Connect 8255 PA0-7 to CNMUX of L1C peripheral board
- ; 2. Connect 8255 PC0-7 to CNKEY of L1C peripheral board
- ; 3. Connect 8255 PB0-7 to CNSEG of L1C peripheral board
- ; 4. Motor one segment showing 0000->0001->....->000F->0000 (key press)

#INCLUDE "TKUP52.DEF"

ORG 0000H

START: LJMP MAIN

ORG 0150H

MAIN MOV SP,#060H

LCALL INIT8255

MOV DPTR,#NUM1

LCALL CLRMEM

MOV DPTR,#NUM2

LCALL CLRMEM

MOV DPTR,#NUM3

LCALL CLRMEM

NOP

MPMC Lab Manual

R17 Autonomous III B. Tech II Semester

LOOP LCALL SCANKBD

MOV DPTR,#NUM3

MOVX A,@DPTR

MOV DPTR,#SEGTBL

MOVC A,@A+DPTR

MOV DPTR, #PB8255

LCALL WRPORT

MOV A,#070H

MOV DPTR,#PA8255

LCALL WRPORT

LJMP LOOP

- ;****** MATRIX KBD SCAN module
- ;****** Output either E0,D0,B0,70 for Row 1,2,3,4
- ;****** Read PC port ended with 0x0F, expect 0F,0E,0D,0B,07
- SCANKBD MOV A,#00H
- SKLOOP MOV DPTR,#NUM1

MOVX @DPTR,A

MOV DPTR,#KBDTBL

MOVC A,@A+DPTR

CJNE A,#00,SKL1

RET

SKL1 MOV DPTR,#PC8255 LCALL WRPORT

MOV DPTR, #PC8255

LCALL RDPORT

ANL A,#0FH

CJNE A,#0FH,SKL2

MOV DPTR,#NUM1

MOVX A,@DPTR

MPMC Lab Manual

INC A

LJMP SKLOOP

SKL2 LJMP GETKEY

- ;****** GETKEY module
- GETKEY MOV DPTR,#NUM2

MOVX @DPTR,A

MOV DPTR,#RETTBL

MOVC A,@A+DPTR

MOV R0,A

MOV DPTR,#NUM1

MOVX A,@DPTR

MOV DPTR,#ROWTBL

MOVC A,@A+DPTR

ADD A,RO

MOV DPTR,#NUM3

MOVX @DPTR,A

RET

;***** Clear memory location

CLRMEM MOV A,#0

MOVX @DPTR,A

RET

WRPORT CLR P1_7

MOVX @DPTR,A

SETB P1_7

RET

;***** Read Port

RDPORT CLR P1_7

MOVX A,@DPTR

SETB P1_7

RET

;****** Delay module

SDELAY NOP

MOV R0,#0FFH

MOV R1,#01H

LJMP DLY1

NOP

DELAY NOP

	MOV R0,#0FFH	; load lsb of delay=0x34FF
	MOV R1,#055H	; load msb
	NOP	
DLY1	DJNZ RO, DLY1	
	MOV R0,#0FFH	; decrement msb count
	DJNZ R1, DLY1	

MPMC Lab Manual

RET ; end of delay

;****** initialize 8255

INIT8255

MOV A,#081H	; make all ports output
	,

MOV DPTR,#CMD8255 ; write to command register

LCALL WRPORT

RET

ORG 0500H

.****** /	initialize seven segment table	
SEGTBL	HEX	3F,06,5B,4F,66,6D,7D,07,7F,6F,77,7C,39,5E,79,71,00

- KBDTBL HEX E0,D0,B0,70,00
- RETTBLHEX 00,00,00,00,00,00,03,00,00,00,02,00,01,00,00,00
- ROWTBL HEX 00, 04, 08, 0C, 00

RESULT: INPUT:

OUTPUT:

Exercise Question:

1) Write an assembly language program for the display of MRCET string on LCD by using 8051

- 1) What are the special function register of 8051?
- 2) What is the function of accumulator register?
- 3) How many no. of pins available for 8051?
- 4) What is the function of SP register