

FINITE ELEMENT ANALYSIS

COURSE FILE

III B. Tech II Semester

(2017-2018)

Prepared By

Mr. S. SHAILESH BABU

Asst. Prof.

Department of Aeronautical Engineering

**MALLA REDDY COLLEGE OF ENGINEERING &
TECHNOLOGY**

(Autonomous Institution – UGC, Govt. of India)

Affiliated to JNTU, Hyderabad, Approved by AICTE - Accredited by NBA & NAAC – 'A' Grade - ISO 9001:2015
Certified)

Maisammaguda, Dhulapally (Post Via. Kompally), Secunderabad – 500100, Telangana State, India.

MRCET VISION

- ☐ To become a model institution in the fields of Engineering, Technology and Management.
- ☐ To have a perfect synchronization of the ideologies of MRCET with challenging demands of International Pioneering Organizations.

MRCET MISSION

To establish a pedestal for the integral innovation, team spirit, originality and competence in the students, expose them to face the global challenges and become pioneers of Indian vision of modern society.

MRCET QUALITY POLICY.

- ☐ To pursue continual improvement of teaching learning process of Undergraduate and Post Graduate programs in Engineering & Management vigorously.
- ☐ To provide state of art infrastructure and expertise to impart the quality education.

PROGRAM OUTCOMES

(PO's)

Engineering Graduates will be able to:

1. **Engineering knowledge:** Apply the knowledge of mathematics, science, engineering fundamentals, and an engineering specialization to the solution of complex engineering problems.
2. **Problem analysis:** Identify, formulate, review research literature, and analyze complex engineering problems reaching substantiated conclusions using first principles of mathematics, natural sciences, and engineering sciences.
3. **Design / development of solutions:** Design solutions for complex engineering problems and design system components or processes that meet the specified needs with appropriate consideration for the public health and safety, and the cultural, societal, and environmental considerations.
4. **Conduct investigations of complex problems:** Use research-based knowledge and research methods including design of experiments, analysis and interpretation of data, and synthesis of the information to provide valid conclusions.
5. **Modern tool usage:** Create, select, and apply appropriate techniques, resources, and modern engineering and IT tools including prediction and modeling to complex engineering activities with an understanding of the limitations.
6. **The engineer and society:** Apply reasoning informed by the contextual knowledge to assess societal, health, safety, legal and cultural issues and the consequent responsibilities relevant to the professional engineering practice.
7. **Environment and sustainability:** Understand the impact of the professional engineering solutions in societal and environmental contexts, and demonstrate the knowledge of, and need for sustainable development.
8. **Ethics:** Apply ethical principles and commit to professional ethics and responsibilities and norms of the engineering practice.
9. **Individual and team work:** Function effectively as an individual, and as a member or leader in diverse teams, and in multidisciplinary settings.
10. **Communication:** Communicate effectively on complex engineering activities with the engineering community and with society at large, such as, being able to comprehend and write effective reports and design documentation, make effective presentations, and give and receive clear instructions.
11. **Project management and finance:** Demonstrate knowledge and understanding of the engineering and management principles and apply these to one's own work, as a member and leader in a team, to manage projects and in multi disciplinary environments.
12. **Life- long learning:** Recognize the need for, and have the preparation and ability to engage in independent and life-long learning in the broadest context of technological change.

DEPARTMENT OF AERONAUTICAL ENGINEERING

VISION

Department of Aeronautical Engineering aims to be indispensable source in Aeronautical Engineering which has a zeal to provide the value driven platform for the students to acquire knowledge and empower themselves to shoulder higher responsibility in building a strong nation.

MISSION

The primary mission of the department is to promote engineering education and research. To strive consistently to provide quality education, keeping in pace with time and technology. Department passions to integrate the intellectual, spiritual, ethical and social development of the students for shaping them into dynamic engineers.

QUALITY POLICY STATEMENT

Impart up-to-date knowledge to the students in Aeronautical area to make them quality engineers. Make the students experience the applications on quality equipment and tools. Provide systems, resources and training opportunities to achieve continuous improvement. Maintain global standards in education, training and services.

PROGRAM EDUCATIONAL OBJECTIVES – Aeronautical Engineering

1. **PEO1 (PROFESSIONALISM & CITIZENSHIP):** To create and sustain a community of learning in which students acquire knowledge and learn to apply it professionally with due consideration for ethical, ecological and economic issues.
2. **PEO2 (TECHNICAL ACCOMPLISHMENTS):** To provide knowledge based services to satisfy the needs of society and the industry by providing hands on experience in various technologies in core field.
3. **PEO3 (INVENTION, INNOVATION AND CREATIVITY):** To make the students to design, experiment, analyze, and interpret in the core field with the help of other multi disciplinary concepts wherever applicable.
4. **PEO4 (PROFESSIONAL DEVELOPMENT):** To educate the students to disseminate research findings with good soft skills and become a successful entrepreneur.
5. **PEO5 (HUMAN RESOURCE DEVELOPMENT):** To graduate the students in building national capabilities in technology, education and research

PROGRAM SPECIFIC OUTCOMES – Aeronautical Engineering

1. To mould students to become a professional with all necessary skills, personality and sound knowledge in basic and advance technological areas.
2. To promote understanding of concepts and develop ability in design manufacture and maintenance of aircraft, aerospace vehicles and associated equipment and develop application capability of the concepts sciences to engineering design and processes.
3. Understanding the current scenario in the field of aeronautics and acquire ability to apply knowledge of engineering, science and mathematics to design and conduct experiments in the field of Aeronautical Engineering.
4. To develop leadership skills in our students necessary to shape the social, intellectual, business and technical worlds.

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

III Year B. Tech, ANE-II Sem

L T/P/D C

4 0 4

**(R15A2120) FINITE ELEMENT ANALYSIS
(CORE ELECTIVE – IV)****Objectives:**

- It covers the fundamental theoretical approach beginning with a review of differential equations, boundary conditions, integral forms, interpolation, parametric geometry, numerical integration, and matrix algebra.
- Next, engineering applications to field analysis, stress analysis and vibrations are introduced. Time dependent problems are also treated.
- Students are also introduced, by means of selected tutorials, to the commercial finite element system SolidWorks which is similar to one they could be expected to use upon graduation. Graduate students will also be introduced to the more powerful (and difficult to use) Ansys system.

UNIT – I

Introduction to Finite Element Method for solving field problems. Stress and Equilibrium. Strain – Displacement relations. Stress – strain relations. One Dimensional problems : Finite element modeling coordinates and shape functions. Potential Energy approach : Assembly of Global stiffness matrix and load vector. Finite element equations, Treatment of boundary conditions, Quadratic shape functions.

UNIT – II

Analysis of Beams : Element stiffness matrix for two node, two degrees of freedom per node beam element. Finite element modelling of two dimensional stress analysis with constant strain triangles and treatment of boundary conditions.

UNIT – III

Finite element modelling of Axisymmetric solids subjected to Axisymmetric loading with triangular elements. Two dimensional four noded isoparametric elements and numerical integration.

UNIT – IV

Steady state heat transfer analysis : one dimensional analysis of a fin and two dimensional analysis of thin plate. Analysis of a uniform shaft subjected to torsion.

UNIT-V

Dynamic Analysis : Formulation of finite element model, element matrices, evaluation of Eigen values and Eigen vectors for a stepped bar and a beam.

Outcomes:

- Upon completion of the course students should be able to correlate a differential equation and its equivalent integral form.
- Understand parametric interpolation and parametric geometry enforce essential boundary conditions to a matrix system.

TEXT BOOK:

1. Introduction to Finite Elements in Engineering / Chandraputla, Ashok and Belegundu / Prentice – Hall.
2. The Finite Element Methods in Engineering / SS Rao / Pergamon.
3. The Finite Element Method for Engineers – Kenneth H. Huebner, Donald L. Dewhirst, Douglas E. Smith and Ted G. Byrom / John Wiley & sons (ASIA) Pte Ltd.

REFERENCES:

1. An introduction to Finite Element Method / JN Reddy / Me Graw Hill
2. Finite Element Methods/ Alavala/TMH
3. Finite Element Analysis/ C.S.Krishna Murthy

UNIT I

INTRODUCTION: The finite element analysis is a numerical technique. In this method all the complexities of the problems, like varying shape, boundary conditions and loads are maintained as they are but the solutions obtained are approximate. The fast improvements in computer hardware technology and slashing of cost of computers have boosted this method, since the computer is the basic need for the application of this method. A number of popular brand of finite element analysis packages are now available commercially. Some of the popular packages are STAAD-PRO, GT-STRUDEL, NASTRAN, NISA and ANSYS. Using these packages one can analyze several complex structures.

The finite element analysis originated as a method of stress analysis in the design of aircrafts. It started as an extension of matrix method of structural analysis. Today this method is used not only for the analysis in solid mechanics, but even in the analysis of fluid flow, heat transfer, electric and magnetic fields and many others. Civil engineers use this method extensively for the analysis of beams, space frames, plates, shells, folded plates, foundations, rock mechanics problems and seepage analysis of fluid through porous media. Both static and dynamic problems can be handled by finite element analysis. This method is used extensively for the analysis and design of ships, aircrafts, space crafts, electric motors and heat engines.

The **basic unknowns** or the **Field variables** which are encountered in the engineering problems are displacements in solid mechanics, velocities in fluid mechanics, electric and magnetic potentials in electrical engineering and temperatures in heat flow problems. In a continuum, these unknowns are infinite. The finite element procedure reduces such unknowns to a finite number by dividing the solution region into small parts called **elements** and by expressing the unknown field variables in terms of assumed **approximating functions** (Interpolating functions/Shape functions) within each element. The approximating functions are defined in terms of field variables of specified points called **nodes** or **nodal points**. Thus in the finite element analysis the unknowns are the field variables of the nodal points. Once these are found the field variables at any point can be found by using interpolation functions. After selecting elements and nodal unknowns next step in finite element analysis is to assemble **element properties** for each element. For example, in solid mechanics, we have to find the force-displacement i.e. stiffness characteristics of each individual element. Mathematically this relationship is of the form

$$[k]_e \{\delta\}_e = \{F\}_e$$

where $[k]_e$ is element stiffness matrix, $\{\delta\}_e$ is nodal displacement vector of the element and $\{F\}_e$ is nodal force vector. The element of stiffness matrix k_{ij} represent the force in coordinate direction 'i' due to a unit displacement in coordinate direction 'j'. Four methods are available for formulating these element properties

viz. direct approach, variational approach, weighted residual approach and energy balance approach. Any one of these methods can be used for assembling element properties. In solid mechanics variational approach is commonly employed to assemble stiffness matrix and nodal force vector (consistent loads). Element properties are used to assemble global properties/structure properties to get system equations $[k]\{\delta\} = \{F\}$. Then the boundary conditions are imposed. The solution of these simultaneous equations give the nodal unknowns. Using these nodal values additional calculations are made to get the required values e.g. stresses, strains, moments, etc. in solid mechanics problems.

Thus the various steps involved in the finite element analysis are:

- (i) Select suitable field variables and the elements.
- (ii) Discretise the continua.
- (iii) Select interpolation functions.
- (iv) Find the element properties.
- (v) Assemble element properties to get global properties.
- (vi) Impose the boundary conditions.
- (vii) Solve the system equations to get the nodal unknowns.
- (viii) Make the additional calculations to get the required values.

Methods of Engineering Analysis

There are three methods are adopted for analyzing the product

1. Experimental methods

2. Analytical methods

Numerical methods

Experimental methods

In these methods the actual products or their proto type models or atleast their material specimen are tested by using some equipments

Ex: UTM, Rockwell hardness tester

Analytical methods

These methods are theoretically analyzing methods. Only simple and regular shaped products like beams, shafts, plates can be analyzed by these methods

Numerical methods

For the products of complicated sizes and shapes with complicated material properties and boundary conditions getting solution using analytical methods is highly difficult. In such situation the numerical method can be employed

There are three numerical methods

i) Functional approximating methods

ii) **Finite element method**

iii) Finite difference method

Application of FEM

S.No	Area of Study	Analysing problem
1	Civil Engineering structures	Analysis of trusses, folded plates, shell roofs, bridges and prestressed concrete structures
2	Aircraft structures	Analysis of aircraft wings, fins, rockets, space craft and missile structures
3	Mechanical Design	Stress analysis of pressure vessels, pistons, composite materials, Linkages and gears
4	Heat Conduction	Temperature distribution in solids and fluids
5	Hydraulic and water resources engineering	Analysis of potential flows, free surface flows, viscous flows, analysis of hydraulic structures and dams
6	Electrical Machines and electromagnetics	Analysis of synchronous and induction machines eddy current and core losses in electric machines
7	Nuclear Engineering	Analysis of nuclear pressure vessels and containment structures
8	Geomechanics	Stress analysis in soils, dams, layered piles and machine foundations

Advantages and disadvantages of FEM

Advantages

Using FEM we are able to

1. model irregular shaped bodies quite easily
2. handle general load conditions without difficulty


3. model bodies composed of several different materials because the element equations are evaluated individually
4. handle unlimited numbers and kinds of boundary conditions
5. vary the size of the element to make it possible to use small elements
6. alter the finite element model easily and cheaply
7. include dynamic effects

Disadvantages

1. The finite element method is time consuming process
2. FEM cannot produce exact results as those of analytical methods

Equations of Equilibrium for 3D Body

Typical three dimensional element of size $dx \times dy \times dz$. Face $abcd$ may be called as negative face of x and the face $efgh$ as the positive face of x since the x value for face $abcd$ is less than that for the face $efgh$. Similarly the face $aehd$ is negative face of y and $bfgc$ is positive face of y . Negative and positive faces of z are $dhgc$ and $aefb$. The direct stresses σ and shearing stresses τ acting on the negative faces are shown in the Fig. with suitable subscript. It may be noted that the first subscript of shearing stress is the plane and the second subscript is the direction. Thus the τ_{xy} means shearing stress on the plane where x value is constant and y is the direction.



Face	Stress on -ve Face	Stresses on +ve Face
x	σ_x τ_{xy} τ_{xz}	$\sigma_x^+ = \sigma_x + \frac{\partial \sigma_x}{\partial x} dx$ $\tau_{xy}^+ = \tau_{xy} + \frac{\partial \tau_{xy}}{\partial x} dx$ $\tau_{xz}^+ = \tau_{xz} + \frac{\partial \tau_{xz}}{\partial x} dx$
y	σ_y τ_{yx} τ_{yz}	$\sigma_y^+ = \sigma_y + \frac{\partial \sigma_y}{\partial y} dy$ $\tau_{yx}^+ = \tau_{yx} + \frac{\partial \tau_{yx}}{\partial y} dy$ $\tau_{yz}^+ = \tau_{yz} + \frac{\partial \tau_{yz}}{\partial y} dy$
z	σ_z τ_{zx} τ_{zy}	$\sigma_z^+ = \sigma_z + \frac{\partial \sigma_z}{\partial z} dz$ $\tau_{zx}^+ = \tau_{zx} + \frac{\partial \tau_{zx}}{\partial z} dz$ $\tau_{zy}^+ = \tau_{zy} + \frac{\partial \tau_{zy}}{\partial z} dz$

Let the intensity of body forces acting on the element in x, y, z directions be X, Y and Z respectively as shown in Fig. The intensity of body forces are uniform over entire body. Hence the total body force in x, y, z direction on the element shown are given by

- (i) $X dx dy dz$ in x – direction
- (ii) $Y dx dy dz$ in y – direction and
- (iii) $Z dx dy dz$ in z – direction

Equations of Equilibrium

Considering all forces are acting we can write the equilibrium equations for the element

$$\sum F_x = 0$$

$$\sigma_x^+ dy dz - \sigma_x dy dz + \tau_{yx}^+ dx dz - \tau_{yx} dx dz + \tau_{zx}^+ dx dy - \tau_{zx} dx dy + X dx dy dz = 0$$

$$\text{i.e.} \quad \left(\sigma_x + \frac{\partial \sigma_x}{\partial x} dx \right) dy dz - \sigma_x dy dz + \left(\tau_{yx} + \frac{\partial \tau_{yx}}{\partial y} dy \right) dx dz - \tau_{yx} dx dz$$

$$+ \left(\tau_{zx} + \frac{\partial \tau_{zx}}{\partial z} dz \right) dx dy - \tau_{zx} dx dy + X dx dy dz = 0$$

Simplifying and dividing throughout by dx dy dz

$$\frac{\partial \sigma_x}{\partial x} + \frac{\partial \tau_{yx}}{\partial y} + \frac{\partial \tau_{zx}}{\partial z} + X = 0$$

Similarly $\Sigma F_y=0$ and $\Sigma F_z=0$ Equilibrium conditions give

$$\frac{\partial \tau_{xy}}{\partial x} + \frac{\partial \sigma_y}{\partial y} + \frac{\partial \tau_{yz}}{\partial z} + Y = 0$$

$$\frac{\partial \tau_{xz}}{\partial x} + \frac{\partial \tau_{yz}}{\partial y} + \frac{\partial \sigma_z}{\partial z} + Z = 0$$

$$\Sigma M_x=0$$

$$\tau_{yz}^+ dx dz \frac{dy}{\gamma} + \tau_{yz}^- dx dz \frac{dy}{\gamma} - \left[\tau_{zy}^+ dx dz \frac{dy}{\gamma} + \tau_{zy}^- dx dz \frac{dy}{\gamma} \right] = 0$$

$$\text{i.e.} \quad \left(\tau_{yz} + \frac{\partial \tau_{yz}}{\partial y} dy \right) dx dy \frac{dz}{2} + \tau_{yz} dx dy \frac{dz}{2} - \left[\left(\tau_{zy} + \frac{\partial \tau_{zy}}{\partial z} dz \right) dx dy \frac{dz}{2} + \tau_{zy} dx dy \frac{dz}{2} \right] = 0$$

Neglecting small quantity then

$$\tau_{zy} = \tau_{yz}$$

$\Sigma M_y=0$ then we will get

$$\tau_{xz} = \tau_{zx}$$

$\Sigma M_z=0$ then we will get

$$\tau_{xy} = \tau_{yx}$$

$$[\sigma]^T = [\sigma_x \quad \sigma_y \quad \sigma_z \quad \tau_{xy} \quad \tau_{yz} \quad \tau_{xz}]$$

and the equilibrium equations are

$$\frac{\partial \sigma_x}{\partial x} + \frac{\partial \tau_{xy}}{\partial y} + \frac{\partial \tau_{xz}}{\partial z} + X = 0$$

$$\frac{\partial \tau_{xy}}{\partial x} + \frac{\partial \sigma_y}{\partial y} + \frac{\partial \tau_{yz}}{\partial z} + Y = 0$$

$$\frac{\partial \tau_{xz}}{\partial x} + \frac{\partial \tau_{yz}}{\partial y} + \frac{\partial \sigma_z}{\partial z} + Z = 0$$

$$\tau_{xy} = \tau_{yx}, \quad \tau_{yz} = \tau_{zy} \quad \text{and} \quad \tau_{xz} = \tau_{zx}$$

Strain Displacement equations

Taking displacement components in x, y, z directions as u, v, and w respectively, the relations among components of strain and the components of displacement are

$$\epsilon_x = \frac{\partial u}{\partial x} + \frac{1}{2} \left[\left(\frac{\partial u}{\partial x} \right)^2 + \left(\frac{\partial v}{\partial x} \right)^2 + \left(\frac{\partial w}{\partial x} \right)^2 \right]$$

$$\epsilon_y = \frac{\partial v}{\partial y} + \frac{1}{2} \left[\left(\frac{\partial u}{\partial y} \right)^2 + \left(\frac{\partial v}{\partial y} \right)^2 + \left(\frac{\partial w}{\partial y} \right)^2 \right]$$

$$\epsilon_z = \frac{\partial w}{\partial z} + \frac{1}{2} \left[\left(\frac{\partial u}{\partial z} \right)^2 + \left(\frac{\partial v}{\partial z} \right)^2 + \left(\frac{\partial w}{\partial z} \right)^2 \right]$$

$$\gamma_{xy} = \frac{\partial v}{\partial x} + \frac{\partial u}{\partial y} + \frac{\partial u}{\partial x} \cdot \frac{\partial u}{\partial y} + \frac{\partial v}{\partial x} \cdot \frac{\partial v}{\partial y} + \frac{\partial w}{\partial x} \cdot \frac{\partial w}{\partial y}$$

$$\gamma_{yz} = \frac{\partial w}{\partial y} + \frac{\partial v}{\partial z} + \frac{\partial u}{\partial y} \cdot \frac{\partial u}{\partial z} + \frac{\partial v}{\partial y} \cdot \frac{\partial v}{\partial z} + \frac{\partial w}{\partial y} \cdot \frac{\partial w}{\partial z}$$

$$\gamma_{xz} = \frac{\partial u}{\partial z} + \frac{\partial w}{\partial x} + \frac{\partial u}{\partial x} \cdot \frac{\partial u}{\partial z} + \frac{\partial v}{\partial x} \cdot \frac{\partial v}{\partial z} + \frac{\partial w}{\partial x} \cdot \frac{\partial w}{\partial z}$$

strains are expressed up to the accuracy of second order (quadratic) changes in displacements. These equations may be simplified to the first (linear) order accuracy only by dropping the second order changes terms. Then linear strain – displacement relation is given by:

$$\epsilon_x = \frac{\partial u}{\partial x} \quad \gamma_{xy} = \frac{\partial u}{\partial x} + \frac{\partial v}{\partial y}$$

$$\epsilon_y = \frac{\partial v}{\partial y} \quad \gamma_{yz} = \frac{\partial w}{\partial y} + \frac{\partial v}{\partial z}$$

$$\epsilon_z = \frac{\partial w}{\partial z} \quad \gamma_{xz} = \frac{\partial w}{\partial x} + \frac{\partial u}{\partial z}$$

LINEAR CONSTITUTIVE EQUATIONS

The constitutive law expresses the relationship among stresses and strains. In theory of elasticity, usually it is considered as linear. In one dimensional stress analysis, the linear constitutive law is stress is proportional to strain and the constant of proportionality is called Young's modulus. It is very well known as Hooke's law.

The similar relation is expressed among the six components of stresses and strains and is called '**Generalized Hooke's Law**'. This may be stated as:

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{xz} \end{Bmatrix} = \begin{Bmatrix} D_{11} & D_{12} & D_{13} & D_{14} & D_{15} & D_{16} \\ D_{21} & D_{22} & D_{23} & D_{24} & D_{25} & D_{26} \\ D_{31} & D_{32} & D_{33} & D_{34} & D_{35} & D_{36} \\ D_{41} & D_{42} & D_{43} & D_{44} & D_{45} & D_{46} \\ D_{51} & D_{52} & D_{53} & D_{54} & D_{55} & D_{56} \\ D_{61} & D_{62} & D_{63} & D_{64} & D_{65} & D_{66} \end{Bmatrix} \begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \epsilon_z \\ \gamma_{xy} \\ \gamma_{yz} \\ \gamma_{xz} \end{Bmatrix}$$

$$\{\sigma\} = [D] \{\epsilon\},$$

where D is 6×6 matrix of constants of elasticity to be determined by experimental investigations for each material. As D is symmetric matrix [$D_{ij} = D_{ji}$], there are 21 material properties for linear elastic

Anisotropic Materials. Certain materials exhibit symmetry with respect to planes within the body. Such materials are called **Orthotropic materials**. Hence for orthotropic materials, the number of material constants reduce to 9 as shown below:

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{xz} \end{Bmatrix} = \begin{Bmatrix} D_{11} & D_{12} & D_{13} & 0 & 0 & 0 \\ & D_{22} & D_{23} & 0 & 0 & 0 \\ & & D_{33} & 0 & 0 & 0 \\ & Sym & & D_{44} & 0 & 0 \\ & & & & D_{55} & 0 \\ & & & & & D_{66} \end{Bmatrix} \begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \epsilon_z \\ \gamma_{xy} \\ \gamma_{yz} \\ \gamma_{xz} \end{Bmatrix}$$

Using the Young's Moduli and Poisson's ratio terms the above relation may be expressed as:

$$\begin{aligned} \epsilon_x &= \frac{\sigma_x}{E_x} - \mu_{yx} \frac{\sigma_y}{E_y} - \mu_{zx} \frac{\sigma_z}{E_z} \\ \epsilon_y &= -\mu_{xy} \frac{\sigma_x}{E_x} + \frac{\sigma_y}{E_y} - \mu_{zy} \frac{\sigma_z}{E_z} \\ \epsilon_z &= -\mu_{xz} \frac{\sigma_x}{E_x} - \mu_{yz} \frac{\sigma_y}{E_y} + \frac{\sigma_z}{E_z} \\ \gamma_{xy} &= \frac{\tau_{xy}}{G_{xy}}, \quad \gamma_{yz} = \frac{\tau_{yz}}{G_{yz}}, \quad \gamma_{zx} = \frac{\tau_{zx}}{G_{zx}} \end{aligned}$$

Note that there are 12 material properties in above equations However only nine of these are independent because the following relations exist

$$\frac{E_x}{\mu_{xy}} = \frac{E_y}{\mu_{yx}}, \quad \frac{E_y}{\mu_{yz}} = \frac{E_z}{\mu_{zy}}, \quad \frac{E_z}{\mu_{zx}} = \frac{E_x}{\mu_{xz}}$$

For **Isotropic Materials** the above set of equations are further simplified. An isotropic material is the one that has same material property in all directions. In other word for isotropic materials,

$$E_x = E_y = E_z \text{ say } E \text{ and} \\ \mu_{xy} = \mu_{yx} = \mu_{yz} = \mu_{zy} = \mu_{xz} = \mu_{zx} \text{ say } \mu$$

Hence for a three dimensional problem, the strain stress relation for isotropic material is,


$$\begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \epsilon_z \\ \gamma_{xy} \\ \gamma_{yz} \\ \gamma_{xz} \end{Bmatrix} = \begin{bmatrix} \frac{1}{E} & -\frac{\mu}{E} & -\frac{\mu}{E} & 0 & 0 & 0 \\ -\frac{\mu}{E} & \frac{1}{E} & -\frac{\mu}{E} & 0 & 0 & 0 \\ -\frac{\mu}{E} & -\frac{\mu}{E} & \frac{1}{E} & 0 & 0 & 0 \\ 0 & 0 & 0 & \frac{1-\mu}{2} & 0 & 0 \\ 0 & 0 & 0 & 0 & \frac{1-\mu}{2} & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{1-\mu}{2} \end{bmatrix} \begin{Bmatrix} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{xz} \end{Bmatrix}$$

Since $G = \frac{E}{2(1-\mu)}$ and stress – strain relation is

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{xz} \end{Bmatrix} = \frac{E}{(1+\mu)(1-2\mu)} \begin{bmatrix} 1-\mu & \mu & \mu & 0 & 0 & 0 \\ \mu & 1-\mu & \mu & 0 & 0 & 0 \\ \mu & \mu & 1-\mu & 0 & 0 & 0 \\ 0 & 0 & 0 & \frac{1-2\mu}{2} & 0 & 0 \\ 0 & 0 & 0 & 0 & \frac{1-2\mu}{2} & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{1-2\mu}{2} \end{bmatrix} \begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \epsilon_z \\ \gamma_{xy} \\ \gamma_{yz} \\ \gamma_{xz} \end{Bmatrix}.$$

PLANE STRESS PROBLEM

The thin plates subject to forces in their plane only, fall under this category of the problems. Fig. shows a typical plane stress problem. In this, there is



no force in the z-direction and no variation of any forces in z-direction. Hence

$$\sigma_z = \tau_{xz} = \tau_{yz} = 0$$

The conditions $\tau_{xz} = \tau_{yz} = 0$ give $\gamma_{xz} = \gamma_{yz} = 0$ and the condition $\sigma_z = 0$ gives,

$$\sigma_z = \mu \varepsilon_x + \mu \varepsilon_y + (1 - \mu) \varepsilon_z = 0$$

i.e.


$$\varepsilon_z = -\frac{\mu}{1 - \mu} (\varepsilon_x + \varepsilon_y)$$

If this is substituted in equation 2.13 the constitutive law reduces to

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \tau_{xy} \end{Bmatrix} = \frac{E}{1 - \mu^2} \begin{bmatrix} 1 & \mu & 0 \\ \mu & 1 & 0 \\ 0 & 0 & \frac{1 - \mu}{2} \end{bmatrix} \begin{Bmatrix} \varepsilon_x \\ \varepsilon_y \\ \gamma_{xy} \end{Bmatrix}$$

PLANE STRAIN PROBLEM

A long body subject to significant lateral forces but very little longitudinal forces falls under this category of problems. Examples of such problems are pipes, long strip footings, retaining walls, gravity dams, tunnels, etc. In these problems, except for a small distance at the ends, state of stress is represented by any small longitudinal strip. The displacement in longitudinal direction (z-direction) is zero in typical strip. Hence the strain components,






Fig. 2.7 (contd)

$$\varepsilon_z = \gamma_{xz} = \gamma_{yz} = 0$$

$\gamma_{xz} = \gamma_{yz} = 0$ means τ_{xz} and τ_{yz} are zero.

$\varepsilon_z = 0$ means

$$\varepsilon_z = \frac{\sigma_z}{E} - \mu \frac{(\sigma_x + \sigma_y)}{E} = 0$$

i.e.

$$\sigma_z = \mu(\sigma_x + \sigma_y)$$

Hence equation 2.13 when applied to plane strains problems reduces to

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \tau_{xy} \end{Bmatrix} = \frac{E}{(1+\mu)(1-2\mu)} \begin{pmatrix} 1-\mu & \mu & 0 \\ \mu & 1-\mu & 0 \\ 0 & 0 & \frac{1-2\mu}{2} \end{pmatrix} \begin{Bmatrix} \varepsilon_x \\ \varepsilon_y \\ \gamma_{xy} \end{Bmatrix}$$

Functional Approximation Methods

The nature of the problems for which the solutions to be found out are

- i) Equilibrium problems
- ii) Eigen value problems
- iii) propagation problems

The functional approximation methods for solving the above types of problems are classified into major types

- i) Variational methods
- ii) Weighted residual methods

Rayleigh-Ritz method is good example for variational method

Weighted residual method

- Point collocation method
- sub domain collocation method
- Least square method
- Galerkin's method

Rayleigh-Ritz Method

Rayleigh -Ritz method is a typical variational method in which principle of integral approach is adopted for solving the complex structural problems

i) Minimum potential energy method

ii) Integral approach method

Minimum potential energy method

In this method the total potential energy ' Π ' is considered as the function of generalized coordinated which are exactly equal to the number of degrees of freedom

$$\Pi = U - W$$

U=Internal energy

W=work done by the external force

Polynomial series

$$y(x) = a_1 + a_2x + a_3x^2 + \text{-----}$$

a_1, a_2, a_3 ----- are Ritz parameters

Integral approach method

Differential equation is

$$D \frac{d^2y}{dx^2} + Q = 0$$

$$I \int_0^l [D/2 (dy/dx)^2 - Qy] dx$$

ONE DIMENSIONAL PROBLEMS

Bar and beam elements are considered as One Dimensional elements. These elements are often used to model trusses and frame structures

Types of Loading

i) **Body force (f)**

It is a distributed force acting on every elemental volume of the body. Unit is Force / Unit volume. Ex: Self weight due to gravity.

ii) **Traction (T)**


It is a distributed force acting on the surface of the body. Unit is Force / Unit area. But for one dimensional problem, unit is Force / Unit length. Ex: Frictional resistance, viscous drag and Surface shear.

iii) **Point load (P)**

It is a force acting at a particular point which causes displacement.

Finite Element Modeling

It has two processes. (1) Discretization of structure (2) Numbering of nodes.




CO – ORDINATES

(A) Global co – ordinates, (B) Local co – ordinates and (C) Natural co – ordinates.


- Equation of Stiffness Matrix for One dimensional bar element

$$[K] = \frac{AE}{l} \begin{bmatrix} 1 & -1 \\ -1 & 1 \end{bmatrix}$$

For a stepped bar loaded as shown in figure. Determine a) Nodal displacements
b) support Reactions c) Element Stress



Solution



Element 1	Element 2	Element 3
$A_1 = 15 \text{ cm}^2$	$A_2 = 15 \text{ cm}^2$	$A_3 = 24 \text{ cm}^2$
$E_1 = 20 \times 10^6 \text{ N/cm}^2$	$E_2 = 20 \times 10^6 \text{ N/cm}^2$	$E_3 = 20 \times 10^6 \text{ N/cm}^2$
$L_1 = 75 \text{ cm}$	$L_2 = 75 \text{ cm}$	$L_3 = 60 \text{ cm}$
$\alpha_1 = 11 \times 10^{-6} \text{ cm/cm}^0\text{C}$	$\alpha_2 = 11 \times 10^{-6} \text{ cm/cm}^0\text{C}$	$\alpha_3 = 11 \times 10^{-6} \text{ cm/cm}^0\text{C}$
$\Delta T = 10^0\text{C}$	$\Delta T = 10^0\text{C}$	$\Delta T = 10^0\text{C}$

$$F_{0(1)} = A_1 E_1 \alpha_1 \Delta T = 33000 \text{ N}$$

$$F_{0(2)} = A_2 E_2 \alpha_2 \Delta T = 33000 \text{ N}$$

$$F_{0(3)} = A_3 E_3 \alpha_3 \Delta T = 52800 \text{ N}$$

The Nodal Forces are

$$F_1 = R_1 + P - F_{0(1)} = R_1 - 33000$$

$$F_2 = P_2 + F_{0(1)} - F_{0(2)} = 10000$$

$$F_3 = P_3 + F_{0(2)} - F_{0(3)} = -39800$$

$$F_4 = R_4 + P_3 + F_{0(2)} - F_{0(3)} = R_4 + 52800$$

The stiffness values are

$$k_1 = A_1 E_1 / L_1 = 4 \times 10^6 \text{ N/cm}$$

$$k_2 = A_2 E_2 / L_2 = 4 \times 10^6 \text{ N/cm}$$

$$k_3 = A_3 E_3 / L_3 = 8 \times 10^6 \text{ N/cm}$$

the nodal conditions are $u_1 = 0$ and $u_4 = 0$

$$10^6 \begin{bmatrix} 4 & -4 & 0 & 0 \\ -4 & 8 & -4 & 0 \\ 0 & -4 & 12 & -8 \\ 0 & 0 & -8 & 8 \end{bmatrix} \begin{Bmatrix} 0 \\ u_2 \\ u_3 \\ 0 \end{Bmatrix} = \begin{Bmatrix} R_1 - 33,000 \\ 10,000 \\ -39,800 \\ R_4 + 52,800 \end{Bmatrix}$$

solve the above matrix then you will get the values of u_2 and u_3 as $-3.48 \times 10^{-3} \text{ cm}$ and as $-0.49 \times 10^{-1} \text{ cm}$

$$R_1 = 34960 \text{ N}$$

$$R_4 = -24960 \text{ N}$$

$$\sigma_{r(1)} = \sigma_{(1)} - \sigma_{0(1)} = -2330.7 \text{ N/cm}^2$$

$$\sigma_{r(2)} = \sigma_{(2)} - \sigma_{0(2)} = -2997.3 \text{ N/cm}^2$$

$$\sigma_{r(3)} = \sigma_{(3)} - \sigma_{0(3)} = -1010 \text{ N/cm}^2$$

CHAPTER – II

One could obtain the global stiffness matrix of a continuous beam from assembling member stiffness matrix of individual beam elements. Towards this end, we break the given beam into a number of beam elements. The stiffness matrix of each individual beam element can be written very easily. For example, consider a continuous beam $ABCD$ as shown in Fig. 1a. The given continuous beam is divided into three beam elements as shown in Fig. 1b. It is noticed that, in this case, nodes are located at the supports. Thus each span is treated as an individual beam. However sometimes it is required to consider a node between support points. This is done whenever the cross sectional area changes suddenly or if it is required to calculate vertical or rotational displacements at an intermediate point. Such a division is shown in Fig. 1c. If the axial deformations are neglected then each node of the beam will have two degrees of freedom: a vertical displacement (corresponding to shear) and a rotation (corresponding to bending moment). In Fig. 1b, numbers enclosed in a circle represents beam numbers. The beam $ABCD$ is divided into three beam members. Hence, there are four nodes and eight degrees of freedom. The possible displacement degrees of freedom of the beam are also shown in the figure. Let us use lower numbers to denote unknown degrees of freedom (unconstrained degrees of freedom) and higher numbers to denote known (constrained) degrees of freedom. Such a method of identification is adopted in this course for the ease of imposing boundary conditions directly on the structure stiffness matrix. However, one could number sequentially as shown in Fig. 1d. This is preferred while solving the problem on a computer.




Fig 27.1a Continuous beam




Fig. 27.1b Member and node numbering




Fig. 27.1c Member and node numbering





Fig 27.1d Member and node numbering

In the above figures, single headed arrows are used to indicate translational and double headed arrows are used to indicate rotational degrees of freedom.



Beam Stiffness Matrix:


Fig. 2 shows a prismatic beam of a constant cross section that is fully restrained at ends in local orthogonal coordinate system $x' y' z'$. The beam ends are denoted by nodes j and k . The x' axis coincides with the centroidal axis of the member with the positive sense being defined from j to k . Let L be the length of the member, A area of cross section of the member and I_{zz} is the moment of inertia about z' axis.




Two degrees of freedom (one translation and one rotation) are considered at each end of the member. Hence, there are four possible degrees of freedom for this member and hence the resulting stiffness matrix is of the order 4×4 . In this method counterclockwise moments and counterclockwise rotations are taken as positive. The positive sense of the translation and rotation are also shown in the figure. Displacements are considered as positive in the direction of the co-ordinate axis. The elements of the stiffness matrix indicate the forces exerted on the the member by the restraints at the ends of the member when unit displacements are imposed at each end of the member. Let us calculate the forces developed in the above beam member when unit displacement is imposed along each degree of freedom holding all other displacements to zero. Now impose a unit displacement along y' axis at j end of the member while holding all other displacements to zero as shown in Fig.a. This displacement causes both shear and moment in the beam. The restraint actions are also shown in the figure. By definition they are elements of the member stiffness matrix. In particular they form the first column of element stiffness matrix.

In Fig.b, the unit rotation in the positive sense is imposed at j end of the beam while holding all other displacements to zero. The restraint actions are shown in the figure. The restraint actions at ends are calculated referring to tables given in lesson ...





(c) Unit displacement along y' at end k



(d) Unit rotation about z' at end k

In Fig. 3c, unit displacement along y' axis at end k is imposed and corresponding restraint actions are calculated. Similarly in Fig.d, unit rotation about z' axis at end k is imposed and corresponding stiffness coefficients are calculated. Hence the member stiffness matrix for the beam member is


$$[k] = \begin{bmatrix} 1 & 2 & 3 & 4 \\ \left[\begin{array}{cc|cc} \frac{12EI_z}{L^3} & \frac{6EI_z}{L^2} & -\frac{12EI_z}{L^3} & \frac{6EI_z}{L^2} \\ \frac{6EI_z}{L^2} & \frac{4EI_z}{L} & -\frac{6EI_z}{L^2} & \frac{2EI_z}{L} \end{array} \right] & \begin{array}{c} 1 \\ 2 \end{array} \\ -\frac{L^2}{12EI_z} & -\frac{L}{6EI_z} & \frac{L^2}{12EI_z} & -\frac{L}{6EI_z} & \begin{array}{c} 3 \\ 4 \end{array} \\ \left[\begin{array}{cc|cc} \frac{L^3}{6EI_z} & \frac{L^2}{2EI_z} & -\frac{L^3}{6EI_z} & \frac{L^2}{2EI_z} \\ \frac{L^2}{2EI_z} & \frac{L}{EI_z} & -\frac{L^2}{2EI_z} & \frac{L}{EI_z} \end{array} \right] & \begin{array}{c} 1 \\ 2 \end{array} \end{bmatrix}$$

The stiffness matrix is symmetrical. The stiffness matrix is partitioned to separate the actions associated with two ends of the member. For continuous beam problem, if the supports are unyielding, then only rotational degree of freedom shown in Fig. is possible. In such a case the first and the third rows and columns will be deleted. The reduced stiffness matrix will be,

$$[k] = \left[\begin{array}{c|c} \frac{4EI_z}{L} & \frac{2EI_z}{L} \\ \hline \frac{2EI_z}{L} & \frac{4EI_z}{L} \end{array} \right]$$



Instead of imposing unit displacement along y' at j end of the member in Fig.a, apply a displacement u'_1 along y' at j end of the member as shown in Fig. a, holding all other displacements to zero. Let the restraining forces developed be denoted by q_{11} , q_{21} , q_{31} and q_{41} .



The forces are equal to,

$$q_{11} = k_{11}u'_1; \quad q_{21} = k_{21}u'_1; \quad q_{31} = k_{31}u'_1; \quad q_{41} = k_{41}u'_1$$

Now, give displacements u'_1 , u'_2 , u'_3 and u'_4 simultaneously along displacement degrees of freedom 1, 2, 3 and 4 respectively. Let the restraining forces developed at member ends be q_1 , q_2 , q_3 and q_4 respectively as shown in Fig. b along respective degrees of freedom. Then by the principle of superposition, the force displacement relationship can be written as,


$$\begin{bmatrix} q_1 \\ q_2 \\ q_3 \\ q_4 \end{bmatrix} = \begin{bmatrix} \frac{12EI_z}{L^3} & \frac{6EI_z}{L^2} & -\frac{12EI_z}{L^3} & \frac{6EI_z}{L^2} \\ \frac{6EI_z}{L^2} & \frac{4EI_z}{L} & -\frac{6EI_z}{L^2} & \frac{2EI_z}{L} \\ -\frac{12EI_z}{L^3} & -\frac{6EI_z}{L^2} & \frac{12EI_z}{L^3} & -\frac{6EI_z}{L^2} \\ \frac{6EI_z}{L^2} & \frac{2EI_z}{L} & -\frac{6EI_z}{L^2} & \frac{4EI_z}{L} \end{bmatrix} \begin{bmatrix} u'_1 \\ u'_2 \\ u'_3 \\ u'_4 \end{bmatrix}$$

This may also be written in compact form as,

$$\{q\} = [k] \{u'\}$$


Beam (global) Stiffness Matrix:

The formation of structure (beam) stiffness matrix from its member stiffness matrices is explained with help of two span continuous beams shown in Fig. a. Note that no loading is shown on the beam. The orthogonal co-



ordinate system xyz denotes the global co-ordinate system.

For the case of continuous beam, the x - and x' - axes are collinear and other axes (y and y' , z and z') are parallel to each other. Hence it is not required to transform member stiffness matrix from local co-ordinate system to global coordinate system as done in the case of trusses. For obtaining the global stiffness matrix, first assume that all joints are restrained. The node and member numbering for the possible degrees of freedom are



shown in Fig b. The continuous beam is divided into two beam members. For this member there are six possible degrees of freedom. Also in the figure, each beam member with its displacement degrees of freedom (in local co ordinate system) is also shown. Since the continuous beam has the same moment of inertia and span, the member stiffness matrix of element 1 and 2 are the same. They are,

$$\begin{array}{l}
 \text{Global d.o.f} \quad 1 \quad \quad 2 \quad \quad 3 \quad \quad 4 \\
 \text{Local d.o.f} \quad 1 \quad \quad 2 \quad \quad 3 \quad \quad 4
 \end{array}$$

$$[k'] = \begin{bmatrix} k'_{11} & k'_{12} & k'_{13} & k'_{14} \\ k'_{21} & k'_{22} & k'_{23} & k'_{24} \\ k'_{31} & k'_{32} & k'_{33} & k'_{34} \\ k'_{41} & k'_{42} & k'_{43} & k'_{44} \end{bmatrix} \begin{array}{l} 1 \quad 1 \\ 2 \quad 2 \\ 3 \quad 3 \\ 4 \quad 4 \end{array}$$

$$\begin{array}{l}
 \text{Global d.o.f} \quad 3 \quad \quad 4 \quad \quad 5 \quad \quad 6 \\
 \text{Local d.o.f} \quad 1 \quad \quad 2 \quad \quad 3 \quad \quad 4
 \end{array}$$

$$[k^2] = \begin{bmatrix} k^2_{11} & k^2_{12} & k^2_{13} & k^2_{14} \\ k^2_{21} & k^2_{22} & k^2_{23} & k^2_{24} \\ k^2_{31} & k^2_{32} & k^2_{33} & k^2_{34} \\ k^2_{41} & k^2_{42} & k^2_{43} & k^2_{44} \end{bmatrix} \begin{array}{l} 1 \quad 3 \\ 2 \quad 4 \\ 3 \quad 5 \\ 4 \quad 6 \end{array}$$


The local and the global degrees of freedom are also indicated on the top and side of the element stiffness matrix. This will help us to place the elements of the element stiffness matrix at the appropriate locations of the global stiffness matrix. The continuous beam has six degrees of freedom and hence the stiffness matrix is of the order 6. Let [K] denotes the continuous beam stiffness matrix of order 6X6. From Fig., [K] may be written as,

$$\begin{array}{c}
 \text{Member } AB \text{ (1)} \\
 [K] = \left[\begin{array}{cc|cc|cc}
 k_{11}^1 & k_{12}^1 & k_{13}^1 & k_{14}^1 & 0 & 0 \\
 k_{21}^1 & k_{22}^1 & k_{23}^1 & k_{24}^1 & 0 & 0 \\
 \hline
 k_{31}^1 & k_{32}^1 & k_{33}^1 + k_{11}^2 & k_{34}^1 + k_{12}^2 & k_{13}^2 & k_{14}^2 \\
 k_{41}^1 & k_{42}^1 & k_{43}^1 + k_{21}^2 & k_{44}^1 + k_{22}^2 & k_{23}^2 & k_{24}^2 \\
 \hline
 0 & 0 & k_{31}^2 & k_{32}^2 & k_{33}^2 & k_{34}^2 \\
 0 & 0 & k_{41}^2 & k_{42}^2 & k_{43}^2 & k_{44}^2
 \end{array} \right] \\
 \text{Member } BC \text{ (2)}
 \end{array}$$


The 4X4 upper left hand section receives contribution from member 1 (AB) and 4X4 lower right hand section of global stiffness matrix receives contribution from member 2. The element of the global stiffness matrix corresponding to global degrees of freedom 3 and 4 receives element from both members 1 and 2.

FORMATION OF LOAD VECTOR:


Consider a continuous beam *ABC* as shown in Fig.




We have two types of load: member loads and joint loads. Joint loads could be handled very easily as done in case of trusses. Note that stiffness matrix of each member was developed for end loading only. Thus it is required to replace the member loads by equivalent joint loads. The equivalent joint loads must be evaluated such that the displacements produced by them in the beam should be the same as the displacements produced by the actual loading on the beam. This is evaluated by invoking the method of superposition.



(a) Actual beam with loading



(b) Reaction in the restrained beam



(c) Equivalent joint loads

The loading on the beam shown in Fig. (a), is equal to the sum of Fig. (b) and Fig. (c). In Fig. (c), the joints are restrained against displacements and fixed end forces are calculated. In Fig. (c) these fixed end actions are shown in reverse direction on the actual beam without any load. Since the beam in Fig. (b) is restrained (fixed) against any displacement, the displacements produced by the joint loads in Fig. (c) must be equal to the displacement produced by the actual beam in Fig. (a). Thus the loads shown in Fig. (c) are the equivalent joint loads. Let, p_1, p_2, p_3, p_4, p_5 and p_6 be the equivalent joint loads acting on the continuous beam along displacement degrees of freedom 1,2,3,4,5 and 6 respectively as shown in Fig. (b). Thus the global load vector is,

$$\begin{Bmatrix} p_1 \\ p_2 \\ p_3 \\ p_4 \\ p_5 \\ p_6 \end{Bmatrix} = \begin{Bmatrix} -\frac{Pb}{L} \\ -\frac{Pab^2}{L^2} \\ -\left(\frac{Pa}{L} + \frac{wL}{2}\right) \\ -\left(\frac{wL^2}{12} - \frac{Pba^2}{L^2}\right) \\ -\left(\frac{wL}{2} + 2P\right) \\ \frac{wL^2}{12} \end{Bmatrix}$$

SOLUTION OF EQUILIBRIUM EQUATIONS:

After establishing the global stiffness matrix and load vector of the beam, the load displacement relationship for the beam can be written as

$$\{P\} = [K]\{u\}$$

Where is the global load vector, $\{P\}$ $\{u\}$ is displacement vector and is the global stiffness matrix. In the above equation some joint displacements are known from support conditions. The above equation may be written as

$$\begin{Bmatrix} \{p_k\} \\ \{p_u\} \end{Bmatrix} = \begin{bmatrix} [k_{11}] & [k_{12}] \\ [k_{21}] & [k_{22}] \end{bmatrix} \begin{Bmatrix} \{u_u\} \\ \{u_k\} \end{Bmatrix}$$

Where $\{p_k\}$ and $\{u_k\}$ denote respectively vector of known forces and known displacements. And $\{p_u\}$ and $\{u_u\}$ denote respectively vector of unknown forces and unknown displacements respectively. Now expanding equation

$$\{p_k\} = [k_{11}]\{u_u\} + [k_{12}]\{u_k\}$$




$$\{p_u\} = [k_{21}]\{u_u\} + [k_{22}]\{u_k\}$$

Since $\{u_k\}$ is known, the unknown joint displacements can be evaluated. And support reactions are evaluated from equation, after evaluating unknown displacement vector.

Let R_1, R_3 and R_5 be the reactions along the constrained degrees of freedom. Since equivalent joint loads are directly applied at the supports, they also need to be considered while calculating the actual reactions. Thus,

$$\begin{Bmatrix} R_1 \\ R_3 \\ R_5 \end{Bmatrix} = - \begin{Bmatrix} p_1 \\ p_3 \\ p_5 \end{Bmatrix} + [K_{21}]\{u_u\}$$

The reactions may be calculated as follows. The reactions of the beam shown in Fig. a are equal to the sum of reactions shown in Fig. b, Fig. c and Fig. d.



From the method of superposition,

$$R_1 = \frac{Pb}{L} + K_{14}u_4 + K_{16}u_6$$

$$R_3 = \frac{Pa}{L} + K_{34}u_4 + K_{36}u_6$$

$$R_5 = \frac{wL}{2} + 2P + K_{54}u_4 + K_{56}u_6$$

or

$$\begin{Bmatrix} R_1 \\ R_3 \\ R_5 \end{Bmatrix} = \begin{Bmatrix} Pb/L \\ Pa/L \\ \frac{wl}{2} + 2P \end{Bmatrix} + \begin{bmatrix} K_{14} & K_{16} \\ K_{34} & K_{36} \\ K_{54} & K_{56} \end{bmatrix} \begin{Bmatrix} u_4 \\ u_6 \end{Bmatrix}$$

$$\begin{Bmatrix} R_1 \\ R_3 \\ R_5 \end{Bmatrix} = \begin{Bmatrix} Pb/L \\ Pa/L \\ \frac{wl}{2} + 2P \end{Bmatrix} + \begin{bmatrix} K_{14} & K_{16} \\ K_{34} & K_{36} \\ K_{54} & K_{56} \end{bmatrix} \begin{Bmatrix} u_4 \\ u_6 \end{Bmatrix}$$

Member end actions q_1 , q_2 , q_3 and q_4 are calculated as follows. For example consider the first element 1

$$\begin{Bmatrix} q_1 \\ q_2 \\ q_3 \\ q_4 \end{Bmatrix} = \begin{Bmatrix} \frac{Pb}{L} \\ \frac{Pab^2}{L^2} \\ \frac{Pa}{L} \\ \frac{Pa^2b}{L^2} \end{Bmatrix} + [K]_{\text{element1}} \begin{Bmatrix} 0 \\ u_2 \\ 0 \\ u_4 \end{Bmatrix}$$

Finite Elements for 2-D Problems

General Formula for the Stiffness Matrix


Displacements (u, v) in a plane element are interpolated from nodal displacements (u_i, v_i) using shape functions N_i as follows,

$$\begin{Bmatrix} u \\ v \end{Bmatrix} = \begin{bmatrix} N_1 & 0 & N_2 & 0 & \dots \\ 0 & N_1 & 0 & N_2 & \dots \end{bmatrix} \begin{Bmatrix} u_1 \\ v_1 \\ u_2 \\ v_2 \\ \vdots \end{Bmatrix} \quad \text{or} \quad \mathbf{u} = \mathbf{N}\mathbf{d}$$

where \mathbf{N} is the shape function matrix, \mathbf{u} the displacement vector and \mathbf{d} the nodal displacement vector. Here we have assumed that u depends on the nodal values of u only, and v on nodal values of v only. Most commonly employed 2-D elements are linear or quadratic triangles and quadrilaterals.

Constant Strain Triangle (CST or T3)

This is the simplest 2-D element, which is also called *linear triangular element*.



For this element, we have three nodes at the vertices of the triangle, which are numbered around the element in the counter clockwise direction. Each node has two degrees of freedom (can move in the x and y directions). The displacements u and v are assumed to be linear functions within the element, that is,

$$u = b_1 + b_2x + b_3y, \quad v = b_4 + b_5x + b_6y$$

where b_i ($i = 1, 2, \dots, 6$) are constants. From these, the strains are found to be,

$$\epsilon_x = b_2, \quad \epsilon_y = b_6, \quad \gamma_{xy} = b_3 + b_5$$

which are constant throughout the element.

The displacements should satisfy the following six equations,

$$u_1 = b_1 + b_2 x_1 + b_3 y_1$$

$$u_2 = b_1 + b_2 x_2 + b_3 y_2$$

$$\vdots$$

$$v_3 = b_4 + b_5 x_3 + b_6 y_3$$

Solving these equations, we can find the coefficients b_1, b_2, \dots , and b_6 in terms of nodal displacements and coordinates.

The displacements can be expressed as

$$\begin{Bmatrix} u \\ v \end{Bmatrix} = \begin{bmatrix} N_1 & 0 & N_2 & 0 & N_3 & 0 \\ 0 & N_1 & 0 & N_2 & 0 & N_3 \end{bmatrix} \begin{Bmatrix} u_1 \\ v_1 \\ u_2 \\ v_2 \\ u_3 \\ v_3 \end{Bmatrix}$$

The shape functions (linear functions in x and y) are

$$N_1 = \frac{1}{2A} \{ (x_2 y_3 - x_3 y_2) + (y_2 - y_3)x + (x_3 - x_2)y \}$$

$$N_2 = \frac{1}{2A} \{ (x_3 y_1 - x_1 y_3) + (y_3 - y_1)x + (x_1 - x_3)y \}$$

$$N_3 = \frac{1}{2A} \{ (x_1 y_2 - x_2 y_1) + (y_1 - y_2)x + (x_2 - x_1)y \}$$

and

$$A = \frac{1}{2} \det \begin{bmatrix} 1 & x_1 & y_1 \\ 1 & x_2 & y_2 \\ 1 & x_3 & y_3 \end{bmatrix} \quad \text{is the area of the triangle.}$$

The strain-displacement relations are written as

$$\begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \gamma_{xy} \end{Bmatrix} = \mathbf{B} \mathbf{d} = \frac{1}{2A} \begin{bmatrix} y_{23} & 0 & y_{31} & 0 & y_{12} & 0 \\ 0 & x_{32} & 0 & x_{13} & 0 & x_{21} \\ x_{32} & y_{23} & x_{13} & y_{31} & x_{21} & y_{12} \end{bmatrix} \begin{Bmatrix} u_1 \\ v_1 \\ u_2 \\ v_2 \\ u_3 \\ v_3 \end{Bmatrix}$$


where $x_{ij} = x_i - x_j$ and $y_{ij} = y_i - y_j$ ($i, j = 1, 2, 3$). Again, we see constant strains within the element. From stress-strain relation, we see that stresses obtained using the CST element are also constant.

The element stiffness matrix for the CST element,

$$\mathbf{k} = \int_V \mathbf{B}^T \mathbf{E} \mathbf{B} dV = tA(\mathbf{B}^T \mathbf{E} \mathbf{B})$$

in which t is the thickness of the element. Notice that \mathbf{k} for CST is a 6 by 6 symmetric matrix.

The Natural Coordinates



We introduce the *natural coordinates* (ξ, η) on the triangle, then the *shape functions* can be represented simply by,

$$N_1 = \xi, \quad N_2 = \eta, \quad N_3 = 1 - \xi - \eta$$

Notice that,


$$N_1 + N_2 + N_3 = 1$$

which ensures that the rigid body translation is represented by the chosen shape functions. Also, as in the 1-D case,

$$N_i = \begin{cases} 1, & \text{at node } i; \\ 0, & \text{at the other nodes} \end{cases}$$

and varies linearly within the element.

The plot for shape function N_1 is shown in the following figure. N_2 and N_3 have similar features.



We have two coordinate systems for the element: the global coordinates (x, y) and the natural coordinates (ξ, η) . The relation between the two is given by

$$\begin{aligned} x &= N_1 x_1 + N_2 x_2 + N_3 x_3 \\ y &= N_1 y_1 + N_2 y_2 + N_3 y_3 \end{aligned} \quad \Rightarrow \quad \begin{aligned} x &= x_{13} \xi + x_{23} \eta + x_3 \\ y &= y_{13} \xi + y_{23} \eta + y_3 \end{aligned}$$

where $x_{ij} = x_i - x_j$ and $y_{ij} = y_i - y_j$ ($i, j = 1, 2, 3$) as defined earlier.

Displacement u or v on the element can be viewed as functions of (x, y) or (ξ, η) .

Using the chain rule for derivatives, we have,

$$\begin{Bmatrix} \frac{\partial u}{\partial \xi} \\ \frac{\partial u}{\partial \eta} \end{Bmatrix} = \begin{bmatrix} \frac{\partial x}{\partial \xi} & \frac{\partial y}{\partial \xi} \\ \frac{\partial x}{\partial \eta} & \frac{\partial y}{\partial \eta} \end{bmatrix} \begin{Bmatrix} \frac{\partial u}{\partial x} \\ \frac{\partial u}{\partial y} \end{Bmatrix} = \mathbf{J} \begin{Bmatrix} \frac{\partial u}{\partial x} \\ \frac{\partial u}{\partial y} \end{Bmatrix}$$

where \mathbf{J} is called the *Jacobian matrix* of the transformation, and is expressed as

$$\mathbf{J} = \begin{bmatrix} x_{13} & y_{13} \\ x_{23} & y_{23} \end{bmatrix}, \quad \mathbf{J}^{-1} = \frac{1}{2A} \begin{bmatrix} y_{23} & -y_{13} \\ -x_{23} & x_{13} \end{bmatrix}$$

where $\det \mathbf{J} = x_{13} y_{23} - x_{23} y_{13} = 2A$ and A is the area of the triangular element.

$$\begin{Bmatrix} \frac{\partial u}{\partial x} \\ \frac{\partial u}{\partial y} \end{Bmatrix} = \frac{1}{2A} \begin{bmatrix} y_{23} & -y_{13} \\ -x_{23} & x_{13} \end{bmatrix} \begin{Bmatrix} \frac{\partial u}{\partial \xi} \\ \frac{\partial u}{\partial \eta} \end{Bmatrix} = \frac{1}{2A} \begin{bmatrix} y_{23} & -y_{13} \\ -x_{23} & x_{13} \end{bmatrix} \begin{Bmatrix} u_1 - u_3 \\ u_2 - u_3 \end{Bmatrix}$$

Similarly,

$$\begin{Bmatrix} \frac{\partial v}{\partial x} \\ \frac{\partial v}{\partial y} \end{Bmatrix} = \frac{1}{2A} \begin{bmatrix} y_{23} & -y_{13} \\ -x_{23} & x_{13} \end{bmatrix} \begin{Bmatrix} v_1 - v_3 \\ v_2 - v_3 \end{Bmatrix}$$

Using the relations $\varepsilon = \mathbf{D}\mathbf{u} = \mathbf{D}\mathbf{N}\mathbf{d} = \mathbf{B}\mathbf{d}$, we obtain the strain-displacement matrix,


$$\mathbf{B} = \frac{1}{2A} \begin{bmatrix} y_{23} & 0 & y_{31} & 0 & y_{12} & 0 \\ 0 & x_{32} & 0 & x_{13} & 0 & x_{21} \\ x_{32} & y_{23} & x_{13} & y_{31} & x_{21} & y_{12} \end{bmatrix}$$

Applications of the CST Element:

- Use in areas where the strain gradient is small.
- Use in mesh transition areas (fine mesh to coarse mesh).
- Avoid using CST in stress concentration or other crucial areas in the structure, such as edges of holes and corners.
- Recommended for quick and preliminary FE analysis of 2-D problems.

Linear Strain Triangle (LST or T6)

This element is also called *quadratic triangular element*.



There are six nodes on this element: three corner nodes and three mid-side nodes. Each node has two degrees of freedom (DOF) as before. The displacements (u, v) are assumed to be quadratic functions of (x, y) ,

$$u = b_1 + b_2x + b_3y + b_4x^2 + b_5xy + b_6y^2$$

$$v = b_7 + b_8x + b_9y + b_{10}x^2 + b_{11}xy + b_{12}y^2$$

where b_i ($i = 1, 2, \dots, 12$) are constants.

The strains are found to be,

$$\epsilon_x = b_2 + 2b_4x + b_5y$$

$$\epsilon_y = b_9 + b_{11}x + 2b_{12}y$$

$$\gamma_{xy} = (b_3 + b_8) + (b_5 + 2b_{10})x + (2b_6 + b_{11})y$$

which are linear functions. Thus, we have the “linear strain triangle” (LST), which provides better results than the CST.

In the natural coordinate system we defined earlier, the six shape functions for the LST element are,

$$N_1 = \xi(2\xi - 1)$$

$$N_2 = \eta(2\eta - 1)$$

$$N_3 = \zeta(2\zeta - 1)$$


$$N_4 = 4\xi\eta$$

$$N_5 = 4\eta\zeta$$

$$N_6 = 4\zeta\xi$$

in which $\zeta = 1 - \xi - \eta$


Each of these six shape functions represents a quadratic form on the element as shown in the following figure.



Displacements can be written as,

$$u = \sum_{i=1}^6 N_i u_i, \quad v = \sum_{i=1}^6 N_i v_i$$

Linear Quadrilateral Element (Q4)



There are four nodes at the corners of the quadrilateral shape. In the natural coordinate system \$(\xi, \eta)\$, the four shape functions are,

$$N_1 = \frac{1}{4}(1-\xi)(1-\eta), \quad N_2 = \frac{1}{4}(1+\xi)(1-\eta)$$

$$N_3 = \frac{1}{4}(1+\xi)(1+\eta), \quad N_4 = \frac{1}{4}(1-\xi)(1+\eta)$$

$$\sum_{i=1}^4 N_i = 1 \quad \text{at any point inside the element.}$$


The displacement field is given by

$$u = \sum_{i=1}^4 N_i u_i, \quad v = \sum_{i=1}^4 N_i v_i$$

which are bilinear functions over the element.

Quadratic Quadrilateral Element (Q8)

This is the most widely used element for 2-D problems due to its high accuracy in analysis and flexibility in modeling.



There are eight nodes for this element, four corners nodes and four mid-side nodes.

In the natural coordinate system (ξ, η) the eight shape functions are,

$$\begin{aligned} N_1 &= \frac{1}{4}(1-\xi)(\eta-1)(\xi+\eta+1) & N_5 &= \frac{1}{2}(1-\eta)(1-\xi^2) \\ N_2 &= \frac{1}{4}(1+\xi)(\eta-1)(\eta-\xi+1) & N_6 &= \frac{1}{2}(1+\xi)(1-\eta^2) \\ N_3 &= \frac{1}{4}(1+\xi)(1+\eta)(\xi+\eta-1) & N_7 &= \frac{1}{2}(1+\eta)(1-\xi^2) \\ N_4 &= \frac{1}{4}(\xi-1)(\eta+1)(\xi-\eta+1) & N_8 &= \frac{1}{2}(1-\xi)(1-\eta^2) \end{aligned}$$

Again, we have $\sum_{i=1}^8 N_i = 1$ at any point inside the element.

The displacement field is given by

$$u = \sum_{i=1}^8 N_i u_i, \quad v = \sum_{i=1}^8 N_i v_i$$

which are quadratic functions over the element. Strains and stresses over a quadratic quadrilateral element are quadratic functions, which are better representations.

Notes:

- · Q4 and T3 are usually used together in a mesh with linear elements.
- · Q8 and T6 are usually applied in a mesh composed of quadratic elements.
- · Quadratic elements are preferred for stress analysis, because of their high accuracy and the flexibility in modelling complex geometry, such as curved boundaries.

Stress Calculation

The stress in an element is determined by the following relation,

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \tau_{xy} \end{Bmatrix} = \mathbf{E} \begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \gamma_{xy} \end{Bmatrix} = \mathbf{EBd}$$

where \mathbf{B} is the strain-nodal displacement matrix and \mathbf{d} is the nodal displacement vector which is known for each element once the global FE equation has been solved.

Stresses can be evaluated at any point inside the element (such as the center) or at the nodes. Contour plots are usually used in FEA software packages (during post-process) for users to visually inspect the stress results.

The von Mises Stress:

The von Mises stress is the *effective or equivalent stress* for 2-D and 3-D stress analysis.

$$\sigma_e = \frac{1}{\sqrt{2}} \sqrt{(\sigma_1 - \sigma_2)^2 + (\sigma_2 - \sigma_3)^2 + (\sigma_3 - \sigma_1)^2}$$

in which σ_1, σ_2 and σ_3 and are the three principle stresses at the considered point in a structure.

For 2-D problems, the two principle stresses in the plane are determined by

$$\sigma_1^P = \frac{\sigma_x + \sigma_y}{2} + \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$
$$\sigma_2^P = \frac{\sigma_x + \sigma_y}{2} - \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$

Thus, we can also express the von Mises stress in terms of the stress components in the *xy coordinate system*.

For plane stress conditions, we have,

$$\sigma_e = \sqrt{(\sigma_x + \sigma_y)^2 - 3(\sigma_x \sigma_y - \tau_{xy}^2)}$$

Unit – III

Axisymmetric solids subjected to Axisymmetric loading with triangular elements. Two dimensional four noded isoparametric elements and numerical integration.

Elasticity Equations

Elasticity equations are used for solving structural mechanics problems. These equations must be satisfied if an exact solution to a structural mechanics problem is to be obtained. The types of elasticity equations are

1. Strian – Displacement relationship equations

$$e_x = \frac{\partial u}{\partial x}; e_y = \frac{\partial v}{\partial y}; \gamma_{xy} = \frac{\partial u}{\partial y} + \frac{\partial v}{\partial x}; \gamma_{xz} = \frac{\partial u}{\partial z} + \frac{\partial w}{\partial x};$$

$$\gamma_{yz} = \frac{\partial v}{\partial z} + \frac{\partial w}{\partial y}.$$

e_x – Strain in X direction, e_y – Strain in Y direction.

γ_{xy} - Shear Strain in XY plane, γ_{xz} - Shear Strain in XZ plane,

γ_{yz} - Shear Strain in YZ plane

2. Sterss – Strain relationship equation

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{zx} \end{Bmatrix} = \frac{E}{(1+\nu)(1-2\nu)} \begin{bmatrix} (1-\nu) & \nu & \nu & 0 & 0 & 0 \\ \nu & (1-\nu) & \nu & 0 & 0 & 0 \\ \nu & \nu & (1-\nu) & 0 & 0 & 0 \\ 0 & 0 & 0 & \frac{1-2\nu}{2} & 0 & 0 \\ 0 & 0 & 0 & 0 & \frac{1-2\nu}{2} & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{1-2\nu}{2} \end{bmatrix} \begin{Bmatrix} e_x \\ e_y \\ e_z \\ \gamma_{xy} \\ \gamma_{yz} \\ \gamma_{zx} \end{Bmatrix}$$

σ – Stress, τ – Shear Stress, E – Young's Modulus, ν – Poisson's Ratio, e – Strain, γ - Shear Strain.

3. Equilibrium equations

$$\frac{\partial \sigma_x}{\partial x} + \frac{\partial \tau_{xy}}{\partial y} + \frac{\partial \tau_{xz}}{\partial z} + B_x = 0; \quad \frac{\partial \sigma_y}{\partial y} + \frac{\partial \tau_{yz}}{\partial z} + \frac{\partial \tau_{xy}}{\partial x} + B_y = 0$$

$$\frac{\partial \sigma_z}{\partial z} + \frac{\partial \tau_{xz}}{\partial x} + \frac{\partial \tau_{yz}}{\partial y} + B_z = 0$$

σ – Stress, τ – Shear Stress, B_x - Body force at X direction,
 B_y - Body force at Y direction, B_z - Body force at Z direction.

4. Compatibility equations


There are six independent compatibility equations, one of which is

$$\frac{\partial^2 e_x}{\partial y^2} + \frac{\partial^2 e_y}{\partial x^2} = \frac{\partial^2 \gamma_{xy}}{\partial x \partial y}.$$

The other five equations are similarly second order relations.

➤ Axisymmetric Elements

Most of the three dimensional problems are symmetry about an axis of rotation. Those types of problems are solved by a special two dimensional element called as axisymmetric element.



➤ Axisymmetric Formulation

The displacement vector u is given by

$$u(r, z) = \begin{Bmatrix} u \\ w \end{Bmatrix}$$

The stress σ is given by

$$Stress, \{\sigma\} = \begin{Bmatrix} \sigma_r \\ \sigma_\theta \\ \sigma_z \\ \tau_{rz} \end{Bmatrix}$$

The strain e is given by

$$Strain, \{e\} = \begin{Bmatrix} e_r \\ e_\theta \\ e_z \\ \gamma_{rz} \end{Bmatrix}$$

Equation of shape function for Axisymmetric element

Shape function,

$$N_1 = \frac{\alpha_1 + \beta_1 r + \gamma_1 z}{2A}; \quad N_2 = \frac{\alpha_2 + \beta_2 r + \gamma_2 z}{2A}; \quad N_3 = \frac{\alpha_3 + \beta_3 r + \gamma_3 z}{2A}$$

$$\alpha_1 = r_2 z_3 - r_3 z_2; \quad \alpha_2 = r_3 z_1 - r_1 z_3; \quad \alpha_3 = r_1 z_2 - r_2 z_1$$

$$\beta_1 = z_2 - z_3; \quad \beta_2 = z_3 - z_1; \quad \beta_3 = z_1 - z_2$$

$$\gamma_1 = r_3 - r_2; \quad \gamma_2 = r_1 - r_3; \quad \gamma_3 = r_2 - r_1$$

$$2A = (r_2 z_3 - r_3 z_2) - r_1 (r_3 z_1 - r_1 z_3) + z_1 (r_1 z_2 - r_2 z_1)$$

➤ Equation of Strain – Displacement Matrix [B] for Axisymmetric element

$$[B] = \frac{1}{2A} \begin{bmatrix} \beta_1 & 0 & \beta_2 & 0 & \beta_3 & 0 \\ \frac{\alpha_1}{r} + \beta_1 + \frac{\gamma_1 z}{r} & 0 & \frac{\alpha_2}{r} + \beta_2 + \frac{\gamma_2 z}{r} & 0 & \frac{\alpha_3}{r} + \beta_3 + \frac{\gamma_3 z}{r} & 0 \\ 0 & \gamma_1 & 0 & \gamma_2 & 0 & \gamma_3 \\ \gamma_1 & \beta_1 & \gamma_2 & \beta_2 & \gamma_3 & \beta_3 \end{bmatrix} \begin{Bmatrix} u_1 \\ w_1 \\ u_2 \\ w_2 \\ u_3 \\ w_3 \end{Bmatrix}$$

$$r = \frac{r1 + r2 + r3}{3}$$

➤ **Equation of Stress – Strain Matrix [D] for Axisymmetric element**

$$[D] = \frac{E}{(1+\nu)(1-2\nu)} \begin{bmatrix} 1-\nu & \nu & \nu & 0 \\ \nu & 1-\nu & \nu & 0 \\ \nu & \nu & 1-\nu & 0 \\ 0 & 0 & 0 & \frac{1-2\nu}{2} \end{bmatrix}$$

➤ **Equation of Stiffness Matrix [K] for Axisymmetric element**

$$[K] = 2\pi r A [B]^T [D] [B]$$


$$r = \frac{r1 + r2 + r3}{3}; A = (\frac{1}{2}) b \times h$$

➤ **Temperature Effects**


The thermal force vector is given by $\{f\}_t = 2\pi r A [B]^T [D] \{e\}_t$

$$\{f\}_t = \begin{Bmatrix} F_1 u \\ F_1 w \\ F_2 u \\ F_2 w \\ F_3 u \\ F_3 w \end{Bmatrix}$$

➤ **Problem (I set)** 1. For the given element, determine the stiffness matrix. Take $E=200\text{GPa}$ and $\nu=0.25$.




➤ 2. For the figure, determine the element stresses. Take $E=2.1 \times 10^5 \text{N/mm}^2$ and $\nu=0.25$. The co – ordinates are in mm. The nodal displacements are $u_1=0.05\text{mm}$, $w_1=0.03\text{mm}$, $u_2=0.02\text{mm}$, $w_2=0.02\text{mm}$, $u_3=0.0\text{mm}$, $w_3=0.0\text{mm}$.



➤ 3. A long hollow cylinder of inside diameter 100mm and outside diameter 140mm is subjected to an internal pressure of 4N/mm^2 . By using two elements on the 15mm length, calculate the displacements at the inner radius.

➤ Isoparametric element


Generally it is very difficult to represent the curved boundaries by straight edge elements. A large number of elements may be used to obtain reasonable resemblance between original body and the assemblage. In order to overcome this drawback, isoparametric elements are used.



If the number of nodes used for defining the geometry is same as number of nodes used defining the displacements, then it is known as isoparametric element.


➤ Superparametric element

If the number of nodes used for defining the geometry is more than number of nodes used for defining the displacements, then it is known as superparametric element.



➤ **Subparametric element**

If the number of nodes used for defining the geometry is less than number of nodes used for defining the displacements, then it is known as subparametric element.



➤ **Equation of Shape function for 4 noded rectangular parent element**

$$u = \begin{Bmatrix} x \\ y \end{Bmatrix} = \begin{bmatrix} N_1 & 0 & N_2 & 0 & N_3 & 0 & N_4 & 0 \\ 0 & N_1 & 0 & N_2 & 0 & N_3 & 0 & N_4 \end{bmatrix} \begin{Bmatrix} x_1 \\ y_2 \\ x_1 \\ y_2 \\ x_3 \\ y_3 \\ x_4 \\ y_4 \end{Bmatrix}$$

$$N_1 = 1/4(1-\xi)(1-\eta); N_2 = 1/4(1+\xi)(1-\eta); N_3 = 1/4(1+\xi)(1+\eta); N_4 = 1/4(1-\xi)(1+\eta).$$

➤ Equation of Stiffness Matrix for 4 noded isoparametric quadrilateral element

$$[K] = t \int_{-1}^1 \int_{-1}^1 [B]^T [D][B] J | \partial \varepsilon \partial \eta$$

$$[J] = \begin{bmatrix} J_{11} & J_{12} \\ J_{21} & J_{22} \end{bmatrix};$$

$$J_{11} = \frac{1}{4} [-(1-\eta)x_1 + (1-\eta)x_2 + (1+\eta)x_3 - (1+\eta)x_4];$$

$$J_{12} = \frac{1}{4} [-(1-\eta)y_1 + (1-\eta)y_2 + (1+\eta)y_3 - (1+\eta)y_4];$$

$$J_{21} = \frac{1}{4} [-(1-\varepsilon)x_1 - (1+\varepsilon)x_2 + (1+\varepsilon)x_3 + (1-\varepsilon)x_4];$$

$$J_{22} = \frac{1}{4} [-(1-\varepsilon)y_1 - (1+\varepsilon)y_2 + (1+\varepsilon)y_3 + (1-\varepsilon)y_4];$$

$$[B] = \frac{1}{|J|} \begin{bmatrix} J_{22} & -J_{12} & 0 & 0 \\ 0 & 0 & -J_{21} & J_{11} \\ -J_{21} & J_{11} & J_{22} & -J_{12} \end{bmatrix} \begin{bmatrix} \frac{\partial N_1}{\partial \varepsilon} & 0 & \frac{\partial N_2}{\partial \varepsilon} & 0 & \frac{\partial N_3}{\partial \varepsilon} & 0 & \frac{\partial N_4}{\partial \varepsilon} & 0 \\ \frac{\partial N_1}{\partial \eta} & 0 & \frac{\partial N_2}{\partial \eta} & 0 & \frac{\partial N_3}{\partial \eta} & 0 & \frac{\partial N_4}{\partial \eta} & 0 \\ 0 & \frac{\partial N_1}{\partial \varepsilon} & 0 & \frac{\partial N_2}{\partial \varepsilon} & 0 & \frac{\partial N_3}{\partial \varepsilon} & 0 & \frac{\partial N_4}{\partial \varepsilon} \\ 0 & \frac{\partial N_1}{\partial \eta} & 0 & \frac{\partial N_2}{\partial \eta} & 0 & \frac{\partial N_3}{\partial \eta} & 0 & \frac{\partial N_4}{\partial \eta} \end{bmatrix}$$

$$[D] = \frac{E}{(1-\nu^2)} \begin{bmatrix} 1-\nu & \nu & 0 \\ \nu & 1 & 0 \\ 0 & 0 & \frac{1-\nu}{2} \end{bmatrix}, \text{ for plane stress conditions;}$$

$$[D] = \frac{E}{(1+\nu)(1-2\nu)} \begin{bmatrix} 1-\nu & \nu & 0 \\ \nu & 1-\nu & 0 \\ 0 & 0 & \frac{1-2\nu}{2} \end{bmatrix}, \text{ for plane strain conditions.}$$

➤ **Equation of element force vector**

$$\{F\}_e = [N]^T \begin{Bmatrix} F_x \\ F_y \end{Bmatrix};$$

N – Shape function, F_x – load or force along x direction, F_y – load or force along y direction.

➤ **Numerical Integration (Gaussian Quadrature)**

The Gauss quadrature is one of the numerical integration methods to calculate the definite integrals. In FEA, this Gauss quadrature method is mostly preferred. In this method the numerical integration is achieved by the following expression,

$$\int_{-1}^1 f(x) dx = \sum_{i=1}^n w_i f(x_i)$$


Table gives gauss points for integration from -1 to 1.

Number of Points n	Location x_i	Corresponding Weights w_i
1	$x_1 = 0.000$	2.000
2	$x_1, x_2 = \pm\sqrt{\frac{1}{3}} = \pm 0.577350269189$	1.000
3	$x_1, x_3 = \pm\sqrt{\frac{3}{5}} = \pm 0.774596669241$ $x_2 = 0.000$	$\frac{5}{9} = 0.555555$ $\frac{8}{9} = 0.888888$
4	$x_1, x_4 = \pm 0.8611363116$ $x_2, x_3 = \pm 0.3399810436$	0.3478548451 0.6521451549


➤ **Problem (I set)** 1. Evaluate, $I = \int_{-1}^1 \cos \frac{\pi x}{2} dx$, by applying 3 point Gaussian quadrature and compare with exact solution.

2. Evaluate, $I = \int_{-1}^1 \left[3e^x + x^2 + \frac{1}{x+2} \right] dx$, using one point and two point Gaussian quadrature. Compare with exact solution.

3. For the isoparametric quadrilateral element shown in figure, determine the local co –ordinates of the point P which has Cartesian co-ordinates (7, 4).



4. A four noded rectangular element is in figure. Determine (i) Jacobian matrix, (ii) Strain – Displacement matrix and (iii) Element Stresses. Take $E=2 \times 10^5 \text{ N/mm}^2$, $\nu=0.25$, $u=[0,0,0.003,0.004,0.006,0.004,0,0] \text{ T}$, $\epsilon=0$, $\eta=0$. Assume plane stress condition.



MALLAREDDY COLLEGE OF ENGINEERING AND TECHNOLOGY

MECHANICAL DEPARTMENT

SUB: FEM

MODEL PAPER 1

PART A

(25 MARKS)

1. a. What is meant by Engineering analysis and specify its Types (2M)
- b. What is Hermite shape function (3M)
- c. Write the equilibrium equations for 3D body (2M)
- d. What is coordinate system. specify the types and explain (3M)
- e. What is meant by axi-symmetric problems (2M)
- f. Derive the shape functions for 2D truss element (3M)
- g. What is the degree of freedom for the thermal problems (2M)
- h. Distinguish between CST and LST (3M)
- i. Write the dynamic equation of motion for the undamped free vibrations (2M)
- j. Determine the Area of the triangle A(2,2),B(7,4),C(3,6) (3M)


PART B

(10X5=50 MARKS)

2. a) Derive the equations of equilibrium in case of a three dimensional stress system.
- b) Discuss the advantages and disadvantages of FEM over
 - (i) Classical method
 - (ii) Finite difference method.

OR


3. a) Solve the differential equation for the physical problem expressed as $d^2y/dx^2 + 100 = 0$ when $0 \leq x \leq 10$ with boundary condition as $y(0) = 0$ and $y(10) = 0$ using i) point collocation ii) sub-domain collocation iii) least square method iv) Galerkin method
 - b) Write the Strain displacement equations for three dimensional system
4. a) Determine the nodal displacement, Element stresses for axially loaded bar as shown in the fig. below




b) Derive the strain displacement matrices for triangular element of revolving body.

OR

- 5 a) For the beam shown in Figure below, determine the following: a) Slopes at nodes 2 and 3
- b) Vertical deflection at the mid-point of the distributed load. Consider all the elements have $E=200\text{GPa}$, $I=5 \times 10^6 \text{ mm}^4$



6. a) For the element shown in the figure, assemble Jacobian matrix and strain displacement matrix




- b) Determine the shape functions for a 8 node quadratic quadrilateral Evaluation element(boundary noded).


OR

7. a) Establish the shape functions for a 3 – noded triangular element

b) Find the deformed configuration, and the maximum stress and minimum stress locations for the rectangular plate loaded as shown in the fig. Solve the problem using 2 triangular elements. Assume thickness = 10cm; $E = 70 \text{ Gpa}$, and $\nu = 0.33$




8, The composite wall consists of three materials shown in figure. The inside wall temperature is at 200°C and the outside air temperature is 50°C with a convection coefficient of $10 \text{ W/m}^2^\circ\text{C}$. Determine the temperature along the composite wall




9.a) Derive one dimensional steady state heat conduction equation.

b) An axisymmetric triangular element is subjected to the loading as shown in fig. the load is distributed throughout the circumference and normal to the boundary. Derive all the necessary equations and derive the nodal point loads.



10. a) Determine the strain displacement matrix for the TETRAHEDRAL element as shown in fig




b) Explain the concept of numerical integration and its utility in generating Isoperimetric finite element matrices

OR

11. a) What are the necessary requirements for convergence and explain about h- and p requirements

b) Derive the stiffness matrix for truss element in case of linear and quadratic shape functions At 20°C an axial load $P = 300 \times 10^3$ is applied to the rod as shown in Fig. The temperature is then raised to 60°C . Assemble the element stiffness matrix and the element temperature force matrix (F). Again determine the nodal displacements and element stresses. Also find element strains. Assume $E_1 = 70 \times 10^9 \text{ N/m}^2$, $A_1 = 900 \text{ mm}^2$, $\alpha_1 = 23 \times 10^{-6} / ^{\circ}\text{C}$, $E_2 = 200 \times 10^9 \text{ N/m}^2$, $A_2 = 1200$

mm^2 , $\alpha_2 = 11.7 \times 10^{-6} / ^{\circ}\text{C}$.



MALLAREDDY COLLEGE OF ENGINEERING AND TECHNOLOGY

MECHANICAL DEPARTMENT

SUB: FEM

MODEL PAPER 2

PART A


(25 MARKS)

1. a. What is FEM (2M)
- b. Write the advantages of FEM (3M)
- c. What is CST (2M)
- d. Write the strain relations of three dimensional system (3M)
- e. What is local coordinate System (2M)
- f. Write the Eigen values and Eigen vectors for a stepped bar (3M)
- g. What is the degree of freedom for the thermal problems (2M)
- h. Define principle of virtual work. Describe the FEM formulation for 1D bar element (3M)
- i. What is dynamic analysis (2M)
- j. Discuss Mass generation (3M)

PART B

(10X5=50 MARKS)

2. a) Differentiate among Bar element, Truss element and Beam element indicating D.O.F and geometry characteristics.
- b) An axial load $P = 300 \times 10^3 \text{ N}$ is applied at 20° C to the rod as shown in Figure below. The temperature is raised to 60° C
 - a) Assemble the K and F matrices
 - b) Determine the nodal displacements and stresses



3. a) Discuss in detail about the concepts of FEM formulation. How is that emerged as a powerful tool. Discuss in detail about applications of finite element method
- b) Derive an equation for finding out the potential energy by Rayleigh-Ritz method. Using Rayleigh-Ritz method, find the displacement of the midpoint of the rod shown in Fig. Assume $E = 1, A = 1, \rho g = 1$ by using linear and quadratic shape function concept




Fig.

- 4 a) Discuss in detail about Linear and Quadratic shape functions with examples
 b) Consider axial vibration of the Aluminum bar shown in Fig., (i) develop the global stiffness and (ii) determine the nodal displacements and stresses using elimination approach and with help of linear and quadratic shape function concept. Assume Young's Modulus $E = 70\text{Gpa}$





Fig.

OR

5. a) Describe Rayleigh-Ritz method
 b) A beam is fixed at one end and supported by roller at the other end has 20kN load applied at the center of the span of 10m. Calculate deflection and slope and also construct shear force and bending moment diagrams
6. a) State the properties and applications of CST
 b) The nodal coordinates of the triangular element shown in figure at the interior point P. the x coordinate is 3.3 and the shape function at node 1 is N_1 is 0.3. determine the shape functions at nodes 2 and 3 also find the 'y' coordinate of P




OR

7. a) Determine the stiffness and Jacobian matrix for the iso parametric quadrilateral element starting from fundamentals.
 b) Differentiate between axis-symmetric boundary condition and polar symmetric boundary condition.
 c) Derive the load vector for the axis-symmetric triangular element with the variable surface load on the surface.


8. a) derive one dimensional steady state heat conduction equation

b) An axis symmetric element subjected to loading as shown in figure .The load is distributed throughtout the circumference and normal to the boundary. Derive all necessary equations and derive nodal point loads



OR

9. Calculate the conductance matrix $[K(e)]$ and load vector $fF(e)g$ for the triangle element shown in figure 8. The thermal conductivities are $k_x = k_y = 4 \text{ W/cm} \cdot ^\circ\text{C}$ and $h = 0.3 \text{ W/cm}^2 \cdot ^\circ\text{C}$. Thickness of the element is 1cm. All coordinates are given in cms. Convection occurs on the side joining nodes i and j.



10. For the stepped bar shown in figure develop the global stiffness matrix and mass matrices and determine the natural frequencies and mode shapes Assume $E=200\text{GPa}$ and mass density is 7850 Kg/m^3 $L_1=L_2=0.3 \text{ m}$ $A_1=350 \text{ mm}^2$ and $A_2=600 \text{ mm}^2$



Fig.

OR

11. a) Derive the shape functions for the four noded tetrahedron element from the first principles
b) discuss the importance of semi automatic meshing and practical applications

**MALLAREDDY COLLEGE OF ENGINEERING
AND TECHNOLOGY**

MECHANICAL DEPARTMENT

SUB: FEM


**MODEL PAPER 3
PART A (25 MARKS)**

1. a. List the various weighted residual methods (2M)
- b. Write the properties of shape function (3M)
- c. What are the advantages of natural coordinate system (2M)
- d. Write analogies between structural, heat transfer and fluid mechanics (3M)
- e. Name few FEA packages (2M)
- f. Derive the mass matrix for a 1D linear bar element (3M)
- g. What are the properties of stiffness matrix (2M)
- h. Explain about plain stress and plain strain conditions (3M)
- i. Write down the conduction matrix for a three noded triangular element (2M)
- j. Distinguish between Error in solution and Residual (3M)

PART B

(10X5=50)

2. a) Determine the nodal displacement, stress and strain for the bar shown in fig



- b) Using potential energy approach, describe FE formulation for plane truss Element


OR

3. a) Solve the differential equation for the physical problem expressed as $d^2y/dx^2 + 100 = 0$ when $0 \leq x \leq 10$ with boundary condition as $y(0) = 0$ and $y(10) = 0$ using i) point collocation ii) sub-domain collocation iii) least square method

iv) galarkin method.

b) Explain the concept of FEM briefly .outline the steps involved in FEM along with applications


4. a) For a beam and loading shown in fig., determine the slopes at 2 and 3 and the vertical deflection at the midpoint of the distributed load




b) Establish the shape functions for a 3 – noded triangular element.

OR


5. Calculate the nodal displacement, stresses and support reactions for the truss shown in figure



- 6.a) Evaluate the element stiffness matrix for the triangular element shown under plane strain condition. Assume the following values $E=200$ GPa, $\mu=0.25$, $t=1$ mm




b) For the element shown in the figure, assemble Jacobian matrix and strain displacement matrix



OR

7. a) Derive the a) shape function and b) strain displacement matrices for triangular element of revolving body

b) for the Isoparametric quadrilateral element shown in fig , determine the local co-ordinates of the point P whose Cartesian co=ordinates as(6,4)



8 a) Determine the temperature at the nodal interfaces for the two layered wall shown in fig.the left face is supplied with


heat flux of $Q^{11}=5 \text{ W/cm}^2$ and the right face is maintained at 20°C

$$Q^u = 5 \text{ W/cm}^2$$

$$K_1 = 0.2 \text{ W/cm}^\circ\text{C}$$

$$K_2 = 0.06 \text{ W/cm}^\circ\text{C}$$

$$A = 1 \text{ cm}^2.$$




b) Derive the Strain displacement Matrix for 2D-Thin plate. Consider the temperature field with in the triangular element is given by $T = N_1 T_1 + N_2 T_2 + N_3 T_3$

OR

9. Determine the temperature distribution through the composite wall shown in figure, when convection heat loss occurs on the left surface. Assume unit area Assume wall thickness $t_1 = 4\text{cm}$, $t_2 = 2\text{cm}$, $k_1 = 0.5\text{W/cm}^0\text{C}$, $k_2 = 0.05\text{W/cm}^0\text{C}$

$h = 0.1\text{W/cm}^2\text{C}$ and $T_a = -5^0\text{C}$



10. a) Determine the eigen values and the associated Eigen vectors of the matrix $[A]$ given by


$$A = \begin{bmatrix} 3 & 4 \\ 4 & -3 \end{bmatrix}$$

b) State the properties of Eigen Values.


OR

11.a) Explain difference between Lumped Mass and Consistent Mass

b) Determine the Natural frequency of the beam shown in the figure




PART B (10X5=50)



b) Explain the elimination method and penalty method for imposing specified displacement boundary conditions


4. a) Obtain the forces in the plane Truss shown in Figure below and determine the support reactions also. Take $E=200\text{GPa}$ and $A= 2000\text{mm}^2$



b) Derive the Hermite shape functions for beam element.

OR

5.a) Analyze the beam shown in Figure method and determine the end reactions. Also determine the below by finite element deflections at mid spans given $E=2 \times 10^5 \text{N/mm}^2$, and $I=5 \times 10^6 \text{mm}^4$



b) What are the general features of a bar Element?


6. a) Formulate the finite element equations for Constant strain triangle shown in fig. Assume plane stress $E=200\text{GPa}$, $\nu=0.25$, thickness=5mm, nodal co-ordinates. Pressure on 1-2 edge is 5N/mm^2

X1=1	X2=5	X3=3
Y1=2	Y2=4	Y3=6

b) Write the Advantages of iso-parametric elements


OR

- 7.a) For the configuration shown in figure, determine the deflection at the point load application using a one element model. $T = 10 \text{ mm}$, $E = 70 \text{ G Pa}$, $\nu = .3$



- b) Derive the strain displacement matrix for triangular element.

8. a) The plane wall shown in fig. The thermal conductivity $K = 25 \text{ W/m}^\circ\text{C}$ and there is a uniform generation of heat in the wall $Q = 400 \text{ W/m}^3$. Determine the temperature distribution at five nodes (include two sides of the walls) in equal distances through the wall thickness




- b) Derive Approximate the first two natural frequencies of a cantilever beam using one element model. EI =Flexural rigidity

9. a) A metallic fin with thermal conductivity $K=360 \text{ W/m}^\circ\text{C}$, 1mm thick and 100mm long extends from a plane wall whose temperature is 235°C . Determine the distribution and amount of heat transferred from the fin to air at 20°C with $h= 9 \text{ W/m}^2\text{C}$ take width of the fin is 1000 mm. Assume tip is insulated




- b) Explain the concept of numerical integration and its utility in generating Isoperimetric finite element matrices

10.a) Determine the strain displacement matrix for the TETRAHEDRAL element as shown in fig




b) Determine the approximate first two natural frequencies of a simply supported beam using one element. Flexural Rigidity = EI ; Density = ρ Cross-sectional area = A



OR

11.a) State the method used for obtaining natural frequencies and corresponding eigen vectors.

b) Evaluate natural frequencies for the CANTILEVER beam shown in fig USING ONE ELEMENT



**MALLAREDDY COLLEGE OF ENGINEERING
AND TECHNOLOGY**

MECHANICAL DEPARTMENT

SUB: FEM

**MODEL PAPER 5
PART A (25 MARKS)**

1. a. What is the principle of FEM (2M)
- b. Write the stress strain relations for 2D plane stress and plane strain conditions (3M)
- c. Differentiate between truss and beam element based on degree of freedom. (2M)
- d. What is Hermite shape function (3M)
- e. Write the formula for the load vector of triangular element subjected to body force (2M)
- f. What is the size of stiffness matrix for axisymmetric triangular element (3M)
- g. What is the degree of freedom for the thermal problems (2M)
- h. Where do you apply (3M)
- i. Name Few FEA packages (2M)
- j. Explain the importance of lumped mass matrix (3M)


PART B

10X5=50

2. a) Why polynomial type of interpolation function is preferred over trigonometric functions? Explain
- b) Draw the Pascal's triangle and Pascal's tetrahedron for understanding the interpolations functions. Explain the salient features

OR


3. a) Explain the steps involved in obtaining an appropriate solution using AEM
 - b) Explain the equilibrium state of the system, when the system is subjected to different types of loads and explain the stress and equilibrium relations
4. For a two dimensional structure as shown in figure. determine displacement of the nodes and normal stresses developed in the members using FE. Use $E = 39 \times 10^6 \text{ N/cm}^2$ and the diameter of the cross-section of 0.25 cm.



OR

5. A beam is fixed at one end and supported by a roller at the other end, has a 20 kN concentrated load applied at the center of the span of 10 m. Calculate the deflection and slope and also construct shear force and bending moment diagrams and take $I=2500 \text{ cm}^4$

6.a) Evaluate the axisymmetric stiffness matrix K of the triangular element shown in the figure. Consider the coordinates of the nodes (2,1), (4,0), and (3,2). Also assume $E=2.6 \text{ GPa}$ and $\nu=0.2$



b) Difference between CST and LST with respect to the triangular element.

OR


7. Derive the stiffness matrix for the four-noded quadrilateral element in terms of natural coordinate systems

8. Consider a brick wall of thickness 0.3 m, $k=0.7 \text{ W/m}\cdot\text{K}$. The inner surface is at 28°C and the outer surface is exposed to cold air at -15°C . The heat transfer coefficient associated with the outside surface is $40 \text{ W/m}^2\cdot\text{K}$. Determine the steady state temperature distribution within the wall and also the heat flux through the wall. Use two elements and obtain the solution

OR

9. Derive the conductivity matrix for two-dimensional triangular element subjected to convection on one face of the element

10. For the stepped bar shown in figure. Develop the global stiffness and mass matrices and also determine the natural frequencies and mode shapes. Assume $E=200 \text{ GPa}$ and mass density $=7850 \text{ Kg/m}^3$. $L_1=L_2=0.3 \text{ m}$, $A_1=350 \text{ mm}^2$, $A_2=600 \text{ mm}^2$



OR

11.a) Derive the shape functions for the four-noded tetrahedron element from the first principle

b) discuss the importance of semi automatic meshing and auto mesh along with the practical applications