FINITE ELEMENT ANALYSIS

COURSE FILE

III B. Tech II Semester

(2018-2019)

Prepared By

Mr. S. SHAILESH BABU

Asst. Prof.

Department of Aeronautical Engineering

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

Affiliated to JNTU, Hyderabad, Approved by AICTE - Accredited by NBA & NAAC – 'A' Grade - ISO 9001:2015 Certified) Maisammaguda, Dhulapally (Post Via. Kompally), Secunderabad – 500100, Telangana State, India.

Finite Element Analysis

By S. Shailesh Babu

MRCET VISION

- To become a model institution in the fields of Engineering, Technology and Management.
- To have a perfect synchronization of the ideologies of MRCET with challenging demands of International Pioneering Organizations.

MRCET MISSION

To establish a pedestal for the integral innovation, team spirit, originality and competence in the students, expose them to face the global challenges and become pioneers of Indian vision of modern society.

MRCET QUALITY POLICY.

- To pursue continual improvement of teaching learning process of Undergraduate and Post Graduate programs in Engineering & Management vigorously.
- □ To provide state of art infrastructure and expertise to impart the quality education.

By S. Shailesh Babu

PROGRAM OUTCOMES

(PO's)

Engineering Graduates will be able to:

- 1. **Engineering knowledge**: Apply the knowledge of mathematics, science, engineering fundamentals, and an engineering specialization to the solution of complex engineering problems.
- Problem analysis: Identify, formulate, review research literature, and analyze complex engineering problems reaching substantiated conclusions using first principles of mathematics, natural sciences, and engineering sciences.
- 3. **Design / development of solutions**: Design solutions for complex engineering problems and design system components or processes that meet the specified needs with appropriate consideration for the public health and safety, and the cultural, societal, and environmental considerations.
- 4. **Conduct investigations of complex problems**: Use research-based knowledge and research methods including design of experiments, analysis and interpretation of data, and synthesis of the information to provide valid conclusions.
- 5. **Modern tool usage**: Create, select, and apply appropriate techniques, resources, and modern engineering and IT tools including prediction and modeling to complex engineering activities with an understanding of the limitations.
- 6. **The engineer and society**: Apply reasoning informed by the contextual knowledge to assess societal, health, safety, legal and cultural issues and the consequent responsibilities relevant to the professional engineering practice.
- Environment and sustainability: Understand the impact of the professional engineering solutions in societal and environmental contexts, and demonstrate the knowledge of, and need for sustainable development.
- 8. **Ethics**: Apply ethical principles and commit to professional ethics and responsibilities and norms of the engineering practice.
- 9. Individual and team work: Function effectively as an individual, and as a member or leader in diverse teams, and in multidisciplinary settings.
- 10. **Communication**: Communicate effectively on complex engineering activities with the engineering community and with society at large, such as, being able to comprehend and write effective reports and design documentation, make effective presentations, and give and receive clear instructions.
- 11. **Project management and finance**: Demonstrate knowledge and understanding of the engineering and management principles and apply these to one's own work, as a member and leader in a team, to manage projects and in multi disciplinary environments.

12. Life- long learning: Recognize the need for, and have the preparation and ability to engage in independent and life-long learning in the broadest context of technological change.

DEPARTMENT OF AERONAUTICAL ENGINEERING

VISION

Department of Aeronautical Engineering aims to be indispensable source in Aeronautical Engineering which has a zeal to provide the value driven platform for the students to acquire knowledge and empower themselves to shoulder higher responsibility in building a strong nation.

MISSION

The primary mission of the department is to promote engineering education and research. To strive consistently to provide quality education, keeping in pace with time and technology. Department passions to integrate the intellectual, spiritual, ethical and social development of the students for shaping them into dynamic engineers.

QUALITY POLICY STATEMENT

Impart up-to-date knowledge to the students in Aeronautical area to make them quality engineers. Make the students experience the applications on quality equipment and tools. Provide systems, resources and training opportunities to achieve continuous improvement. Maintain global standards in education, training and services.

PROGRAM EDUCATIONAL OBJECTIVES – Aeronautical Engineering

- 1. **PEO1 (PROFESSIONALISM & CITIZENSHIP):** To create and sustain a community of learning in which students acquire knowledge and learn to apply it professionally with due consideration for ethical, ecological and economic issues.
- PEO2 (TECHNICAL ACCOMPLISHMENTS): To provide knowledge based services to satisfy the needs of society and the industry by providing hands on experience in various technologies in core field.
- 3. **PEO3 (INVENTION, INNOVATION AND CREATIVITY):** To make the students to design, experiment, analyze, and interpret in the core field with the help of other multi disciplinary concepts wherever applicable.
- 4. **PEO4 (PROFESSIONAL DEVELOPMENT):** To educate the students to disseminate research findings with good soft skills and become a successful entrepreneur.
- 5. **PEO5 (HUMAN RESOURCE DEVELOPMENT):** To graduate the students in building national capabilities in technology, education and research

PROGRAM SPECIFIC OUTCOMES – Aeronautical Engineering

- 1. To mould students to become a professional with all necessary skills, personality and sound knowledge in basic and advance technological areas.
- 2. To promote understanding of concepts and develop ability in design manufacture and maintenance of aircraft, aerospace vehicles and associated equipment and develop application capability of the concepts sciences to engineering design and processes.
- 3. Understanding the current scenario in the field of aeronautics and acquire ability to apply knowledge of engineering, science and mathematics to design and conduct experiments in the field of Aeronautical Engineering.
- 4. To develop leadership skills in our students necessary to shape the social, intellectual, business and technical worlds.



MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

III Year B. Tech, ANE-II Sem

(R15A2120) FINITE ELEMENT ANALYSIS (CORE ELECTIVE – IV)

Objectives:

- It covers the fundamental theoretical approach beginning with a review of differential equations, boundary conditions, integral forms, interpolation, parametric geometry, numerical integration, and matrix algebra.
- Next, engineering applications to field analysis, stress analysis and vibrations are introduced. Time dependent problems are also treated.
- Students are also introduced, by means of selected tutorials, to the commercial finite element system SolidWorks which is similar to one they could be expected to use upon graduation. Graduate students will also be introduced to the more powerful (and difficult to use) Ansys system.

UNIT – I

Introduction to Finite Element Method for solving field problems. Stress and Equilibrium. Strain – Displacement relations. Stress – strain relations. One Dimensional problems : Finite element modeling coordinates and shape functions. Potential Energy approach : Assembly of Global stiffness matrix and load vector. Finite element equations, Treatment of boundary conditions, Quadratic shape functions.

UNIT – II

Analysis of Beams : Element stiffness matrix for two node, two degrees of freedom per node beam element. Finite element modelling of two dimensional stress analysis with constant strain triangles and treatment of boundary conditions.

UNIT – III

Finite element modelling of Axisymmetric solids subjected to Axisymmetric loading with triangular elements. Two dimensional four noded isoparametric elements and numerical integration.

UNIT – IV

Steady state heat transfer analysis : one dimensional analysis of a fin and two dimensional analysis of thin plate. Analysis of a uniform shaft subjected to torsion.

UNIT-V

Dynamic Analysis : Formulation of finite element model, element matrices, evaluation of Eigen values and Eigen vectors for a stepped bar and a beam.

Outcomes:

- Upon completion of the course students should be able to correlate a differential equation and its
 equivalent integral form.
- Understand parametric interpolation and parametric geometry enforce essential boundary conditions to a matrix system.

TEXT BOOK:

- 1. Introduction to Finite Elements in Engineering / Chandraputla, Ashok and Belegundu / Prentice Hall.
- 2. The Finite Element Methods in Engineering / SS Rao / Pergamon.
- 3. The Finite Element Method for Engineers Kenneth H. Huebner, Donald L. Dewhirst, Douglas E. Smith and Ted G. Byrom / John Wiley & sons (ASIA) Pte Ltd.

REFERENCES:

- 1. An introduction to Finite Element Method / JN Reddy / Me Graw Hill
- 2. Finite Element Methods/ Alavala/TMH
- 3. Finite Element Analysis/ C.S.Krishna Murthy

Finite Element Analysis

By S. Shailesh Babu

L

4

T/P/D

0

С

4

UNIT I

INTRODUCTION: The finite element analysis is a numerical technique. In this method all the complexities of the problems, like varying shape, boundary conditions and loads are maintained as they are but the solutions obtained are approximate. The fast improvements in computer hardware technology and slashing of cost of computers have boosted this method, since the computer is the basic need for the application of this method. A number of popular brand of finite element analysis packages are now available commercially Some of the popular packages are STAAD-PRO, GT-STRUDEL, NASTRAN, NISA and ANSYS. Using these packages one can analyze several complex structures.

The finite element analysis originated as a method of stress analysis in the design of aircrafts. It started as an extension of matrix method of structural analysis. Today this method is used not only for the analysis in solid mechanics, but even in the analysis of fluid flow, heat transfer, electric and magnetic fields and many others. Civil engineers use this method extensively for the analysis of beams, space frames, plates, shells, folded plates, foundations, rock mechanics problems and seepage analysis of fluid through porous media. Both static and dynamic problems can be handled by finite element analysis. This method is used extensively for the analysis and design of ships, aircrafts, space crafts, electric motors and heat engines

The **basic unknowns** or the **Field variables** which are encountered in the engineering problems are displacements in solid mechanics, velocities in fluid mechanics, electric and magnetic potentials in electrical engineering and temperatures in heat flow problems In a continuum, these unknowns are infinite. The finite element procedure reduces such unknowns to a finite number by dividing the solution region into small parts called elements and by expressing the unknown field variables in terms of assumed **approximating functions** (Interpolating functions/Shape functions) within each element. The approximating functions are defined in terms of field variables of specified points called **nodes** or **nodal points**. Thus in the finite element analysis the unknowns are the field variables of the nodal points. Once these are found the field variables at any point can be found by using interpolation functions. After selecting elements and nodal unknowns next step in finite element analysis is to assemble **element properties** for each element. For example, in solid mechanics, we have to find the force-displacement i.e. stiffness characteristics of each individual element. Mathematically this relationship is of the form

$[k]e \{\delta\}e = \{F\}e$

where [k]e is element stiffness matrix, $\{\delta\}e$ is nodal displacement vector of the element and $\{F\}e$ is nodal force vector. The element of stiffness matrix *kij* represent the force in coordinate direction '*i*' due to a unit displacement in coordinate direction '*j*'. Four methods are available for formulating these element properties

viz. direct approach, variational approach, weighted residual approach and energy balance approach. Any one of these methods can be used for assembling element properties. In solid mechanics variational approach is commonly employed to assemble stiffness matrix and nodal force vector (consistant loads). Element properties are used to assemble global properties/structure properties to get system equations [k] $\{u\} = \{F\}$. Then the boundary conditions are imposed. The solution of these simultaneous equations give the nodal unknowns. Using these nodal values additional calculations are made to get the required values e.g. stresses, strains, moments, etc. in solid mechanics problems.

Thus the various steps involved in the finite element analysis are:

- (i) Select suitable field variables and the elements.
- (ii) Discritise the continua.
- (iii) Select interpolation functions.
- (iv) Find the element properties.
- (v) Assemble element properties to get global properties.
- (vi) Impose the boundary conditions.
- (vii) Solve the system equations to get the nodal unknowns.
- (viii) Make the additional calculations to get the required values.

Methods of Engineering Analysis

There are three methods are adopted for analyzing the product

- 1.Experimental methods
- 2. Analytical methods

Numerical methods

Experimental methods

In these methods the actual products or their proto type models or atleast their material specimen are tested by using some equipments

Ex: UTM, Rockwell hardness tester

Analytical methods

These methods are theoretically analyzing methods. Only simple and regular shaped products like beams, shafts, plates can be analyzed by these methods

Numerical methods

For the products of complicated sizes and shapes with complicated material properties and boundary conditions getting solution using analytical methods is highly difficult. In such situation the numerical method can be employed

There are three numerical methods

i)Functional approximating methods

ii) Finite element method

iii) Finite difference method

Application of FEM

S.No	Area of Study	Analysing problem			
1	Civil Engineering structures	Analysis of trusses, folded plates, shell roofs, bridges and			
		prestressed concrete structures			
2	Aircraft structures	Analysis of aircraft wings, fins, rockets, space craft and			
		missile structures			
3	Mechanical Design	Stress analysis of pressure vessels, pistons, composite			
		materials,Linkages and gears			
4	Heat Conduction	Temperature distribution in solida and fluids			
5	Hydraulic and water resources	Analysis of potential flows, free suface fkows, viscous			
	Engineering	flows, analysis of hydraulic structures and dams			
6	Electrical Machines and	Analysis of synchronous and induction machines eddy current			
	Electromagnetic	and core losses in electric machines			
7	Nuclear Engineering	Analysis of nuclear pressure vessels and containment			
		structures			
8	Geomechanics	Stress analysis in soils, dams, layered piles and machine			
		foundations			

Advantages and disadvantages of FEM

Advantages

Using FEM we are able to

1.model irregular shaped bodies quite easily

2.handle general load conditions without difficulty

3.model bodies composed of several different materials because the element equations are evaluated individually

- 4. handle unlimited numbers and kinds of boundary conditions
- 5. vary the size of the element to make it possible to use small elements
- 6. alter the finite element model easily and cheaply
- 7. include dynamic effects

Disadvantages

- 1. The finite element method is time consuming process
- 2. FEM cannot produce exact results as those of analytical methods

Equations of Equilibrium for 3D Body

Typical three dimensional element of size $dx \times dy \times dz$. Face *abcd* may be called as negative face of *x* and the face *efgh* as the positive face of *x* since the *x* value for face *abcd* is less than that for the face *efgh*. Similarly the face *aehd* is negative face of *y* and *bfgc* is positive face of *y*. Negative and positive faces of *z* are *dhgc* and *aefb*. The direct stresses σ and shearing stresses τ acting on the negative faces are shown in the Fig. with suitable subscript. It may be noted that the first subscript of shearing stress is the plane and the second subscript is the direction. Thus the τxy means shearing stress on the plane where *x* value is constant and *y* is the direction.



Face	Stress on –ve Face	Stresses on +ve Face
x	σ_{r}	$\sigma_x^+ = \sigma_x + \frac{\partial \sigma_x}{\partial x} dx$
	τ _{xy}	$\tau_{xy}^{+} = \tau_{xy} + \frac{\partial \tau_{xy}}{\partial x} dx$
	T _{xr}	$\tau_{xx}^+ = \tau_{xx} + \frac{\partial \tau_{xx}}{\partial x} dx$
у	σ_y	$\sigma_y^+ = \sigma_y + \frac{\partial \sigma_y}{\partial y} dy$
	r _{jx}	$\tau_{yx}^{+} = \tau_{yx} + \frac{\partial \tau_{yx}}{\partial y} dy$
	τ _{yz}	$\tau_{yz}^{+} = \tau_{yz} + \frac{\partial \tau_{yz}}{\partial y} dy$
Z	σ.	$\sigma_z^+ = \sigma_z + \frac{\partial \sigma_z}{\partial z} dz$
	τ _m	$\tau_{zx}^{+} = \tau_{zx} + \frac{\partial \tau_{zx}}{\partial z} dz$
	τ _φ ,	$\tau_{zy}^{+} = \tau_{zy} + \frac{\partial \tau_{zy}}{\partial z} dz$

Let the intensity of body forces acting on the element in x, y, z directions be X, Y and Z respectively as shown in Fig The intensity of body forces are uniform over entire body. Hence the total body force in x, y, z direction on the element shown are given by

(i) X dx dy dz in x – direction

(ii) Y dx dy dz in y – direction and

(iii) Z dx dy dz in z – direction

Equations of Equilibrium

Considering all forces are acting we can write the equilibrium equations for the element

$$\sum F_x = 0$$

$$\sigma_x^+ dy \, dz - \sigma_x \, dy \, dz + \tau_{yx}^+ dx \, dz - \tau_{yx} \, dx \, dz + \tau_{zx}^+ dx \, dy - \tau_{zx} \, dx \, dy + X \, dx \, dy \, dz = 0$$

i.e.
$$\left(\sigma_x + \frac{\partial \sigma_x}{\partial x} dx\right) dy \, dz - \sigma_x \, dy \, dz + \left(\tau_{yx} + \frac{\partial \tau_{yx}}{\partial y} \, dy\right) dx \, dz - \tau_{yx} \, dx \, dz$$

$$+ \left(\tau_{zx} + \frac{\partial \tau_{zx}}{\partial z} \, dz\right) dy \, dx - \tau_{zx} \, dx \, dy + X \, dx \, dy \, dz = 0$$

Simplifying and dividing throughout by dx dy dz

$$\frac{\partial \sigma_x}{\partial x} + \frac{\partial \tau_{yx}}{\partial y} + \frac{\partial \tau_{zx}}{\partial z} + X = 0$$

Similarly $\Sigma F_y=0$ and $\Sigma F_z=0$ Equilibrium conditions give

$$\frac{\partial \tau_{xy}}{\partial x} + \frac{\partial \sigma_y}{\partial y} + \frac{\partial \tau_{zy}}{\partial z} + Y = 0$$
$$\frac{\partial \tau_{xz}}{\partial x} + \frac{\partial \tau_{yz}}{\partial y} + \frac{\partial \sigma_z}{\partial z} + Z = 0$$

 $\Sigma M_x=0$

$$\tau_{yz}^{+} dx dz \frac{dy}{2} + \tau_{yz} dx dz \frac{dy}{2} - \left[\tau_{zy}^{+} dx dz \frac{dy}{2} + \tau_{zy} dx dz \frac{dy}{2}\right] = 0$$

1.e. $\left(\tau_{y\pi} + \frac{\partial \tau_{yz}}{\partial y} dy\right) dx dy \frac{dz}{2} + \tau_{y\pi} dx dy \frac{dz}{2} - \left[\left(\tau_{zy} + \frac{\partial \tau_{yz}}{\partial z} dz\right) dx dy \frac{dz}{2} + \tau_{zy} dx dz \frac{dz}{2}\right] = 0$

Neglecting small quantity then $\tau_{zy}{=}\,\tau_{yz}$

 $\Sigma M_{y}\!\!=\!\!0$ then we will get $\tau_{xz}\!\!=\!\tau_{zx}$

 $\Sigma M_{Z}=0 \text{ then we will get}$ $\tau_{xy} = \tau_{yx}$ $[\sigma]^{T} = [\sigma_{x} \sigma_{y} \sigma_{z} \tau_{xy} \tau_{yz} \tau_{xz}]$

and the equilibrium equations are

$$\frac{\partial \sigma_x}{\partial x} + \frac{\partial \tau_{xy}}{\partial y} + \frac{\partial \tau_{xz}}{\partial z} + X = 0$$
$$\frac{\partial \tau_{xy}}{\partial x} + \frac{\partial \sigma_y}{\partial y} + \frac{\partial \tau_{yz}}{\partial z} + Y = 0$$
$$\frac{\partial \tau_{xz}}{\partial x} + \frac{\partial \tau_{yz}}{\partial y} + \frac{\partial \sigma_z}{\partial z} + Z = 0$$

 $\tau_{xy} = \tau_{yx}, \ \tau_{yz} = \tau_{zy}$ and $\tau_{xz} = \tau_{zx}$

Strain Displacement equations

Taking displacement components in x, y ,z directions as u, v, and w respectively, the relations among components of strain and the components of displacement are

$$\begin{split} \varepsilon_{x} &= \frac{\partial u}{\partial x} + \frac{1}{2} \left[\left(\frac{\partial u}{\partial x} \right)^{2} + \left(\frac{\partial v}{\partial x} \right)^{2} + \left(\frac{\partial w}{\partial x} \right)^{2} \right] \\ \varepsilon_{y} &= \frac{\partial v}{\partial y} + \frac{1}{2} \left[\left(\frac{\partial u}{\partial y} \right)^{2} + \left(\frac{\partial v}{\partial y} \right)^{2} + \left(\frac{\partial w}{\partial y} \right)^{2} \right] \\ \varepsilon_{z} &= \frac{\partial w}{\partial z} + \frac{1}{2} \left[\left(\frac{\partial u}{\partial z} \right)^{2} + \left(\frac{\partial v}{\partial z} \right)^{2} + \left(\frac{\partial w}{\partial z} \right)^{2} \right] \\ \gamma_{xy} &= \frac{\partial v}{\partial x} + \frac{\partial u}{\partial y} + \frac{\partial u}{\partial x} \cdot \frac{\partial u}{\partial y} + \frac{\partial v}{\partial x} \cdot \frac{\partial v}{\partial y} + \frac{\partial w}{\partial x} \cdot \frac{\partial w}{\partial y} \\ \gamma_{yz} &= \frac{\partial w}{\partial y} + \frac{\partial v}{\partial z} + \frac{\partial u}{\partial y} \cdot \frac{\partial u}{\partial z} + \frac{\partial v}{\partial y} \cdot \frac{\partial v}{\partial z} + \frac{\partial w}{\partial y} \cdot \frac{\partial w}{\partial z} \\ \gamma_{xz} &= \frac{\partial u}{\partial z} + \frac{\partial w}{\partial x} + \frac{\partial u}{\partial x} \cdot \frac{\partial u}{\partial z} + \frac{\partial v}{\partial x} \cdot \frac{\partial v}{\partial z} + \frac{\partial w}{\partial x} \cdot \frac{\partial w}{\partial z} \end{split}$$

strains are expressed up to the accuracy of second order (quadratic) changes in displacements. These equations may be simplified to the first (linear) order accuracy only by dropping the second order changes terms. Then linear strain – displacement relation is given by:

$$\varepsilon_{x} = \frac{\partial u}{\partial x} \qquad \gamma_{xy} = \frac{\partial u}{\partial x} + \frac{\partial v}{\partial y}$$
$$\varepsilon_{y} = \frac{\partial v}{\partial y} \qquad \gamma_{yz} = \frac{\partial w}{\partial y} + \frac{\partial v}{\partial z}$$
$$\varepsilon_{z} = \frac{\partial w}{\partial z} \qquad \gamma_{xz} = \frac{\partial w}{\partial x} + \frac{\partial u}{\partial z}$$

LINEAR CONSTITUTIVE EQUATIONS

The constitutive law expresses the relationship among stresses and strains. In theory of elasticity, usually it is considered as linear. In one dimensional stress analysis, the linear constitutive law is stress is proportional to strain and the constant of proportionality is called Young's modulus. It is very well known as Hooke's law.

The similar relation is expressed among the six components of stresses and strains and is called 'Generalized Hookes Law". This may be stated as:

$\sigma_{\rm x}$	D_{11}	D_{12}	D_{13}	D_{14}	D_{15}	D16	$\left[\varepsilon_{x} \right]$
σ_y	D_{21}	D_{22}	D_{23}	D_{24}	D_{25}	D_{26}	ε_y
σ_z	D_{31}	D_{32}	D_{33}	D_{34}	D_{35}	D36	ε_z
τ_{xy}	D_{41}	D_{42}	D_{43}	D_{44}	D_{45}	D46	γ _{xy}
τ_{yz}	D_{51}	D_{52}	D_{53}	D_{54}	D_{55}	D ₅₆	γ_{yz}
τ_{xz}	D_{61}	D_{62}	D_{63}	D_{64}	D_{65}	D_{66}	γ _{xz}]

 $\{\sigma\} = [D] \{\varepsilon\},\$

where *D* is 6×6 matrix of constants of elasticity to be determined by experimental investigations for each material. As *D* is symmetric matrix [*Dij* = *Dji*], there are 21 material properties for linear elastic **Anisotropic Materials**. Certain materials exhibit symmetry with respect to planes within the body. Such materials are called **Ortho tropic materials**. Hence for orthotropic materials, the number of material constants reduce to 9 as shown below:

$$\begin{vmatrix} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{xz} \end{vmatrix} = \begin{cases} D_{11} & D_{12} & D_{13} & 0 & 0 & 0 \\ D_{22} & D_{23} & 0 & 0 & 0 \\ D_{33} & 0 & 0 & 0 \\ Sym & D_{44} & 0 & 0 \\ D_{55} & 0 \\ D_{55} & 0 \\ D_{66} \end{cases} \begin{vmatrix} \varepsilon_x \\ \varepsilon_y \\ \varepsilon_z \\ \gamma_{xy} \\ \gamma_{yz} \\ \gamma_{xz} \end{vmatrix}$$

Using the Young's Modulii and Poisons ratio terms the above relation may be expressed as:

$$\begin{split} \varepsilon_x &= \frac{\sigma_x}{E_x} - \mu_{yx} \frac{\sigma_y}{E_y} - \mu_{zx} \frac{\sigma_z}{E_z} \\ \varepsilon_y &= -\mu_{xy} \frac{\sigma_x}{E_x} + \frac{\sigma_y}{E_y} - \mu_{zy} \frac{\sigma_z}{E_z} \\ \varepsilon_z &= -\mu_{xz} \frac{\sigma_x}{E_x} - \mu_{yz} \frac{\sigma_y}{E_y} + \frac{\sigma_z}{E_z} \\ \gamma_{xy} &= \frac{\tau_{xy}}{G_{xy}}, \ \gamma_{yz} &= \frac{\tau_{yz}}{G_{yz}}, \ \gamma_{zx} &= \frac{\tau_{zx}}{G_{zx}} \end{split}$$

Note that there are 12 material properties in above equations However only nine of these are independent because the following relations exist

$$\frac{E_x}{\mu_{xy}} = \frac{E_y}{\mu_{yx}}, \quad \frac{E_y}{\mu_{yz}} = \frac{E_z}{\mu_{zy}}, \quad \frac{E_z}{\mu_{zx}} = \frac{E_x}{\mu_{xz}}$$

For **Isotropic Materials** the above set of equations are further simplified. An isotropic material is the one that has same material property in all directions. In other word for isotropic materials,

$$\begin{split} E_{_{X}} &= E_{_{y}} = E_{_{z}} \, \text{say} \, E \, \text{and} \\ \mu_{_{X\!y}} &= \mu_{_{y\!x}} = \mu_{_{y\!z}} = \mu_{_{z\!y}} = \mu_{_{x\!z}} = \mu_{_{z\!x}} \quad \text{say} \, \mu \end{split}$$

Hence for a three dimensional problem, the strain stress relation for isotropic material is,

$$\begin{bmatrix} \varepsilon_{\chi} \\ \varepsilon_{y} \\ \varepsilon_{z} \\ \varepsilon_{z} \\ \gamma_{xy} \\ \gamma_{yz} \\ \gamma_{yz} \\ \gamma_{xz} \end{bmatrix} = \begin{bmatrix} \frac{1}{E} & -\frac{\mu}{E} & -\frac{\mu}{E} & 0 & 0 & 0 \\ & \frac{1}{E} & -\frac{\mu}{E} & 0 & 0 & 0 \\ & \frac{1}{E} & 0 & 0 & 0 \\ & & \frac{1-\mu}{2} & 0 & 0 \\ & & & \frac{1-\mu}{2} & 0 \\ & & & \frac{1-\mu}{2} \end{bmatrix} \begin{bmatrix} \sigma_{\chi} \\ \sigma_{y} \\ \sigma_{z} \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{xz} \end{bmatrix}$$

Since $G = \frac{E}{2(1-\mu)}$ and stress – strain relation is

$$\begin{vmatrix} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{xz} \end{vmatrix} = \frac{E}{(1+\mu)(1-2\mu)} \begin{cases} 1-\mu & \mu & \mu & 0 & 0 & 0 \\ 1-\mu & \mu & 0 & 0 & 0 \\ & 1-\mu & 0 & 0 & 0 \\ & & \frac{1-2\mu}{2} & 0 & 0 \\ & & & \frac{1-2\mu}{2} & 0 \\ & & & & \frac{1-2\mu}{2} \\ & & & & \frac{1-2\mu}{2} \\ & & & & \frac{1-2\mu}{2} \\ & & & & & \frac{1-2\mu}{2} \\ \end{vmatrix} \, \left. \begin{array}{c} \varepsilon_x \\ \varepsilon_y \\ \varepsilon_z \\ \gamma_{xy} \\ \gamma_{xz} \\ \gamma_{xz} \\ \gamma_{xz} \\ \end{array} \right| \, .$$

PLANE STRESS PROBLEM

The thin plates subject to forces in their plane only, fall under this category of the problems. Fig. shows a typical plane stress problem. In this, there is



no force in the z-direction and no variation of any forces in z-direction. Hence

$$\sigma_z = \tau_{xz} = \tau_{yz} = 0$$

The conditions $\tau_{xz} = \tau_{yz} = 0$ give $\gamma_{xz} = \gamma_{yz} = 0$ and the condition $\sigma_z = 0$ gives,

$$\sigma_z = \mu \varepsilon_x + \mu \varepsilon_y + (1 - \mu) \varepsilon_z = 0$$

4

i.e.

$$\varepsilon_{z} = -\frac{\mu}{1-\mu} \left(\varepsilon_{x} + \varepsilon_{y} \right)$$

-

If this is substituted in equation 2.13 the constitutive law reduces to

$$\begin{cases} \sigma_x \\ \sigma_y \\ \tau_{xy} \end{cases} = \frac{E}{1-\mu^2} \begin{vmatrix} 1 & \mu & 0 \\ \mu & 1 & 0 \\ 0 & 0 & \frac{1-\mu}{2} \end{vmatrix} \begin{cases} \varepsilon_x \\ \varepsilon_y \\ \gamma_{xy} \end{cases}$$

PLANE STRAIN PROBLEM

A long body subject to significant lateral forces but very little longitudinal forces falls under this category of problems. Examples of such problems are pipes, long strip footings, retaining walls, gravity dams, tunnels, etc. In these problems, except for a small distance at the ends, state of stress is represented by any small longitudinal strip. The displacement in longitudinal direction (z-direction) is zero in typical strip. Hence the strain components,





Fig. 2.7 (contd)

 $\varepsilon_{z} = \gamma_{xz} = \gamma_{yz} = 0$ $\gamma_{xz} = \gamma_{yz} = 0 \text{ means } \tau_{xz} \text{ and } \tau_{yz} \text{ are zero.}$ $\varepsilon_{z} = 0 \text{ means}$ $\varepsilon_{z} = \frac{\sigma_{z}}{E} - \mu \frac{(\sigma_{x} + \sigma_{y})}{E} = 0$ $\sigma_{z} = \mu (\sigma_{x} + \sigma_{y})$

i.e.

Hence equation 2.13 when applied to plane strains problems reduces to

$$\begin{cases} \sigma_x \\ \sigma_y \\ \tau_{xy} \end{cases} = \frac{E}{(1+\mu)(1-2\mu)} \begin{pmatrix} 1-\mu & \mu & 0 \\ \mu & 1-\mu & 0 \\ 0 & 0 & \frac{1-2\mu}{2} \end{pmatrix} \begin{cases} \varepsilon_x \\ \varepsilon_y \\ \gamma_{xy} \end{cases}$$

Functional Approximation Methods

The nature of the problems for which the solutions to be found out are

i) Equilibrium problems

ii)Eigen value problems

iii)probagation problems

The functional approximation methods for solving the above types of problems are classified in to major types

i) Variational methods

ii)Weighted residual methods

Rayleigh-Ritz method is good example for variational method

Weighted residual method

- Point collocation method
- sub domain collocation method
- Least square method
- Galerkin's method

Rayleigh-Ritz Method

Rayleigh -Ritz method is a typical variational method in which principle of integral approach is adopted for solving the complex structural problems

i) Minimum potential energy method

ii)Integral approach method

Minimum potential energy method

In this method the total potential energy ' Π ' is considered as the function of generalized coordinated which are exactly equal to the number of degrees of freedom

 $\Pi = U \text{-} W$

U=Internal energy

W=work done by the external force

Polynomial series

 $y(x)=a_1+a_2x+a_3x^2+\cdots$

a₁, a₂, a₃..... are Ritz parameters

Integral approach method

Differential equation is

$$D \frac{d2y}{dx^2} + Q = 0$$

$$I\int_0^l [D/2(dy/dx)\mathbf{2} - Qy] dx$$

ONE DIMENSIONAL PROBLEMS

Bar and beam elements are considered as One Dimensional elements. These elements are often used to model trusses and frame structures

Types of Loading i) **Body force (f)**

It is a distributed force acting on every elemental volume of the body. Unit is Force / Unit volume. Ex: Self weight due to gravity.

ii) Traction (T)

It is a distributed force acting on the surface of the body. Unit is Force / Unit area. But for one dimensional problem, unit is Force / Unit length. Ex: Frictional resistance, viscous drag and Surface shear.

iii) Point load (P)

It is a force acting at a particular point which causes displacement.

Finite Element Modeling

It has two processes. (1) Discretization of structure (2) Numbering of nodes.



CO – ORDINATES

(A) Global co-ordinates, (B) Local co-ordinates and (C) Natural co-ordinates.

• Equation of Stiffness Matrix for One dimensional bar element

$$[\mathbf{K}] = \frac{AE}{l} \begin{bmatrix} 1 & -1 \\ -1 & 1 \end{bmatrix}$$

For a stepped bar loaded as shown in figure.Determine a) Nodal displacements

b) support Reactions c)Element Sress



Solution



Element 1	Element 2	Element 3
$A_1 = 15 \text{ cm}^2$	$A_2 = 15 \text{ cm}^2$	$A_3 = 24 \text{ cm}^2$
$E_1 = 20 \text{ X } 10^6 \text{ N/cm}^2$	$E_2 = 20 \text{ X } 10^6 \text{ N/cm}^2$	$E_3 = 20 \text{ X } 10^6 \text{ N/cm}^2$
$L_1 = 75 \text{ cm}$	$L_2 = 75 \text{ cm}$	$L_3 = 60 \text{ cm}$
$\alpha_1 = 11 \text{ X } 10^{-6} \text{ cm/cm}^0\text{C}$	$\alpha_2 = 11 \text{ X } 10^{-6} \text{ cm/cm}^{\circ}\text{C}$	$\alpha_{3} = 11 \text{ X } 10^{-6} \text{ cm/cm}^{0}\text{C}$
$\Delta T = 10^{0} C$	$\Delta T = 10^{0} C$	$\Delta T = 10^{0} C$

 $F_{0(1)} = A_1 E_1 \alpha_1 \Delta T = 33000 N$

 $F_{0(2)}=A_2 E_2 \alpha_2 \Delta T=33000 N$

 $F_{0(3)} = A_3 E_3 \alpha_3 \Delta T = 52800 N$

The Nodal Forces are

 $F_1 = R_1 + P - F_{0(1)} = R_1 - 33000$

 $F_2 = P_2 + F_{0(1)} - F_{0(2)} = 10000$

 $F_3 = P_3 + F_{0(2)} - F_{0(3)} = -39800$

 $F_4 = R_4 + P_3 + F_{0(2)} - F_{0(3)} = R_4 + 52800$

The stiffness values are

 $k_1 = A_1 E_1 / L_1 = 4 X 10^6 N/cm$

 $k_2 = A_2 E_2 / L_2 = 4 X 10^6 N/cm$

k₃=A₃E₃/L₃=8X 10⁶ N/cm

the nodal conditions are $u_1=0$ and $u_4=0$

$$10^{6} \begin{bmatrix} 4 & -4 & 0 & 0 \\ -4 & 8 & -4 & 0 \\ 0 & -4 & 12 & -8 \\ 0 & 0 & -8 & 8 \end{bmatrix} \begin{bmatrix} 0 \\ u_{2} \\ u_{3} \\ 0 \end{bmatrix} = \begin{bmatrix} R_{1} - 33,000 \\ 10,000 \\ -39,800 \\ R_{4} + 52800 \end{bmatrix}$$

solve the above matrix then you will get the values of u_2 and u_3 as - 3.48 X 10⁻³ cm and as - 0.49 X 10⁻¹ cm R_1 = 34960 N

 $R_4 = -24960 N$

$$\sigma_{r(1)} = \sigma_{0(1)} = -\mathfrak{B}_{30,7 \text{ N/cm}}^{-2}$$

$$\sigma_{r(2)} = \sigma_{0(2)} = \mathfrak{B}_{99,7,3 \text{ N/cm}}^{-2}$$

$$\sigma_{r(3)} = \sigma_{0(3)} = -\mathfrak{G}_{00,7 \text{ N/cm}}^{-2}$$

UNIT II

Two Dimensional Trusses

Figure shows a typical plane truss. The truss may be statically determinate or indeterminate. In the analysis all joints are assumed pin connected and all loads act at joints only. These assumptions result into no bending of any member. All members are subjected to only direct stresses-tensile or compressive. Now we are interested to see the finite element analysis procedure for such trusses



Step 1: Field Variables and Elements

Joint displacements are selected as basic field variables. Since there is no bending of the members, we have to ensure only displacement continuity (Co-continuity) and there is no need to worry about slope continuity (C1continuity). Hence we select two noded bar elements for the analysis of trusses. Since the members are subjected to only axial forces, the displacements are only in the axial directions of the members. Therefore the nodal variable vector for the typical bar element shown in Fig

$$\left\{\boldsymbol{\delta}'\right\} = \begin{cases} \boldsymbol{\delta}'_1\\ \boldsymbol{\delta}'_2 \end{cases}$$

where δ '1, δ '2 are in the axial directions of the element. But the axial direction is not same for all members. If we select *x*-*y* as global coordinate system, there are two displacement components at every node. Hence the nodal variable vector for a typical element is,



From the Figure it is clear that

 $\delta_1' = \delta_1 \cos\theta + \delta_2 \sin\theta$ $\delta_2' = \delta_3 \cos\theta + \delta_4 \sin\theta$

If *l* and *m* are the direction cosines,

$$l = \cos\theta, m = \sin\theta,$$

$$\therefore \ \delta'_1 = l\delta_1 + m\delta_2$$

$$\delta'_2 = l\delta_3 + m\delta_4$$

$$\{\delta'\} = \begin{cases} \delta'_1 \\ \delta'_2 \end{cases} = \begin{bmatrix} l & m & 0 & 0 \\ 0 & 0 & l & m \end{bmatrix} \begin{cases} \delta_1 \\ \delta_2 \\ \delta_3 \\ \delta_4 \end{cases}$$

i.e.
$$\{\delta'\} = [L]\{\delta\}$$

where
$$\begin{bmatrix} L \end{bmatrix} = \begin{bmatrix} l & m & 0 & 0 \\ 0 & 0 & l & m \end{bmatrix}$$

and [L] is called transformation (or rotation) matrix. If the coordinates (x_1, y_1) and (x_2, y_2) of node 1 and 2 of the elements are known, we can find

$$l = \frac{x_2 - x_1}{l_e}, m = \frac{y_2 - y_1}{l_e}$$
$$l_e = \sqrt{(x_2 - x_1)^2 + (y_2 - y_1)^2}$$

where

i.e.

Step 2: Discritising

A member may be taken as an element conveniently. Hence in the typical truss considered. There are

- (a) 4 top chord members
- (b) 4 bottom chord members
- (c) 5-vertical members and
- (d) 8 diagonal members
- :. Total elements selected are -21

There are 10 nodal points and they are numbered as shown in Fig.



Fig. Numbering nodes and members

The numbering is such that the band width is minimum. In this case maximum difference in the node numbers of an element is in diagonal members and is equal to 3. The degree of freedom of each node is 2, one in x-direction and another in y-direction. Hence the maximum band width

$$= (3 + 1) \times 2 = 8$$

Total degrees of freedom is

= Total number of nodes
$$\times$$
 degree of freedom of each node
= $10 \times 2 = 20$

Step 3: Interpolation Functions Since bar element is used,

$$\{u\} = [N] \{\delta'\}$$
$$[N] = [N_1 \quad N_2] = \left[\frac{x_2' - x'}{l} \quad \frac{x' - x_1'}{l}\right] = \left[\frac{1 - \xi'}{2} \quad \frac{1 + \xi'}{2}\right]$$

where

Step 4: Element Properties

(a) Stiffness Matrix: In the analysis of bars and columns, we have seen the element stiffness matrix is

$$\begin{bmatrix} k \end{bmatrix}_e = \frac{EA}{l} \begin{bmatrix} 1 & -1 \\ -1 & 1 \end{bmatrix}$$

when viewed in local coordinate system, the truss is also a one dimensional two noded bar element. Hence the element stiffness matrix of truss element in local coordinate system, $[k']_e$ is given by

$$\begin{bmatrix} k' \end{bmatrix}_{e} = \frac{EA}{l_{e}} \begin{bmatrix} 1 & -1 \\ -1 & 1 \end{bmatrix}$$

$$\therefore \quad U_{e} = \frac{1}{2} \left\{ \delta' \right\}^{T} \begin{bmatrix} k' \end{bmatrix} \left\{ \delta' \right\}$$

$$\left\{ \delta' \right\} = \begin{bmatrix} L \end{bmatrix} \left\{ \delta \right\}$$

$$\therefore U_e = \frac{1}{2} ([L] \{\delta\})^T [k'] [L] \{\delta\}$$
$$= \frac{1}{2} \{\delta\}^T [L]^T [k'] [L] \{\delta\} = \frac{1}{2} \{\delta\}^T [k_e] \{\delta\}$$
$$[k]_e = [L]^T [k'] [L]$$

where

and it may be called as element stiffness matrix in global coordinate system.

$$\therefore \begin{bmatrix} k \end{bmatrix}_{e} = \begin{bmatrix} l & 0 \\ m & 0 \\ 0 & l \\ 0 & m \end{bmatrix} \frac{E_{e} A_{e}}{l_{e}} \begin{bmatrix} 1 & -1 \\ -1 & 1 \end{bmatrix} \begin{bmatrix} l & m & 0 & 0 \\ 0 & 0 & l & m \end{bmatrix}$$

$$= \frac{E_e A_e}{l_e} \begin{bmatrix} l & 0 \\ m & 0 \\ 0 & l \\ 0 & m \end{bmatrix} \begin{bmatrix} l & m & -l & -m \\ -l & -m & l & m \end{bmatrix} = \frac{E_e A_e}{l_e} \begin{bmatrix} l^2 & lm & -l^2 & -lm \\ lm & m^2 & -lm & -m^2 \\ -l^2 & -lm & l^2 & lm \\ -lm & -m^2 & lm & m^2 \end{bmatrix}$$

Step 6: Boundary Conditions

If hand calculations are made usually elimination approach is used and if computers are used penalty approach is used for imposing boundary conditions. The method is exactly same as explained in the analysis of columns and tension members.

Step 7: Solution of Simultaneous Equations

This step is also same as explained in the analysis of tension bars and columns.

Step 8: Additional Calculations

Analysts are interested in finding stresses and forces in the members of the truss.

Finite Elements for 2-D Problems

General Formula for the Stiffness Matrix

Displacements (u, v) in a plane element are interpolated from nodal displacements (u_i, v_i) using shape functions Ni as follows,

$$\begin{cases} u \\ v \end{cases} = \begin{bmatrix} N_1 & 0 & N_2 & 0 & \cdots \\ 0 & N_1 & 0 & N_2 & \cdots \end{bmatrix} \begin{vmatrix} u_1 \\ v_1 \\ u_2 \\ v_2 \\ \vdots \end{vmatrix}$$
 or $\mathbf{u} = \mathbf{N}\mathbf{d}$

where N is the shape function matrix, u the displacement vector and d the nodal displacement vector. Here we have assumed that u depends on the nodal values of u only, and v on nodal values of v only. Most commonly employed 2-D elements are linear or quadratic triangles and quadrilaterals.

Constant Strain Triangle (CST or T3)

This is the simplest 2-D element, which is also called *linear triangular element*.



For this element, we have three nodes at the vertices of the triangle, which are numbered around the element in the counter clockwise direction. Each node has two degrees of freedom (can move in the x and y directions). The displacements u and v are assumed to be linear functions within the element, that is,

$$u = b_1 + b_2 x + b_3 y, \quad v = b_4 + b_5 x + b_6 y$$

where b_i (i = 1, 2, ..., 6) are constants. From these, the strains are found to be, $\varepsilon_x = b_2$, $\varepsilon_y = b_6$, $\gamma_{xy} = b_3 + b_5$ which are constant throughout the element.

The shape functions (linear functions in x and y) are

$$N_{1} = \frac{1}{2A} \{ (x_{2}y_{3} - x_{3}y_{2}) + (y_{2} - y_{3})x + (x_{3} - x_{2})y \}$$
$$N_{2} = \frac{1}{2A} \{ (x_{3}y_{1} - x_{1}y_{3}) + (y_{3} - y_{1})x + (x_{1} - x_{3})y \}$$
$$N_{3} = \frac{1}{2A} \{ (x_{1}y_{2} - x_{2}y_{1}) + (y_{1} - y_{2})x + (x_{2} - x_{1})y \}$$

and

$$A = \frac{1}{2} \det \begin{bmatrix} 1 & x_1 & y_1 \\ 1 & x_2 & y_2 \\ 1 & x_1 & y_2 \end{bmatrix}$$
 is the area of the triangle.

The displacements should satisfy the following six equations,

$$u_{1} = b_{1} + b_{2}x_{1} + b_{3}y_{1}$$
$$u_{2} = b_{1} + b_{2}x_{2} + b_{3}y_{2}$$
$$\vdots$$
$$v_{3} = b_{4} + b_{5}x_{3} + b_{6}y_{3}$$

Solving these equations, we can find the coefficients *b1*, *b2*, ..., and *b6 in terms of nodal displacements and coordinates*.

The displacements can be expressed as

$$\begin{cases} u \\ v \end{cases} = \begin{bmatrix} N_1 & 0 & N_2 & 0 & N_3 & 0 \\ 0 & N_1 & 0 & N_2 & 0 & N_3 \end{bmatrix} \begin{bmatrix} u_1 \\ v_1 \\ u_2 \\ v_2 \\ u_3 \\ v_3 \end{bmatrix}$$

The strain-displacement relations are written as

$$\begin{cases} \boldsymbol{\varepsilon}_{x} \\ \boldsymbol{\varepsilon}_{y} \\ \boldsymbol{\gamma}_{xy} \end{cases} = \mathbf{B}\mathbf{d} = \frac{1}{2A} \begin{bmatrix} y_{23} & 0 & y_{31} & 0 & y_{12} & 0 \\ 0 & x_{32} & 0 & x_{13} & 0 & x_{21} \\ x_{32} & y_{23} & x_{13} & y_{31} & x_{21} & y_{12} \end{bmatrix} \begin{bmatrix} u_{1} \\ v_{1} \\ u_{2} \\ v_{2} \\ u_{3} \\ v_{3} \end{bmatrix}$$

where xij = xi - xj and yij = yi - yj (*i*, j = 1, 2, 3). Again, we see constant strains within the element. From stress-strain relation, we see that stresses obtained using the CST element are also constant.

The element stiffness matrix for the CST element,

$$\mathbf{k} = \int_{V} \mathbf{B}^{T} \mathbf{E} \mathbf{B} \, dV = t \mathcal{A}(\mathbf{B}^{T} \mathbf{E} \mathbf{B})$$

in which t is the thickness of the element. Notice that \mathbf{k} for CST is a 6 by 6 symmetric matrix.

The Natural Coordinates



We introduce the *natural coordinates* (ξ,η) on the triangle, then *the shape functions* can be represented simply by,

$$N_1 = \xi, \quad N_2 = \eta, \quad N_3 = 1 - \xi - \eta$$

Notice that,

$$N_1 + N_2 + N_3 = 1$$

which ensures that the rigid body translation is represented by the chosen shape functions. Also, as in the 1-D case,

$$N_i = \begin{cases} 1, & \text{at node i;} \\ 0, & \text{at the other nodes} \end{cases}$$

and varies linearly within the element.

The plot for shape function N1 is shown in the following figure. N2 and N3 have similar features. =-0



We have two coordinate systems for the element: the global coordinates (x, y) and the natural coordinates (ξ, η) . The relation between the two is given by

$$x = N_1 x_1 + N_2 x_2 + N_3 x_3$$

$$y = N_1 y_1 + N_2 y_2 + N_3 y_3$$

$$x = x_{13} \xi + x_{23} \eta + x_3$$

$$y = y_{13} \xi + y_{23} \eta + y_3$$

where xij = xi - xj and yij = yi - yj (i, j = 1, 2, 3) as defined earlier.

Displacement u or v on the element can be viewed as functions of (x, y) or (ξ, η) .

Using the chain rule for derivatives, we have,

$$\begin{cases} \frac{\partial u}{\partial \xi} \\ \frac{\partial u}{\partial \eta} \end{cases} = \begin{bmatrix} \frac{\partial x}{\partial \xi} & \frac{\partial y}{\partial \xi} \\ \frac{\partial x}{\partial \eta} & \frac{\partial y}{\partial \eta} \end{bmatrix} \begin{bmatrix} \frac{\partial u}{\partial x} \\ \frac{\partial u}{\partial y} \end{bmatrix} = \mathbf{J} \begin{cases} \frac{\partial u}{\partial x} \\ \frac{\partial u}{\partial y} \\ \frac{\partial u}{\partial y} \end{cases}$$

where J is called the Jacobian matrix of the transformation, and is expressed as

$$\mathbf{J} = \begin{bmatrix} x_{13} & y_{13} \\ x_{23} & y_{23} \end{bmatrix}, \qquad \mathbf{J}^{-1} = \frac{1}{2A} \begin{bmatrix} y_{23} & -y_{13} \\ -x_{23} & x_{13} \end{bmatrix}$$

where det $\mathbf{J} = x_{13}y_{23} - x_{23}y_{13} = 2A$ and A is the area of the triangular element.

$$\begin{cases} \frac{\partial u}{\partial x} \\ \frac{\partial u}{\partial y} \end{cases} = \frac{1}{2A} \begin{bmatrix} y_{23} & -y_{13} \\ -x_{23} & x_{13} \end{bmatrix} \begin{cases} \frac{\partial u}{\partial \xi} \\ \frac{\partial u}{\partial \eta} \end{cases} = \frac{1}{2A} \begin{bmatrix} y_{23} & -y_{13} \\ -x_{23} & x_{13} \end{bmatrix} \begin{bmatrix} u_1 - u_3 \\ u_2 - u_3 \end{bmatrix}$$

Similarly,

$$\begin{cases} \frac{\partial v}{\partial x} \\ \frac{\partial v}{\partial y} \end{cases} = \frac{1}{2A} \begin{bmatrix} y_{23} & -y_{13} \\ -x_{23} & x_{13} \end{bmatrix} \begin{cases} v_1 - v_3 \\ v_2 - v_3 \end{cases}$$

Using the relations $\varepsilon = \mathbf{D}\mathbf{u} = \mathbf{D}\mathbf{N}\mathbf{d} = \mathbf{B}\mathbf{d}$, we obtain the strain-displacement matrix,

$$\mathbf{B} = \frac{1}{2A} \begin{bmatrix} y_{23} & 0 & y_{31} & 0 & y_{12} & 0 \\ 0 & x_{32} & 0 & x_{13} & 0 & x_{21} \\ x_{32} & y_{23} & x_{13} & y_{31} & x_{21} & y_{12} \end{bmatrix}$$

Applications of the CST Element:

· Use in areas where the strain gradient is small.

· Use in mesh transition areas (fine mesh to coarse mesh).

 $\cdot\,$ Avoid using CST in stress concentration or other crucial areas in the structure, such as edges of holes and corners.

· Recommended for quick and preliminary FE analysis of

2-D problems.

Linear Strain Triangle (LST or T6)

This element is also called quadratic triangular element.



There are six nodes on this element: three corner nodes and three mid-side nodes. Each node has two degrees of freedom (DOF) as before. The displacements (u, v) are assumed to be quadratic functions of (x, y),

$$u = b_1 + b_2 x + b_3 y + b_4 x^2 + b_5 xy + b_6 y^2$$

$$v = b_7 + b_8 x + b_9 y + b_{10} x^2 + b_{11} xy + b_{12} y^2$$

where *bi* (*i* = 1, 2, ..., 12) are constants.

The strains are found to be,

$$\varepsilon_{x} = b_{2} + 2b_{4}x + b_{5}y$$

$$\varepsilon_{y} = b_{9} + b_{11}x + 2b_{12}y$$

$$\gamma_{xy} = (b_{3} + b_{8}) + (b_{5} + 2b_{10})x + (2b_{6} + b_{11})y$$

which are linear functions. Thus, we have the "linear strain triangle" (LST), which provides better results than the CST.

In the natural coordinate system we defined earlier, the six shape functions for the LST element are,

$$N_{1} = \xi(2\xi - 1)$$

$$N_{2} = \eta(2\eta - 1)$$

$$N_{3} = \zeta(2\zeta - 1)$$

$$N_{4} = 4\xi \eta$$

$$N_{5} = 4\eta \zeta$$

$$N_{6} = 4\zeta \xi$$

in which $\zeta = 1 - \xi - \eta$

Each of these six shape functions represents a quadratic form on the element as shown in the following figure.



Displacements can be written as,

$$u = \sum_{i=1}^{6} N_i u_i, \qquad \qquad v = \sum_{i=1}^{6} N_i v_i$$

Linear Quadrilateral Element (Q4)



There are four nodes at the corners of the quadrilateral shape. In the natural coordinate system (ξ,η) , the four shape functions are,

$$N_{1} = \frac{1}{4}(1-\xi)(1-\eta), \qquad N_{2} = \frac{1}{4}(1+\xi)(1-\eta)$$
$$N_{3} = \frac{1}{4}(1+\xi)(1+\eta), \qquad N_{4} = \frac{1}{4}(1-\xi)(1+\eta)$$

 $\sum_{i=1}^{4} N_{i} = 1 \quad \text{at any point inside the element.}$

The displacement field is given by

$$u = \sum_{i=1}^{4} N_i u_i, \qquad v = \sum_{i=1}^{4} N_i v_i$$

which are bilinear functions over the element.

Quadratic Quadrilateral Element (Q8)

This is the most widely used element for 2-D problems due to its high accuracy in analysis and flexibility in modeling.



There are eight nodes for this element, four corners nodes and four mid-side nodes.

In the natural coordinate system (ξ,η) the eight shape functions are,

$$N_{1} = \frac{1}{4}(1-\xi)(\eta-1)(\xi+\eta+1) \qquad N_{5} = \frac{1}{2}(1-\eta)(1-\xi^{2})$$

$$N_{2} = \frac{1}{4}(1+\xi)(\eta-1)(\eta-\xi+1) \qquad N_{6} = \frac{1}{2}(1+\xi)(1-\eta^{2})$$

$$N_{3} = \frac{1}{4}(1+\xi)(1+\eta)(\xi+\eta-1) \qquad N_{7} = \frac{1}{2}(1+\eta)(1-\xi^{2})$$

$$N_{4} = \frac{1}{4}(\xi-1)(\eta+1)(\xi-\eta+1) \qquad N_{8} = \frac{1}{2}(1-\xi)(1-\eta^{2})$$

Again, we have $\sum_{i=1}^{8} N_i = 1$ at any point inside the element.

The displacement field is given by

$$u = \sum_{i=1}^{\$} N_i u_i, \qquad v = \sum_{i=1}^{\$} N_i v_i$$

which are quadratic functions over the element. Strains and stresses over a quadratic quadrilateral element are quadratic functions, which are better representations.

Stress Calculation

The stress in an element is determined by the following relation,

$$\begin{cases} \boldsymbol{\sigma}_{x} \\ \boldsymbol{\sigma}_{y} \\ \boldsymbol{\tau}_{xy} \end{cases} = \mathbf{E} \begin{cases} \boldsymbol{\varepsilon}_{x} \\ \boldsymbol{\varepsilon}_{y} \\ \boldsymbol{\gamma}_{xy} \end{cases} = \mathbf{E} \mathbf{B} \mathbf{d}$$

where **B** is the strain-nodal displacement matrix and **d** is the nodal displacement vector which is known for each element once the global FE equation has been solved.

Stresses can be evaluated at any point inside the element (such as the center) or at the nodes. Contour plots are usually used in FEA software packages (during post-process) for users to visually inspect the stress results.

The von Mises Stress:

The von Mises stress is the *effective or equivalent stress for* 2-D and 3-D stress analysis.

$$\sigma_{e} = \frac{1}{\sqrt{2}} \sqrt{(\sigma_{1} - \sigma_{2})^{2} + (\sigma_{2} - \sigma_{3})^{2} + (\sigma_{3} - \sigma_{1})^{2}}$$

in which σ_1, σ_2 and σ_3 and are the three principle stresses at the considered point in a structure.

For 2-D problems, the two principle stresses in the plane are determined by

$$\sigma_1^{P} = \frac{\sigma_x + \sigma_y}{2} + \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$
$$\sigma_2^{P} = \frac{\sigma_x + \sigma_y}{2} - \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$

Thus, we can also express the von Mises stress in terms of the stress components in the *xy coordinate system*.

For plane stress conditions, we have,

$$\sigma_e = \sqrt{(\sigma_x + \sigma_y)^2 - 3(\sigma_x \sigma_y - \tau_{xy}^2)}$$

UNIT III

Elasticity Equations

Elasticity equations are used for solving structural mechanics problems. These equations must be satisfied if an exact solution to a structural mechanics problem is to be obtained. The types of elasticity equations are

1. Strian – Displacement relationship equations

$$e_{x} = \frac{\partial u}{\partial x}; \ e_{y} = \frac{\partial v}{\partial y}; \ \gamma_{xy} = \frac{\partial u}{\partial y} + \frac{\partial v}{\partial x}; \ \gamma_{xz} = \frac{\partial u}{\partial z} + \frac{\partial w}{\partial x};$$
$$\gamma_{yz} = \frac{\partial v}{\partial z} + \frac{\partial w}{\partial y}.$$

ex-Strain in X direction, ey-Strain in Y direction.

 $\gamma_{\rm xy}$ - Shear Strain in XY plane, $\gamma_{\rm xz}$ - Shear Strain in XZ plane,

 γ_{yz} - Shear Strain in YZ plane

2. Sterss – Strain relationship equation

$$\begin{cases} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{zx} \end{cases} = \frac{E}{(1+\nu)(1-2\nu)} \begin{bmatrix} (1-\nu) & \nu & \nu & 0 & 0 & 0 \\ \nu & (1-\nu) & \nu & 0 & 0 & 0 \\ \nu & \nu & (1-\nu) & 0 & 0 & 0 \\ 0 & 0 & 0 & \frac{1-2\nu}{2} & 0 & 0 \\ 0 & 0 & 0 & 0 & \frac{1-2\nu}{2} & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{1-2\nu}{2} \end{bmatrix} \begin{bmatrix} e_x \\ e_x \\ e_x \\ \gamma_{yz} \\ \gamma_{yz} \\ \gamma_{zx} \end{bmatrix}$$
σ – Stress, τ – Shear Stress, E – Young's Modulus, v – Poisson's Ratio, e – Strain, γ - Shear Strain.

3. Equilibrium equations

$$\frac{\partial \sigma_x}{\partial x} + \frac{\partial \tau_{xy}}{\partial y} + \frac{\partial \tau_{xz}}{\partial z} + B_x = 0; \quad \frac{\partial \sigma_y}{\partial y} + \frac{\partial \tau_{yz}}{\partial z} + \frac{\partial \tau_{xy}}{\partial x} + B_y = 0$$
$$\frac{\partial \sigma_z}{\partial z} + \frac{\partial \tau_{xz}}{\partial x} + \frac{\partial \tau_{yz}}{\partial y} + B_z = 0$$

- σ Stress, τ Shear Stress, B_x Body force at X direction,
- B_y Body force at Y direction, B_z Body force at Z direction.

4. Compatibility equations

There are six independent compatibility equations, one of which is

$$\frac{\partial^2 e_x}{\partial y^2} + \frac{\partial^2 e_y}{\partial x^2} = \frac{\partial^2 \gamma_{xy}}{\partial x \partial y}.$$

Most of the three dimensional problems are symmetry about an axis of rotation. Those types of problems are solved by a special two dimensional element called as xisymmetric element.



> Axisymmetric Formulation

The displacement vector u is given by

$$u(r,z) = \begin{cases} u \\ w \end{cases}$$

The stress σ is given by

$$Strain, \{e\} = \begin{cases} e_r \\ e_\theta \\ e_z \\ \gamma_{rz} \end{cases} \begin{cases} \sigma_r \\ \sigma_\theta \\ \sigma_z \\ \tau_{rz} \end{cases}$$

The strain e is given by

Equation of shape function for Axisymmetric element

Shape function,

$$N_{1} = \frac{\alpha_{1} + \beta_{1}r + \gamma_{1}z}{2A}; N_{2} = \frac{\alpha_{2} + \beta_{2}r + \gamma_{2}z}{2A}; N_{3} = \frac{\alpha_{3} + \beta_{3}r + \gamma_{3}z}{2A}$$

$$\alpha_{1} = r_{2}z_{3} - r_{3}z_{2}; \qquad \alpha_{2} = r_{3}z_{1} - r_{1}z_{3}; \qquad \alpha_{3} = r_{1}z_{2} - r_{2}z_{1}$$

$$\beta_{1} = z_{2} - z_{3}; \qquad \beta_{2} = z_{3} - z_{1}; \qquad \beta_{3} = z_{1} - z_{2}$$

$$\gamma_{1} = r_{3} - r_{2}; \qquad \gamma_{2} = r_{1} - r_{3}; \qquad \gamma_{3} = r_{2} - r_{1}$$

$$2A = (r_{2}z_{3} - r_{3}z_{2}) - r_{1}(r_{3}z_{1} - r_{1}z_{3}) + z_{1}(r_{1}z_{2} - r_{2}z_{1})$$

1

> Equation of Strain – Displacement Matrix [B] for Axisymmetric element

$$\begin{bmatrix} B \end{bmatrix} = \frac{1}{2A} \begin{bmatrix} \beta_1 & 0 & \beta_2 & 0 & \beta_3 & 0 \\ \frac{\alpha_1}{r} + \beta_1 + \frac{\gamma_1 z}{r} & 0 & \frac{\alpha_2}{r} + \beta_2 + \frac{\gamma_2 z}{r} & 0 & \frac{\alpha_3}{r} + \beta_3 + \frac{\gamma_3 z}{r} & 0 \\ 0 & \gamma_1 & 0 & \gamma_2 & 0 & \gamma_3 \\ \gamma_1 & \beta_1 & \gamma_2 & \beta_2 & \gamma_3 & \beta_3 \end{bmatrix} \begin{bmatrix} u_1 \\ w_1 \\ u_2 \\ u_2 \\ u_3 \\ w_3 \end{bmatrix}$$

$$r = \frac{r1 + r2 + r3}{3}$$

> Equation of Stress – Strain Matrix [D] for Axisymmetric element

$$[D] = \frac{E}{(1+\nu)(1-2\nu)} \begin{bmatrix} 1-\nu & \nu & \nu & 0\\ \nu & 1-\nu & \nu & 0\\ \nu & \nu & 1-\nu & 0\\ 0 & 0 & 0 & \frac{1-2\nu}{2} \end{bmatrix}$$

> Equation of Stiffness Matrix [K] for Axisymmetric element

$$[K] = 2 \prod r A[B]^{T} [D][B]$$
$$r = \frac{r1 + r2 + r3}{3}; A = (\frac{1}{2}) bxh$$

> Temperature Effects

The thermal force vector is given by $\{f\}_t = 2 \prod rA[B][D]\{e\}_t$

$$\{f\}_{t} = \begin{cases} F_{1}u \\ F_{1}w \\ F_{2}u \\ F_{2}w \\ F_{3}u \\ F_{3}w \end{cases}$$

> Problem (I set) 1. For the given element, determine the stiffness matrix. Take E=200GPa and v= 0.25. 2.



> 2. For the figure, determine the element stresses. Take E=2.1x105N/mm2 and v=0.25. The co – ordinates are in mm. The nodal displacements are u1=0.05mm, w1=0.03mm, u2=0.02mm, w2=0.02mm, u3=0.0mm, w3=0.0mm.



3. A long hollow cylinder of inside diameter 100mm and outside diameter 140mm is subjected to an internal pressure of 4N/mm2.
 By using two elements on the 15mm length, calculate the displacements at the inner radius.

> Isoparametric element

Generally it is very difficult to represent the curved boundaries by straight edge elements. A large number of elements may be used to obtain reasonable resemblance between original body and the assemblage. In order to overcome this drawback, isoparametric elements are used.



If the number of nodes used for defining the geometry is same as number of nodes used defining the displacements, then it is known as isoparametric element.

> Superparametric element

If the number of nodes used for defining the geometry is more than number of nodes used for defining the displacements, then it is known as superparametric element.



> Subparametric element

If the number of nodes used for defining the geometry is less than number of nodes used for defining the displacements, then it is known as subparametric element.



> Equation of Shape function for 4 noded rectangular parent element

$$u = \begin{cases} x \\ y \end{cases} = \begin{bmatrix} N_1 & 0 & N_2 & 0 & N_3 & 0 & N_4 & 0 \\ 0 & N_1 & 0 & N_2 & 0 & N_3 & 0 & N_4 \end{bmatrix} \begin{cases} x_1 \\ y_2 \\ x_1 \\ y_2 \\ x_3 \\ y_3 \\ x_4 \\ y_4 \end{cases}$$

 $N_1=1/4(1-\epsilon)(1-\eta); N_2=1/4(1+\epsilon)(1-\eta); N_3=1/4(1+\epsilon)(1+\eta); N_4=1/4(1-\epsilon)(1+\eta).$

> Equation of Stiffness Matrix for 4 noded isoparametric quadrilateral element

$$\begin{split} [K] = \iota_{-1}^{1} \prod_{i=1}^{1} [B]^{T} [D] [B] J [\partial \vartheta \eta \\ \\ [J] = \begin{bmatrix} J_{11} & J_{12} \\ J_{21} & J_{22} \end{bmatrix}; \\ J_{11} = \frac{1}{4} [-(1-\eta)x_{1} + (1-\eta)x_{2} + (1+\eta)x_{3} - (1+\eta)x_{4}]; \\ J_{12} = \frac{1}{4} [-(1-\eta)y_{1} + (1-\eta)y_{2} + (1+\eta)y_{3} - (1+\eta)y_{4}]; \\ J_{21} = \frac{1}{4} [-(1-\varepsilon)x_{1} - (1+\varepsilon)x_{2} + (1+\varepsilon)x_{3} + (1-\varepsilon)x_{4}]; \\ J_{22} = \frac{1}{4} [-(1-\varepsilon)y_{1} - (1+\varepsilon)y_{2} + (1+\varepsilon)y_{3} + (1-\varepsilon)y_{4}]; \\ J_{22} = \frac{1}{4} [-(1-\varepsilon)y_{1} - (1+\varepsilon)y_{2} + (1+\varepsilon)y_{3} + (1-\varepsilon)y_{4}]; \\ \end{bmatrix} \\ \begin{bmatrix} B \\ = \frac{1}{|J|} \begin{bmatrix} J_{22} & -J_{12} & 0 & 0 \\ 0 & 0 & -J_{21} & J_{11} \\ -J_{21} & J_{11} & J_{22} & -J_{12} \end{bmatrix} \begin{bmatrix} \frac{\partial N_{1}}{\partial \varepsilon} & 0 & \frac{\partial N_{2}}{\partial \varepsilon} & 0 & \frac{\partial N_{3}}{\partial \varepsilon} & 0 & \frac{\partial N_{4}}{\partial \varepsilon} & 0 \\ 0 & \frac{\partial N_{1}}{\partial \eta} & 0 & \frac{\partial N_{2}}{\partial \eta} & 0 & \frac{\partial N_{3}}{\partial \varepsilon} & 0 & \frac{\partial N_{4}}{\partial \varepsilon} \\ 0 & \frac{\partial N_{1}}{\partial \eta} & 0 & \frac{\partial N_{2}}{\partial \eta} & 0 & \frac{\partial N_{3}}{\partial \varepsilon} & 0 & \frac{\partial N_{4}}{\partial \varepsilon} \\ 0 & \frac{\partial N_{1}}{\partial \eta} & 0 & \frac{\partial N_{2}}{\partial \eta} & 0 & \frac{\partial N_{3}}{\partial \varepsilon} & 0 & \frac{\partial N_{4}}{\partial \varepsilon} \\ 0 & \frac{\partial N_{1}}{\partial \eta} & 0 & \frac{\partial N_{2}}{\partial \eta} & 0 & \frac{\partial N_{3}}{\partial \varepsilon} & 0 & \frac{\partial N_{4}}{\partial \varepsilon} \\ 0 & \frac{\partial N_{1}}{\partial \eta} & 0 & \frac{\partial N_{2}}{\partial \eta} & 0 & \frac{\partial N_{3}}{\partial \varepsilon} & 0 & \frac{\partial N_{4}}{\partial \varepsilon} \\ 0 & \frac{\partial N_{1}}{\partial \eta} & 0 & \frac{\partial N_{2}}{\partial \eta} & 0 & \frac{\partial N_{3}}{\partial \eta} & 0 & \frac{\partial N_{4}}{\partial \varepsilon} \\ \end{bmatrix} \end{bmatrix}$$

$$[D] = \frac{E}{(1-v^2)} \begin{bmatrix} 1-v & v & 0\\ v & 1 & 0\\ 0 & 0 & \frac{1-v}{2} \end{bmatrix}, \text{ for plane stress conditions;}$$
$$[D] = \frac{E}{(1+v)(1-2v)} \begin{bmatrix} 1-v & v & 0\\ v & 1-v & 0\\ 0 & 0 & \frac{1-2v}{2} \end{bmatrix}, \text{ for plane strain conditions.}$$

> Equation of element force vector

$$\left\{F\right\}_{e} = \left[N\right]^{T} \left\{\begin{matrix}F_{x}\\F_{y}\end{matrix}\right\};$$

N – Shape function, F_x – load or force along x direction, F_y – load or force along y direction.

> Numerical Integration (Gaussian Quadrature)

The Gauss quadrature is one of the numerical integration methods to calculate the definite integrals. In FEA, this Gauss quadrature method is mostly preferred. In this method the numerical integration is achieved by the following expression,

$$\int_{-1}^{1} f(x) dx = \sum_{i=1}^{n} w_i f(x_i)$$

Number of	Location	Corresponding Weights
Points	x_i	w _i
n		
1	$x_1 = 0.000$	2.000
2	$\mathbf{x_{1, x_{2}}} = \pm \sqrt{\frac{1}{3}} = \pm 0.577350269189$	1.000
3	$\mathbf{x_{1}, x_{3} = \pm \sqrt{\frac{3}{5}} = \pm 0.774596669241}$ $\mathbf{x_{2}=0.000}$	$\frac{5}{9} = 0.555555$ $\frac{8}{9} = 0.8888888$
4	$x_1, x_4 = \pm 0.8611363116$ $x_2, x_3 = \pm 0.3399810436$	0.3478548451 0.6521451549

Table gives gauss points for integration from -1 to 1.

> Problem (I set) 1. Evaluate, $I = \int_{-1}^{1} \cos \frac{\pi x}{2} dx$, by applying 3 point Gaussian quadrature and compare with exact solution.

2. Evaluate, $I = \int_{1}^{1} \left[3e^x + x^2 + \frac{1}{x+2} \right] dx$ using one point and two point Gaussian quadrature. Compare

3. For the isoparametric quadrilateral element shown in figure, determine the local co –ordinates of the point P which has Cartesian co- ordinates (7, 4).



4. A four noded rectangular element is in figure. Determine (i) Jacobian matrix, (ii) Strain – Displacement matrix and (iii) Element

Stresses. Take E=2x105N/mm2, v=0.25, u=[0,0,0.003,0.004,0.006, 0.004,0,0] T, E=0, $\eta=0$. Assume plane stress condition.



UNIT IV

One could obtain the global stiffness matrix of a continuous beam from assembling member stiffness matrix of individual beam elements. Towards this end, we break the given beam into a number of beam elements. The stiffness matrix of each individual beam element can be written very easily. For example, consider a continuous beam ABCD as shown in Fig. 1a. The given continuous beam is divided into three beam elements as shown in Fig. 1b. It is noticed that, in this case, nodes are located at the supports. Thus each span is treated as an individual beam. However sometimes it is required to consider a node between support points. This is done whenever the cross sectional area changes suddenly or if it is required to calculate vertical or rotational displacements at an intermediate point. Such a division is shown in Fig. 1c. If the axial deformations are neglected then each node of the beam will have two degrees of freedom: a vertical displacement (corresponding to shear) and a rotation (corresponding to bending moment). In Fig. 1b, numbers enclosed in a circle represents beam numbers. The beam ABCD is divided into three beam members. Hence, there are four nodes and eight degrees of freedom. The possible displacement degrees of freedom of the beam are also shown in the figure. Let us use lower numbers to denote unknown degrees of freedom (unconstrained degrees of freedom) and higher numbers to denote known (constrained) degrees of freedom. Such a method of identification is adopted in this course for the ease of imposing boundary conditions directly on the structure stiffness matrix. However, one could number sequentially as shown in Fig. 1d. This is preferred while solving the problem on a computer.



Fig. 27.1b Member and node numbering



Fig 27.1d Member and node numbering

In the above figures, single headed arrows are used to indicate translational and double headed arrows are used to indicate rotational degrees of freedom.

Beam Stiffness Matrix:

Fig. 2 shows a prismatic beam of a constant cross section that is fully restrained at ends in local orthogonal coordinate system x' y' z'. The beam ends are denoted by nodes j and k. The x' axis coincides with the centroidal axis of the member with the positive sense being defined from j to k. Let L be the length of the member, A area of cross section of the member and I_{zz} is the moment of inertia about z'axis.



Two degrees of freedom (one translation and one rotation) are considered at each end of the member. Hence, there are four possible degrees of freedom for this member and hence the resulting stiffness matrix is of the order 4 X 4. In this method counterclockwise moments and counterclockwise rotations are taken as positive. The positive sense of the translation and rotation are also shown in the figure. Displacements are considered as positive in the direction of the co- ordinate axis. The elements of the stiffness matrix indicate the forces exerted on the member by the restraints at the ends of the member when unit displacements are imposed at each end of the member. Let us calculate the forces developed in the above beam member when unit displacement is imposed along each degree of freedom holding all other displacements to zero. Now impose a unit displacement along y' axis at j end of the member while holding all other displacements to zero as shown in Fig.a. This displacement causes both shear and moment in the beam. The restraint actions are also shown in the figure. By definition they are elements of the member stiffness matrix. In particular they form the first column of element stiffness matrix.

In Fig.b, the unit rotation in the positive sense is imposed at j end of the beam while holding all other displacements to zero. The restraint actions are shown in the figure. The restraint actions at ends are calculated referring to tables given in lesson ...





In Fig. 3c, unit displacement along y' axis at end k is imposed and corresponding restraint actions are calculated. Similarly in Fig.d, unit rotation about z' axis at end k is imposed and corresponding stiffness coefficients are calculated. Hence the member stiffness matrix for the beam member is

$$[k] = \begin{bmatrix} \frac{12 EI_z}{L^3} & \frac{6 EI_z}{L^2} & -\frac{12 EI_z}{L^3} & \frac{6 EI_z}{L^2} \\ \frac{6 EI_z}{L^2} & \frac{4 EI_z}{L} & -\frac{6 EI_z}{L^2} & \frac{2 EI_z}{L^2} \\ -\frac{12 EI_z}{L^3} & -\frac{6 EI_z}{L^2} & \frac{12 EI_z}{L^2} & -\frac{6 EI_z}{L^2} \\ \frac{6 EI_z}{L^2} & \frac{2 EI_z}{L} & -\frac{6 EI_z}{L^2} & \frac{4 EI_z}{L} \end{bmatrix} \frac{4}{4}$$

The stiffness matrix is symmetrical. The stiffness matrix is partitioned to separate the actions associated with two ends of the member. For continuous beam problem, if the supports are unyielding, then only rotational degree of freedom shown in Fig. is possible. In such a case the first and the third rows and columns will be deleted. The reduced stiffness matrix will be,

$$\begin{bmatrix} k \end{bmatrix} = \begin{bmatrix} \frac{4EI_z}{L} & \frac{2EI_z}{L} \\ \frac{2EI_z}{L} & \frac{4EI_z}{L} \end{bmatrix}$$



Instead of imposing unit displacement along y' at j end of the member in Fig.a, apply a displacement u'_1 along y' at j end of the member as shown in Fig. a, holding all other displacements to zero. Let the restraining forces developed be denoted by q_{11} , q_{21} , q_{31} and q_{41} .



The forces are equal to,

 $q_{11} = k_{11}u'_1;$ $q_{21} = k_{21}u'_1;$ $q_{31} = k_{31}u'_1;$ $q_{41} = k_{41}u'_1$

Now, give displacements u'_1 , u'_2 , u'_3 and u'_4 simultaneously along displacement degrees of freedom 1, 2, 3 and 4 respectively. Let the restraining forces developed at member ends be q_1 , q_2 , q_3 and q_4 respectively as shown in Fig. b along respective degrees of freedom. Then by the principle of superposition, the force displacement relationship can be written as,

$$\begin{bmatrix} q_{1} \\ q_{2} \\ q_{3} \\ q_{4} \end{bmatrix} = \begin{bmatrix} \frac{12EI_{z}}{L^{3}} & \frac{6EI_{z}}{L^{2}} & -\frac{12EI_{z}}{L^{3}} & \frac{6EI_{z}}{L^{2}} \\ \frac{6EI_{z}}{L^{2}} & \frac{4EI_{z}}{L} & -\frac{6EI_{z}}{L^{2}} & \frac{2EI_{z}}{L} \\ -\frac{12EI_{z}}{L^{3}} & -\frac{6EI_{z}}{L^{2}} & \frac{12EI_{z}}{L^{3}} & -\frac{6EI_{z}}{L^{2}} \\ \frac{6EI_{z}}{L^{2}} & \frac{2EI_{z}}{L} & -\frac{6EI_{z}}{L^{2}} & \frac{4EI_{z}}{L} \end{bmatrix} \begin{bmatrix} u'_{1} \\ u'_{2} \\ u'_{3} \\ u'_{4} \end{bmatrix}$$

This may also be written in compact form as,

 $\{q\} = [k] \{u'\}$

Beam (global) Stiffness Matrix:

The formation of structure (beam) stiffness matrix from its member stiffness matrices is explained with help of two span continuous beams shown in Fig. a. Note that no loading is shown on the beam. The orthogonal co-



ordinate system xyz denotes the global co-ordinate system.

For the case of continuous beam, the x - and x' - axes are collinear and other axes (y and y', z and z') are parallel to each other. Hence it is not required to transform member stiffness matrix from local co-ordinate system to global coordinate system as done in the case of trusses. For obtaining the global stiffness matrix, first assume that all joints are restrained. The node and member numbering for the possible degrees of freedom are



shown in Fig b. The continuous beam is divided into two beam members. For this member there are six possible degrees of freedom. Also in the figure, each beam member with its displacement degrees of freedom (in local co ordinate system) is also shown. Since the continuous beam has the same moment of inertia and span, the member stiffness matrix of element 1 and 2 are the same. They are,

Global d.o.f 1 2 3 4
Local d.o.f 1 2 3 4

$$\begin{bmatrix} k'_{11} & k'_{12} & k'_{13} & k'_{14} \\ k'_{21} & k'_{22} & k'_{23} & k'_{24} \\ k'_{31} & k'_{32} & k'_{33} & k'_{34} \\ k'_{41} & k'_{42} & k'_{43} & k'_{44} \end{bmatrix} 4 1$$

Global d.o.f 3 4 5 6
Local d.o.f 1 2 3 4

$$\begin{bmatrix} k^2 \end{bmatrix} = \begin{bmatrix} k^2_{11} & k^2_{12} & k^2_{13} & k^2_{14} \\ k^2_{21} & k^2_{22} & k^2_{23} & k^2_{24} \\ k^2_{31} & k^2_{32} & k^2_{33} & k^2_{34} \\ k^2_{41} & k^2_{42} & k^2_{43} & k^2_{44} \end{bmatrix} \begin{bmatrix} k^2_{14} & k^2_{14} \\ k^2_{21} & k^2_{22} \\ k^2_{33} & k^2_{34} \\ k^2_{43} & k^2_{44} \end{bmatrix} \begin{bmatrix} k^2_{14} & k^2_{14} \\ k^2_{21} & k^2_{22} \\ k^2_{33} & k^2_{34} \\ k^2_{41} & k^2_{42} \\ k^2_{43} & k^2_{44} \end{bmatrix} \begin{bmatrix} k^2_{14} & k^2_{14} \\ k^2_{22} & k^2_{23} \\ k^2_{33} & k^2_{34} \\ k^2_{44} & k^2_{44} \end{bmatrix} \begin{bmatrix} k^2_{14} & k^2_{14} \\ k$$

The local and the global degrees of freedom are also indicated on the top and side of the element stiffness matrix. This will help us to place the elements of the element stiffness matrix at the appropriate locations of the global stiffness matrix. The continuous beam has six degrees of freedom and hence the stiffness matrix is of the order6. Let [K] denotes the continuous beam stiffness matrix of order 6X6. From Fig., [K] may be written as,



The 4X4 upper left hand section receives contribution from member 1 (AB) and 4X4 lower right hand section of global stiffness matrix receives contribution from member 2. The element of the global stiffness matrix corresponding to global degrees of freedom 3 and 4 receives element from both members 1 and 2.

FORMATION OF LOAD VECTOR:

Consider a continuous beam ABC as shown in Fig.



We have two types of load: member loads and joint loads. Joint loads could be handled very easily as done in case of trusses. Note that stiffness matrix of each member was developed for end loading only. Thus it is required to replace the member loads by equivalent joint loads. The equivalent joint loads must be evaluated such that the displacements produced by them in the beam should be the same as the displacements produced by the actual loading on the beam. This is evaluated by invoking the method of superposition.



(a) Actual beam with loading



(b) Reaction in the restrained beam



(c) Equivalent joint loads

The loading on the beam shown in Fig. (a), is equal to the sum of Fig. (b) and Fig. (c). In Fig. (c), the joints are restrained against displacements and fixed end forces are calculated. In Fig. (c) these fixed end actions are shown in reverse direction on the actual beam without any load. Since the beam in Fig. (b) is restrained (fixed) against any displacement, the displacements produced by the joint loads in Fig. (c) must be equal to the displacement produced by the actual beam in Fig. (a). Thus the loads shown in Fig. (c) are the equivalent joint loads .Let, p_1 , p_2 , p_3 , p_4 , p_5 and p_6 be the equivalent joint loads acting on the continuous beam along displacement degrees of freedom 1,2,3,4,5 and 6 respectively as shown in Fig. (b). Thus the global load vector is,

$$\begin{cases}
P_{1} \\
P_{2} \\
P_{3} \\
P_{4} \\
P_{5} \\
P_{6}
\end{cases} = \begin{cases}
-\frac{Pb}{L} \\
-\frac{Pab^{2}}{L^{2}} \\
-\left(\frac{Pa}{L} + \frac{wL}{2}\right) \\
-\left(\frac{wL^{2}}{12} - \frac{Pba^{2}}{L^{2}}\right) \\
-\left(\frac{wL}{2} + 2P\right) \\
\frac{wL^{2}}{12}
\end{cases}$$

SOLUTION OF EQUILIBRIUM EQUATIONS:

After establishing the global stiffness matrix and load vector of the beam, the load displacement relationship for the beam can be written as

$$\{P\} = [K]\{u\}$$

Where is the global load vector, $\{P\}$ $\{u\}$ is displacement vector and is the global stiffness matrix. In the above equation some joint displacements are known from support conditions. The above equation may be written as

$$\begin{cases} \{p_k\} \\ \{p_u\} \end{cases} = \begin{bmatrix} [k_{11}] & [k_{12}] \\ [k_{21}] & [k_{22}] \end{bmatrix} \begin{cases} \{u_u\} \\ \{u_k\} \end{cases}$$

Where $\{p_k\}$ and $\{u_k\}$ denote respectively vector of known forces and known displacements. And $\{p_k\}$ and $\{u_k\}$ denote respectively vector of unknown forces and unknown displacements respectively. Now expanding equation

$$\{p_k\} = [k_{11}]\{u_u\} + [k_{12}]\{u_k\}$$
$$\{p_u\} = [k_{21}]\{u_u\} + [k_{22}]\{u_k\}$$

Since $\{u_k\}$ is known, the unknown joint displacements can be evaluated. And support reactions are evaluated from equation, after evaluating unknown displacement vector.

Let R_1, R_3 and R_5 be the reactions along the constrained degrees of freedom. Since equivalent joint loads are directly applied at the supports, they also need to be considered while calculating the actual reactions. Thus,

$$\begin{cases} R_1 \\ R_3 \\ R_5 \end{cases} = - \begin{cases} p_1 \\ p_3 \\ p_5 \end{cases} + [K_{21}] \{u_u\}$$

The reactions may be calculated as follows. The reactions of the beam shown in Fig. a are equal to the sum of reactions shown in Fig. b, Fig. c and Fig. d.







(d)

From the method of superposition,

$$R_{1} = \frac{Pb}{L} + K_{14}u_{4} + K_{16}u_{6}$$

$$R_{3} = \frac{Pa}{L} + K_{34}u_{4} + K_{36}u_{6}$$

$$R_{5} = \frac{wL}{2} + 2P + K_{54}u_{4} + K_{56}u_{6}$$

or

Member end actions q_1 , q_2 , q_3 and q_4 are calculated as follows. For example consider the first element 1

$$\begin{cases} q_1 \\ q_2 \\ q_3 \\ q_4 \end{cases} = \begin{cases} \frac{Pb}{L} \\ \frac{Pab^2}{L^2} \\ \frac{Pa}{L} \\ -\frac{Pa^2b}{L^2} \\ -\frac{Pa^2b}{L^2} \end{cases} + \begin{bmatrix} K \end{bmatrix}_{element1} \begin{cases} 0 \\ u_2 \\ 0 \\ u_4 \end{cases}$$

UNIT V

Dynamic analysis

Modal analysis - Natural frequency and mode shapes

- Harmonic analysis Forced response of system to a sinusoidal forcing
- Transient analysis Forced response for non-harmonic loads (impact, step or ramp forcing etc.)

DYNAMIC CONSIDERATIONS

Static analysis holds when the loads are slowly applied. When the loads are suddenly applied, or when the loads are of a variable nature, the mass and acceleration effects come into the picture. If a solid body, such as an engineering structure, is deformed elastically and suddenly released, it tends to vibrate about its equilibrium position. This periodic motion due to the restoring strain energy is called **free vibration**.

The number of cycles per unit time is called **frequency**.

The maximum displacement from the equilibrium position is the **amplitude**.

FORMULATION

We define the Lagrangean by

$$L = T - \Pi$$

where *T* is the kinetic energy and Π is the potential energy.

Hamilton's principle For an arbitrary time interval from t_1 to t_2 , the state of motion of a body extremizes the functional

$$I = \int_{t_1}^{t_2} L \, dt$$

If *L* can be expressed in terms of the generalized variables $(q_1, q_2, ..., q_n, \dot{q}_1, \dot{q}_2, ..., \dot{q}_n)$ where $\dot{q}_i = dq_i/dt$, then the equations of motion are given by

$$\frac{d}{dt} \left(\frac{\partial L}{\partial \dot{q}_i} \right) - \frac{\partial L}{\partial q_i} = 0 \qquad i = 1 \text{ to } n$$

Example

Consider the spring-mass system in Fig.. The kinetic and potential energies are given by

$$T = \frac{1}{2}m_1\dot{x}_1^2 + \frac{1}{2}m_2\dot{x}_2^2$$
$$\Pi = \frac{1}{2}k_1x_1^2 + \frac{1}{2}k_2(x_2 - x_1)^2$$



Using $L = T - \Pi$, we obtain the equations of motion

$$\frac{d}{dt} \left(\frac{\partial L}{\partial \dot{x}_1} \right) - \frac{\partial L}{\partial x_1} = m_1 \ddot{x}_1 + k_1 x_1 - k_2 \left(x_2 - x_1 \right) = 0$$
$$\frac{d}{dt} \left(\frac{\partial L}{\partial \dot{x}_2} \right) - \frac{\partial L}{\partial x_2} = m_2 \ddot{x}_2 + k_2 \left(x_2 - x_1 \right) = 0$$

which can be written in the form

$$\begin{bmatrix} m_1 & 0 \\ 0 & m_2 \end{bmatrix} \begin{bmatrix} \ddot{x}_1 \\ \ddot{x}_2 \end{bmatrix} + \begin{bmatrix} (k_1 + k_2) & -k_2 \\ -k_2 & k_2 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} = 0$$

which is of the form

$$M\ddot{x} + kx = 0$$

where *M* is the mass matrix, *K* is the stiffness matrix, and \mathcal{X} a representing accelerations and displacements.

\ddot{x} and x are vectors

Solid Body with Distributed Mass

Consider a solid body with distributed mass. The kinetic energy is given by



where ρ is the density (mass per unit volume) of the material and

$$\dot{u} = \left[\dot{u}, \dot{v}, \dot{w} \right]^T$$

is the velocity vector of the point at x, with components In the finite element method, we dive the body into elements, and in each element,

we express u in terms of the nodal displacements q, using shape functions N.

u = Nq

In dynamic analysis, the elements of q are dependent on time, while N represents (spatial) shape functions defined on a master element. The velocity vector is then given by

$$\dot{u} = N\dot{q}$$

the kinetic energy Te in element e is

$$T = \frac{1}{2} \dot{q}^{T} \left[\int_{e} \rho N^{T} N \, dV \right] \dot{q}$$

where the bracketed expression is the element mass matrix

$$m^e = \int \rho N^T N \ dV$$

This mass matrix is consistent with the shape functions chosen and is called the consistent mass matrix. On summing over all the elements, we get

$$T = \sum_{e} T_{e} = \sum_{e} \frac{1}{2} \dot{q}^{T} m^{e} \dot{q} = \frac{1}{2} \dot{Q}^{T} M \dot{Q}$$
$$\Pi = \frac{1}{2} Q^{T} K Q - Q^{T} F$$

Using the Lagrangean $L = T - \Pi$, we obtain the equation of motion:

$$M\ddot{Q} + KQ = F$$

For free vibrations the force F is zero. Thus,

$$M\ddot{Q} + KQ = 0$$

For the steady-state conditions, starting from the equilibrium state, we get

$$Q = U \sin \omega t$$

where U is the vector of modal amplitudes of vibration and ω (rad/s) is the circular frequency ($2\pi f$, f = cycles/s or Hz).

$$KU = \omega^2 MU$$

This is the generalized eigen value problem

$$KU = \lambda MU$$

ELEMENT MASS MATRICES

Treating the material density ρ to be constant over the element, we have,

$$m^e = \rho \int_e N^T N \ dV$$

One-dimensional bar element For the bar element

$$N_{1} = \frac{1-\xi}{2} \qquad N_{2} = \frac{1+\xi}{2}$$

$$q^{T} = \begin{bmatrix} q_{1} & q_{2} \end{bmatrix} \qquad m^{e} = \rho \int_{e} N^{T} N A \ dx = \frac{\rho A_{e} \ell_{e}}{2} \int_{-1}^{+1} N^{T} N \ d\xi$$



On carrying out the integration of each term in $N^T N$, we find that

 $m^{e} = \frac{\rho A_{e} \ell_{e}}{6} \begin{bmatrix} 2 & 1\\ 1 & 2 \end{bmatrix}$

Truss element For the truss element

$$u^{T} = \begin{bmatrix} u, v \end{bmatrix}$$

$$q^{T} = \begin{bmatrix} q_{1} & q_{2} & q_{3} & q_{4} \end{bmatrix}$$

$$N = \begin{bmatrix} N_{1} & 0 & N_{2} & 0 \\ 0 & N_{1} & 0 & N_{2} \end{bmatrix}$$

$$N_1 = \frac{1-\xi}{2}$$
 $N_2 = \frac{1+\xi}{2}$

in which $\boldsymbol{\xi}$ is defined from -1 to +1. Then



CST element For the plane stress and plane strain conditions for the CST element

$$u^{T} = \begin{bmatrix} u & v \end{bmatrix}$$

$$q^{T} = \begin{bmatrix} q_{1} & q_{2} & \dots & q_{6} \end{bmatrix}$$

$$N = \begin{bmatrix} N_{1} & 0 & N_{2} & 0 & N_{3} & 0 \\ 0 & N_{1} & 0 & N_{2} & 0 & N_{3} \end{bmatrix}$$

The element mass matrix is then given by

$$m^{e} = \rho t_{e} \int_{e}^{N^{T} N} dA$$

Noting that $\int_{e}^{N^{2}} dA = \frac{1}{6} A_{e}, \int_{e}^{N_{1} N_{2}} dA = \frac{1}{12} A_{e}, \text{ etc., we have}$
$$m^{e} = \frac{\rho t_{e} A_{e}}{12} \begin{bmatrix} 2 & 0 & 1 & 0 & 1 & 0 \\ 2 & 0 & 1 & 0 & 1 & 0 \\ 2 & 0 & 1 & 0 & 1 \\ 2 & 0 & 1 & 0 & 1 \\ 2 & 0 & 1 & 0 & 1 \\ 2 & 0 & 1 & 0 & 1 \\ 3 & 2 & 0 & 1 & 0 \\ 5 & 3 & 3 & 2 & 0 & 1 \\ 5 & 3 & 3 & 3 & 2 \end{bmatrix}$$

Lumped mass matrices Practicing engineers also use lumped mass techniques, where the total element mass in each direction is distributed equally to the nodes of the element, and the masses are associated with translational degrees of freedom only. For the truss element, the lumped mass approach gives a mass matrix of

For the beam element, the lumped element mass matrix is

$$m^{e} = \frac{\rho A_{e} \ell_{e}}{2} \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 \\ 1 & 0 \\ Symmetric & 0 \end{bmatrix}$$

EVALUATION OF EIGENVALUES AND EIGENVECTORS

$$KU = \lambda MU$$

We observe here that *K* and *M* are symmetric matrices. Further, *K* is positive definite for properly constrained problems.

Properties of Eigenvectors

For a positive definite symmetric stiffness matrix of size n, there are n real eigenvalues and corresponding eigenvectors. The eigenvalues may be arranged in ascending order:

$$0 \le \lambda_1 \le \lambda_2 \le \ldots \le \lambda_n$$

If U1, U2...Un are the corresponding eigenvectors, we have

$$KU_i = \lambda_i MU_i$$

The eigenvectors possess the property of being orthogonal with respect to both the stiffness and mass matrices

$$U_i^T K U_j = 0 \qquad if \ i \neq j$$
$$U_i^T M U_j = 0 \qquad if \ i \neq j$$

The lengths of eigenvectors are generally normalized so that

$$U_i^T M U_i = 1$$

The foregoing normalization of the eigenvectors leads to the relation

$$U_i^T K U_i = \lambda_i$$

EIGENVALUE – EIGENVECTOR EVALUATION

The eigenvalue-eigenvector evaluation procedures fall into the following basic categories:

- 1. Characteristic polynomial technique
- 2. Vector iteration methods
- **3**. Transformation methods

Characteristic polynomial

$$(K - \lambda M)U = 0$$

If the eigenvector is to be nontrivial, the required condition is

$$det(K - \lambda M) = 0$$

This represents the characteristic polynomial in λ .

2. Evaluate, $I = \int_{-1}^{1} \left[3e^x + x^2 + \frac{1}{x+2} \right] dx$, using one point and two point Gaussian quadrature. Compare with exact solution.

3. For the isoparametric quadrilateral element shown in figure, determine the local co –ordinates of the point P which has Cartesian coordinates (7, 4).



4. A four noded rectangular element is in figure. Determine (i) Jacobian matrix, (ii) Strain – Displacement matrix and (iii) Element Stresses. Take E=2x105N/mm2, v=0.25, u=[0,0,0.003,0.004,0.006, 0.004,0,0] T, E=0, $\eta=0$. Assume plane stress condition.



MALLAREDDY COLLEGE OF ENGINEERING AND TECHNOLOGY

SUB: FEA

MODEL PAPER 1 PART A

(25 MARKS)

1. a. What is meant by Engineering analysis and specify its Types	(2M)
b. What is Hermite shape function	(3M)
c. Write the equilibrium equations for 3D body	(2M)
d. What is coordinate system. specify the types and explain	(3M)
e. What is meant by axi-symmetric problems	(2M)
f. Derive the shape functions for 2D truss element	(3M)
g. What is the degree of freedom for the thermal problems	(2M)
h. Distinguish between CST and LST	(3M)
i. Write the dynamic equation of motion for the undamped free vibrations	(2M)
j. Determine the Area of the triangle $A(2,2),B(7,4),C(3,6)$	(3M)

PART B

(10X5=50 MARKS)

2. a) Derive the equations of equilibrium in case of a three dimensional stress system.

b) Discuss the advantages and disadvantages of FEM over

(i) Classical method

(ii) Finite difference method.

OR

3.a) Solve the differential equation for the physical problem expressed as $d^2y/dx^2+100=0$ when 0=x=10 with boundary

condition as y(0)=0 and y(10)=0 using i) point collocation ii) sub-domain collocation iii) least square method

iv) galarkin method

b) Write the Strain displacement equations for three dimensional system

4. a) Determine the nodal displacement, Element stresses for axially loaded bar as shown in the fig. below



b) Derive the strain displacement matrices for triangular element of revolving body.

5 a) For the beam shown in Figure below, determine the following: a) Slopes at nodes 2 and 3

b) Vertical deflection at the mid-point of the distributed load. Consider all the elements have E=200GPa, I=5X10⁶ mm⁴



6. a) For the element shown in the figure, assemble Jacobian matrix and strain displacement matrix



b) Determine the shape functions for a 8 node quadratic quadrilateral Evaluation element(boundary noded).

OR

7. a) Establish the shape functions for a 3 - noded triangular element

b) Find the deformed configuration, and the maximum stress and minimum stress locations for the rectangular plate loaded as shown in the fig. Solve the problem using 2 triangular elements. Assume thickness = 10cm; E = 70 Gpa, and v = 0.33



8, The composite wall consists of three materials shown in figure. The inside wall temperature is at 200° C and the outside air temperature is 50° C with a convection coefficient of 10 W/m² ^oC Determine

the temperature along the composite wall



9.a) Derive one dimensional steady state heat conduction equation.

b) An axisymmetric triangular element is subjected to the loading as shown in fig. the load is distributed throughout the circumference and normal to the boundary. Derive all the necessary equations and derive the nodal point loads.



10. a)Determine the strain displacement matrix for the TETRAHEDRAL element as shown in fig



b) Explain the concept of numerical integration and its utility in generating Isoperimetric finite element matrices

11. a) What are the necessary requirements for convergence and explain about h- and p

requirements

b) Derive the stiffness matrix for truss element in case of linear and quadratic shape functions At 20^{0} C an axial load P = 300 x 10^{3} is applied to the rod as shown in Fig. The temperature is then raised to 60^{0} C. Assemble the element stiffness matrix and the element temperature force matrix (F). Again determine the nodal displacements and element stresses. Also find element strains. Assume E₁= 70 x 10^{9} N/m², $_{1}$ = 900 mm², α_{1} = 23 x 10^{-6} / 0 C, E₂ = 200 X 10^{9} N/m², A₂ = 1200mm², α 2= 11.7 x 10^{-6} / 0 C.



MALLAREDDY COLLEGE OF ENGINEERING AND TECHNOLOGY

SUB: FEA MODEL PAPER 2 PART A

(25 MARKS)

1. a. What is FEM	(2M)
b. Write the advantages of FEM	(3M)
c. What is CST	(2M)
d. Write the strain relations of three dimensional system	(3M)
e. What is local coordinate System	(2M)
f. Write the Eigen values and Eigen vectors for a stepped bar	(3M)
g. What is the degree of freedom for the thermal problems	(2M)
h. Define principle of virtual work. Describe the FEM formulation	on for 1D bar element (3M)
i What is dynamic analysis	(2M)

j. Discuss Mess generation(3M)

PART B

(10X5=50 MARKS)

2. a) Differentiate among Bar element, Truss element and Beam element indicating D.O.F and geometry characteristics.

b) An axial load P = $300X10^3$ N is applied at 20^0 C to the rod as shown in Figure below. The temperature is the raised to 60° C a) Assemble the K and F matrices

b) Determine the nodal displacements and stresses



- 3. a) Discuss in detail about the concepts of FEM formulation How is that emerged as powerful tool. Discuss in detail about applications of finite element method
 - b) Derive an equation for finding out the potential energy by Rayleigh –Ritz method Using Rayleigh – Ritz method, find the displacement of the midpoint of the rod shown in Fig. Assume $E = 1, A=1, \rho g=1$ by using linear and quadratic shape function concept


4 a) Discuss in detail about Linear and Quadratic shape functions with examples

b) Consider axial vibration of the Aluminum bar shown in Fig., (i) develop the global stiffness and
(ii) determine the nodal displacements and stresses using elimination approach and with help of linear and quadratic shape function concept. Assume Young's Modulus E = 70Gpa



OR

5. a)Describe Rayleigh-Ritz method

b) Abeam is fixed at one end and supported by roller at the other end has 20KN load applied at the center of the span of 10m.Calculate deflection and slope and also

construct shear fore and bending moment diagrams

6. a) State the properties and applications of CST

b) The nodal coordinates of the triangular element shown in figure at the interior point P.the x coordinate is 3.3 and the shape function at node 1 is N_1 is 0.3.determine the shape functions at nodes 2 and 3 also find the 'y' coordinate of P



OR

- 7. a) Determine the stiffness and Jacobian matrix for the iso parametric quadrilateral element starting from fundamentals.
 - b) Differentiate between axi- symmetric boundary condition and polar symmetric boundary condition.

c) Derive the load vector for the axi-symmetric triangular element with the variable surface load on the surface.

8. a) derive one dimensional steady state heat conduction equation

b)An axi symmetric element subjected to loading as shown in figure .The load is distributed througout the circumference and normal to the boundary. Derive all necessary equations and derive nodal point loads



9. Calculate the conductance matrix [K(e)] and load vector fF(e)g for the triangle element shown in figure 8. The thermal conductivities are kx = ky = 4 W=cm \bigcirc OC and h = 0.3 W/cm2 OC. Thickness of the element is 1cm. All coordinates are given in cms. Convection occurs on the side joining modes i and j.



10. For the stepped bar shown in figure develope the global stiffness matrix and mass matrices and determine the natural frequencies and mode shapes Assume E=200GPa and mass density is 7850 Kg/m³ L₁=L₂=0.3 m A₁=350 mm² and A₂ =600 mm²



OR

11. a)Derive the shape functions for the four noded tetrahedron element from the first principles b)discuss the importance of semi automatic meshing and practical applications

MALLAREDDY COLLEGE OF ENGINEERING AND TECHNOLOGY SUB: FEM MODEL PAPER 3 PART A

(25 MARKS)

1. a. List the various weighted residual methods	(2M)
b. Write the properties of shape function	(3M)
c. What the advantages of natural coordinate system	(2M)
d. Write analogies between structural, heat transfer and fluid mechanics	(3M)
e. Name few FEA packages	(2M)
f. Derive the mass matrix for a 1D linear bar element	(3M)
g. What are the properties of stiffness matrix	(2M)
h. Explain about plain stress and plain strain conditions	(3M)
i. Write down the conduction matrix for a three noded triangular element	(2M)
j. Distinguish between Error in solution and Residual	(3M)

PART B

(10X5=50)

2. a)Determint the nodal displacement ,stress and strain for the bar shown in fig



b) Using potential energy approach, describe FE formulation for plane truss Element

OR

- 3.a) Solve the differential equation for the physical problem expressed as $d^2y/dx^2+100=0$ when 0=x=10 with boundary condition as y(0)=0 and y(10)=0 using i) point collocation ii) subdomain collocation iii) least square method iv) galarkin method.
 - b) Explain the concept of FEM briefly .outline the steps involved in FEM along with applications

4. a)For a beam and loading shown in fig., determine the slopes at 2 and 3 and the vertical deflection at the midpoint of the distributed load



b) Establish the shape functions for a 3 – noded triangular element.

OR

5. Calculate the nodal displacement, stresses and support reactions for the truss shown in figure



6.a) Evaluate the element stiffness matrix for the triangular element shown under plane strain condition. Assume the following values E=200 GPa, $\mu=0.25$, t=1 mm



b) For the element shown in the figure, assemble Jacobian matrix and strain displacement matrix



7. a) Derive the a)shape function and b) strain displacement matrices for triangular element of revolving body

b) For the Isoparametric quadrilateral element shown in fig , determine the local co-ordinates of the point P whose Cartesian co=ordinates as(6,4)



8 a) Determine the temperature at the nodal interfaces for the two layered wall shown in fig.the left face is supplied with heat flux of $Q^{11}=5$ W/cm² and the right face is maintained at 20⁰C



b) Derive the Strain displacement Matrix for 2D-Thin plate. Consider the temperature field with in the triangular element is given by $T = N_1T_1 + N_2T_2 + N_3T_3$

OR

9. Determine the temperature distribution through the composite wall shown in figure, when convection heat loss occurs on the left surface. Assume unit area Assume wall thickness $t_1 = 4$ cm, $t_2 = 2$ cm, $k_1 = 0.5$ w/cm⁰c, $k_2 = 0.05$ w/cm⁰c h= 0.1w/cm² °c and $T_{\alpha} = -5^{\circ}$ c

OR



10. a) Determine the eigen values and the associated Eigen vectors of the matrix [A] given by

$$A = \begin{bmatrix} 3 & 4 \\ 4 & -3 \end{bmatrix}$$

b) State the properties of Eigen Values.

OR

- 11.a) Explain difference between Lumped Mass and Consistent Mass
 - b) Determine the Natural frequency of the beam shown in the figure



MALLAREDDY COLLEGE OF ENGINEERING AND TECHNOLOGY SUB: FEM MODEL PAPER 4 PART A

(25 MARKS)

1. a. Give the limitations of FEM.	(2M)
b. Briefly explain the role of shape function FEM analysis	(3M)
c. Write a short note on numerical integration.	(2M)
d. What do you understand by discritisation of the domain	(3M)
e. What is Jocobian matrix	(2M)
f. Determine the matrix relating strains and nodal displacements for an axisymmetric	
triangular element.	(3M)
g. What is difference between CST and LST	(2M)
h. What are the ways by which a 3D problem can be reduced to a 2D problem	n (3M)
i. Name Few FEA packages	(2M)
j. Derive the convection matrix for a 1D linear bar element	(3M)

PART B

(10X5=50)

2. a) Write down expressions for the element stiffness matrices and element body force vectors

b) Evaluate the stresses in each element Determine the reaction force at the support. consider 1in=1cm for SI UNITS



3.a) Determine the nodal displacement, Element stresses f r axially loaded bar as shown in the fig. below



b) Explain the elimination method and penalty method for imposing specified displacement boundary conditions

4. a) Obtain the forces in the plane Truss shown in Figure below and determine the support reactions also. Take E=200GPa and A=200mm²



b) Derive the Hermite shape functions for beam element.

OR

5.a) Analyze the beam shown in Figure method and determine the end reactions. Also determine the below by finite element deflections at mid spans given $E=2X10^5 N/mm^2$, and $I=5X10^6 mm^4$



b) What are the general features of a bar Element?

6. a) Formulate the finite element equations for Constant strain triangle shown in fig. Assume plane stress E=200Gpa,v=0.25,thickness=5mm,nodal co-ordinates. Pressure on 1-2 edge is 5N/mm2

X1=1	X2=5	X3=3
Y1=2	Y2=4	Y3=6

b) Write the Advantages of iso-parametric elements

7.a) For the configuration shown in figure, determine the deflection at the point load application using a one element model. T = 10 mm , E = 70 G Pa ,v = .3



b) Derive the strain displacement matrix for triangular element.

8. a) The plane wall shown in fig. The thermal conductivity $K = 25 / m^0 C$ and there is a uniform generation of heat in the wall Q = 400 W /m³. Determine the temperature distribution at five nodes (include two sides of the walls) in equal distances through the wall thickness



b) Derive Approximate the first two natural frequencies of a cantilever beam using one element model. EI=Flexural rigidity

9. a) A metallic fin with thermal conductivity $K=360W/m^0c$, 1mm thick and100mm long extends from a plane wall whose temperature is 235^0c . Determine the distribution and amount of heat transferred from the fin to air at 20^0c with $h=9W/m^{20}c$ take width of the fin is 1000 mm. Assume tip is insulted



b) Explain the concept of numerical integration and its utility in generating Isoperimetric finite element matrices

10.a) Determine the strain displacement matrix for the TETRAHEDRAL element as shown in fig



b) Determine the approximate first two natural frequeneves of a simply supported beam using on a element. Flexural Rigidity =EI; Density = P Cross-sectional area=A



11.a) State the method used for obtaining natural frequencies and corresponding eigen vectors.

b) Evaluate natural frequencies for the CANTI LEVER beam shown in fig USING ONE ELEMENT



MALLAREDDY COLLEGE OF ENGINEERING AND TECHNOLOGY

SUB: FEM

MODEL PAPER 5 PART A

(25 MARKS)

1. a. What is the principle of FEM	(2M)
b. Write the stress strain relations for 2D plane stress and pane strain conditions	(3M)
c. Differentiate between truss and beam element based on degree of freedom.	(2M)
d. What is Hermite shape function	(3M)
e. Write the formula for the load vector of triangular element subjected to body	force(2M)
f. What is the size of stiffness matrix for axisymmetric triangular element	(3M)
g. What is the degree of freedom for the thermal problems	(2M)
h. Where do you apply (3M)	
i. Name Few FEA packages	(2M)
j. Explain the importance of lumped mass matrix	(3M)

PART B

10X5=50

2. a)Why polynomial type of interpolation function is preferred over trigonometric functions? Explain

b)Draw the Pascal's triangle and Pascal's tetrahedron for understanding the interpolations functions. Explain the salient features

OR

3. a)Explain the steps involved in obtaining an appropriate solution using AEM

b) Explain the equilibrium state of the system, when the system is subjected to different types of loads and explain the stress and equilibrium relations

4.For a two dimensional structure as shown in figure. determine displacement of the nodes and normal stresses developed in the members using FE. Use $E = 39x \ 106 \text{ N/cm2}$ and the diameter of the cross-section of 0.25 cm.



5. A beam is fixed at one end and supported by a roller at the other end, has a 20 KN concentrated load applied at the center of the span of 10 m. Calculate the deflection and slope and also construct shear force and bending moment diagrams and take $I=2500 \text{ cm}^4$

6.a) Evaluate the axisymmetric stiffness matrix K of the triangular element shown in the figure .Consider the coordinates of the nodes (2,1), (4,00, and (3,2).also assume E= 2.6 GPa and v=0.2



b) Difference between CST and LST with respect to the triangular element.

7. Derive the stiffness matrix for the four noded quadrilateral element in terms of natural coordinate systems

OR

8.consider a brick wall of thickness 0.3 m ,k=0.7 W/m/K. The inner surface is at 28° C and the outer surface is exposed to cold air at -15°C. The heat transfer coefficient associated with the outside surface is 40W/m²K. Determine the steady state temperature distribution within in the wall and also the heat flux through the wall. Use two elements and obtain the solution

OR

9. Derive the conductivity matrix for two dimensional triangular element subjected to convection on one face of the element

10. For the stepped bar shown in figure. Develop the global stiffness and mass matrices and also determine the natural frequencies and mode shapes. Assume E=200 GPa and mass desity =7850 Kg/m³ L₁=L₂=0.3 m A₁=350mm² A₂=600 mm²



11.a)Derive the shape functions for the four noded tetrahedron element from the first principle

b)discuss the importance of semi automatic meshing and auto mesh along with the practical applications